





Easy Series Programmable Logic Controller **User Guide**

Suzhou Inovance Technology Co., Ltd.

>>>

Fundamental Safety Instructions

Safety Disclaimer

- This chapter explains the safety precautions that need to be paid attention to
 when using this product correctly. Before operating the equipment, read through
 the guide and comprehend all the safety instructions. To ensure the safety of
 humans and equipment, follow the signs on the equipment and all the safety
 instructions in this user guide. Failure to comply may result in severe personal
 injuries or even death or equipment damage.
- The DANGER, WARNING and NOTICE messages in the user guide does not cover all the safety risks.
- Use this product in environments meeting the design and specification requirements; otherwise, a fault may occur. Noncompliance-caused malfunction or damage to parts are not covered in product quality warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper usage.

Safety Levels and Definitions

DANGER Indicates that failure to comply with the notice can result in death or severe personal injuries.

warning Indicates that failure to comply with the notice may result in death or severe personal injuries.

Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

■ Safety Precautions

- Product illustrations in the user guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- Product illustrations in this guide are for reference only. Actual products may vary.

Unpacking



- Do not install the equipment if you find any sign of damage, rust, or prior use on the equipment or accessories.
- Do not install the equipment if you find any sign of water seepage or missing or damaged components.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.



- Check whether the packing is intact and whether there is any sign of damage, water seepage, dampness, and deformation.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is any sign of damage or rust on the surfaces of the equipment and accessories.
- Check whether the package contents are consistent with the packing list.

Storage and transportation



- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport this product in strict accordance with the storage and transportation requirements. Failure to comply may result in damage to the product.
- Do not store or transport the equipment in environments exposed to water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing this product for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

Installation



Installation must be carried out by the specialists who have received the necessary
electrical training and understood enough electrical knowledge. Ensure no
unprofessional person has access to the equipment.



- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, ensure that the installation position has sufficient mechanical strength to support the weight of the device. Failure to comply will result in a mechanical danger.
- To avoid electric shock, do not wear loose clothes or accessories.
- When this equipment is installed in a cabinet or final equipment, use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit this equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When this product is installed in a cabinet or terminal device, protection measures such as a fireproof enclosure, an electrical enclosure, or a mechanical enclosure must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing devices with strong electromagnetic interference, such as a transformer, install a shielding device for the equipment to prevent malfunction.
- Install the equipment onto flame retardant materials, such as metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.




- During installation, use a piece of cloth or paper to cover the top of the product to
 prevent metal chippings, oil, and water from entering into the product when drilling
 holes. Failure to comply will cause product malfunctions. After installation, remove the
 cloth or paper for effective ventilation and cooling.
- If the device running at a constant speed begins to run at variable speeds, resonance may occur. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring



- Only professionals are allowed to perform installation, wiring, maintenance, inspection or parts replacement on the equipment.
- Before wiring, cut off all the power supplies of the equipment. Wait as specified on the
 product warning sign before further operations because residual voltage exists after
 power-off. Measure the DC voltage of the main circuit and make sure that it is below the
 safety voltage. Failure to comply will result in an electric shock.
- Never perform wiring, remove the product cover, or contact the PCB at power-on. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply will result in an
 electric shock. Separate grounding or single-point grounding, other than common
 grounding, is recommended.





- Do not connect the input power supply to the output end of the equipment. Failure to comply can result in equipment damage or even a fire.
- When connecting a drive to the motor, make sure the phase sequence of the drive and motor are consistent to prevent motor reverse rotation.
- Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Ensure that all cables are connected correctly. Cable sheath is not damaged, and no screw or washer is left inside the equipment. Otherwise, electric shock or equipment damage may occur.



- During wiring, follow the proper electrostatic discharge (ESD) procedure and wear an antistatic wrist strap. Failure to comply can result in damage to the equipment or internal circuits.
- In wiring the control circuit, use shielded twisted pair cable and connect the shield to the PE terminal. Otherwise, the equipment may not function properly.

Power-on



- Before power-on, check that the equipment is installed properly, the wiring is secure and the motor can be restarted.
- Before power-on, check that the power supply meets equipment requirements to prevent equipment damage or even a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment. Do not touch any wiring terminals, or remove any part of the equipment at power-on.
 Failure to comply will result in an electric shock.



- Perform a trial run after wiring and parameter setting to ensure that the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, ensure that the nominal voltage of the equipment is consistent with the power supply voltage. Improper power supply voltage will cause a fire.
- Before power-on, ensure that there are no people around the equipment, motor and other machines. Failure to comply will result in injuries or death.

Operation



- Only qualified professionals are allowed to run the equipment. Failure to comply can result in injury or death.
- Do not touch any wiring terminals or remove any part of the equipment during operation. Failure to comply will result in an electric shock.



- Do not touch the equipment enclosure, fan, or resistor to sense the temperature. Failure to comply may result in burns.
- Prevent metal or other objects from falling into the device during operation. Failure to comply may result in a fire or product damage.

Maintenance



- Only professionals are allowed to perform installation, wiring, maintenance, inspection
 or parts replacement on the equipment.
- Do not perform maintenance on the equipment with power ON. Failure to comply can result in the risk of electric shock.
- Before maintenance, cut off all power supplies of the device and wait for a period specified on the warning label of the device.
- When a PM motor rotates, its terminals will produce induced voltage even if the motor is powered off. Failure to comply will result in an electric shock.



 Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.

Repair



- Only professionals are allowed to perform installation, wiring, maintenance, inspection
 or parts replacement on the equipment.
- Do not repair the equipment after power-on. Failure to comply can result in the risk of electric shock
- Before device inspection and repair, cut off all power supplies of the device and wait for a period specified on the warning label of the device.



- Submit the repair request according to the warranty agreement.
- When the fuse is blown, the circuit breaker trips, or the earth leakage circuit breaker (ELCB) trips, wait for a period specified on the warning label of the device before you energize or operate the device. Failure to comply may result in personnel injuries or damage to the device.
- When the device is faulty or damaged, require professionals to perform troubleshooting and repair by following repair instructions and keep a repair record.
- Replace quick-wear parts of the equipment according to the replacement instructions.
- Do not operate damaged device. Failure to comply may result in personnel injuries or death or greater damage to the device.
- After replacing the equipment, perform wiring inspection and parameter settings again.

Disposal



- Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death.
- Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.

Safety labels

To ensure safe operations, comply with safety signs on the device, and do not damage or remove the safety labels. See the following table for descriptions of the safety labels.

Safety Label	Description
10min	 Read through the safety instructions before operating the equipment. Failure to comply may result in death, personal injuries, or equipment damage.

1 Easy301 Programmable Logic Controller

User Guide

1.1 Preface

■ Introduction

The Easy301 series PLC, a new generation of small-scaled ultra-thin PLC developed by Inovance, carries RS485 and RS232 interfaces to achieve multi-layer network communication. It allows process packaging and reuse with FB/FC function and supports extension of up to eight modules.

This guide describes installation and wiring of the PLC, including product information, mechanical installation, and electrical installation.

Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the certifications compliant with, see the certification marks on the product nameplate.

Certification	Directive		Standard
CE certification	EMC Directive	2014/30/EU	24 VDC products:
			EN 61131-2
			220 VAC products:
			EN 61131-2
			EN 61000-3-2
			EN 61000-3-3
	Low Voltage	2014/35/EU	EN 61010-1
	Directive (LVD)		EN 61010-2-201
	RoHS Directive	2011/65/EU amended by (EU)2015/863	EN IEC 63000
UL/cUL	_	., (.,,	UL 61010-1
certification			UL 61010-2-201
			UL 61010-2-201
			CAN/CSA-C22.2 No. 61010-1
			CSA C22.2 NO. 61010-2- 201
			CSA C22.2 NO. 61010-2- 030
KCC certification	-		-
EAC certification	-		-

■ Revision history

Date	Version	Description
March 2023	A02	Updated DIN rail mounting hook diagram and product specifications.
October 2022	A01	Made minor corrections.
August 2022	A00	First release

■ Document acquisition

This guide is not in the scope of delivery. If necessary, you can download the PDF file in two ways:

- Log in to Inovance's website (<u>www.inovance.com</u>), choose Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

■ Warranty

The warranty period of the product is 18 months as of the date of manufacture (refer to the barcode on the equipment). If otherwise agreed upon, the agreed terms and conditions shall prevail. After the warranty period expires, maintenance will be charged.

Within the warranty period, maintenance will be charged for damages caused by the following:

- Operations not following instructions in the user guide
- Fire, flood, and abnormal voltage
- Unintended use
- Improper use outside the designed scope of application
- Force majeure (such as natural disaster, earthquake, and lightning strike) and the secondary damage caused thereof

The maintenance fee is charged according to the latest Maintenance Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail. For details, see Product Warranty Card.

1.2 产品信息

1.2.1 Model and Nameplate

Model description

$$\frac{\text{Easy}}{(1)} \frac{301}{(2)} - \frac{0808}{(3)} \frac{\text{TN}}{(4)}$$

1 Product Series

Easy: Easy series programmable logic controller

② Series Number

- 3: Without EtherCAT
- 0: Without Ethernet
- 1: Model serial number

③ Inputs/Outputs


08: 8 inputs

08: 8 outputs

4 Output Type


TN: SINK transistor

■ Description of the nameplate



Model	Description	Code
•	Easy300 series programmable controller with 8 inputs and 8 outputs	01440323

1.2.2 Components



No.	Terminal Type	Terminal Code	Assignment	Indicator color	Description
		PWR	Power supply	Yellow- green	 Solid ON: Indicates that the power supply is normal. OFF: Indicates that the power supply is abnormal.
1	Operation status indicator	RUN	Running	Yellow- green	Solid ON: Indicates that the user program is running. OFF: Indicates that the user program has been stopped.
	ERR	Error	Red	OFF: Indicates no critical errors occur. Flashing: Indicates a critical error has occurred.	
2	DIP switch	RUN/ STOP	Used to control the operation of the controller.	-	-
3	Type-C interface	æ	Communica- tion with PC	-	-
		485+	RS485 communica- tion signal+	-	-
④ RS485	485-	RS485 communica- tion signal-	-	-	
		GND	RS485 communica- tion GND	-	-
(5)	I/O terminal	-	8 inputs and 8 outputs	-	See details in "1.4.1 Layout of Terminals" on page 29.

No.	Terminal Type	Terminal Code	Assignment	Indicator color	Description
	Power	+24V	24 VDC power supply (+)	-	-
6	supply interface	OV	24 VDC power supply (-)	-	-
		4	PE	-	-
7	I/O indicator	X/Y	I/O status display	Yellow- green	 Solid ON: Indicates the input or output is active. OFF: Indicates the input or output is inactive.
8	RS-232	TX	RS232 signal transmission	-	-
		RX	RS232 signal reception	-	-
		GND	RS232 GND	-	-

1.2.3 Specifications

1.2.3.1 General Specifications

Item	Specifications
Program data capacity	128 k-step user program
	1 Mb user-defined variables, in which 128 kb variables are retentive at power failure
	About 150 k soft elements (Elements after No. 1000 are retentive at power failure.)
Speed reference	20 k-step user program executed in 2 ms
Bit operations	0.144 μs/reference
Word transfer	0.338 μs/reference
Float operation	0.779 μs/reference
Ethernet	-
EtherCAT communication	-
Serial communication	1 x RS485 and 1 x RS232
CAN communication	-

Item	Specifications
High-speed input	Single-phase: 8-channel 200 k
High-speed output	4-axis 200 k, PWM pulse width modulation supported
Extension module	Supports up to 8 local extension modules
Extension card	-
Program language	LD, SFC, FB/FC function (LD) supported
Type-C	Supports upload and download of user programs and firmware upgrade.
IP rating	IP20
Dimensions (W x H x D)	24 mm x 100 mm x 83 mm
Weight	About 135 g

1.2.3.2 Power Supply Specifications

Item	Specifications
Rated voltage of terminal input power supply	24 VDC±10% (21.6 VDC to 26.4 VDC)
Rated current of terminal input power supply	1 A (maximum value at 24 V)
24 V input power supply protection	Providing protection against short circuit and reverse connection
Hot-plugging	Not supported

1.2.3.3 Input Specifications

Item	Specifications	
Input type	Digital input	
Number of input channels	8	
Input mode	SINK/SOURCE	
Input voltage class	24 VDC±10% (21.6 VDC to 26.4 VDC)	

Item		Specifications	
	Input current at input ON	> 4 mA	
High-speed	Input current at input OFF	< 2.5 mA	
input	Hardware response time	2 μs (RC time)	
(X0-X7)	Max. input frequency	200 kHz	
	Input impedance	2.7 K	
ON voltage		≥ 15 VDC	
OFF voltage		≤ 5 VDC	
Software filter time		Low-speed: 2 ms to 1000 msHigh speed: 2 μs to 1000 μs	
Isolation mode		Isolated by digital isolator chip	
Common terminal mode		8-point/common terminal (The polarity +/- of input power supply is changeable.)	
Input action display		The input indicator lights up (controlled by software) when the input is in drive state.	

1.2.3.4 Output Specifications


Item	Specifications
Output type	Transistor NPN
Number of output channels	8
Output voltage class	24 VDC±10% (21.6 VDC to 26.4 VDC)

Item		Specifications		
	Output load (resistive load)	0.5 A/point; 2 A/8-point		
	Output load (inductive load)	7.2 W/point; 24 W/8-point		
High-speed	Output load (lamp load)	5 W/point, 18 W/8-point		
output (Y0 to Y3)	Hardware response time ON/OFF	< 1 μs (OFF \rightarrow ON); < 2 μs (ON \rightarrow OFF)		
	Load current requirements	Load current ≥ 12 mA when used with outputs greater than 10 kHz		
	Max. output frequency	200 kHz for resistive load; 0.5 Hz for inductive load; 10 Hz for lamp load		
	Output load (resistive load)	0.5 A/point, 1 A/common terminal		
	Output load (inductive load)	6 W/24 VDC (total)		
Common	Output load (lamp load)	1 W/24 VDC (total)		
output (Y4 to Y7)	Hardware response time ON/OFF	< 100 μs (OFF→ON, ON→OFF)		
	Load current requirements	≥5 mA		
	Maximum output frequency	100 Hz with resistive load, 0.5 Hz with inductive load, 10 Hz with lamp load		
PWM output (Y0 to Y3)		Maximum frequency 200 kHz, minimum pulse width 2.5 μ s, minimum resolution 2.5 μ s, adjustable duty cycle ^[1] 0.01% to 99.99%		
Leakage current at OFF		Less than 30 μA at 24 V		
Max. residual voltage during ON		Less than 0.5 VDC		
Isolation mode		Opto-coupler isolation		
Common terminal mode		8-point/common terminal (polarity of output power supply being "-")		

Item	Specifications
Short circuit protection	Providing protection against short circuit of each channel (The short circuit protection state can be cancelled through a power cycle.)
External inductive load protection	Connect a flywheel diode ^[2] when connecting the external inductive load.
Output action display	The output indicator lights up (controlled by software) when the output is in drive state.

[1]: The duty cycle setting is frequency dependent, and the pulse width corresponding to the duty cycle is not less than the minimum pulse width.

[2]: D: 1N4001 or similar diodes are shown in the following figure.



1.3 Mechanical Installation

1.3.1 Installation Environment

Take the operability, serviceability, and adaptability to environment into account when installing the programmable controller.

Item	Specification
Working environment	Free from corrosive and flammable gas, as well as excessive conductive dust
Altitude	Up to 2000 m (80 kPa)
Pollution degree	PD2
Immunity	2 kV on power supply line (compliant with IEC 61000-4-4)
Overvoltage category	I

Item	Specification
EMC immunity level	Zone B, IEC61131-2
vibration resistance	IEC 60068-2-6, 5 Hz to 8.4 Hz, 3.5 mm, 8.4 Hz to 150 Hz, 1 g, 10 cycles in each of X, Y and Z directions
Shock resistance	IEC 60068-2-27 150 m/s², 11 ms, 3 times each in \pm X, \pm Y and \pm Z directions, 18 times in total
Overcurrent protection device	1.1 A fuse
Storage	• Storage temperature: -20°C to +60°C
temperature/ humidity	Relative humidity: < 90% RH (without condensation)
Shipping temperature/ humidity	Shipping temperature: -40°C to +70°C Relative humidity: < 95% RH (without condensation)

Item	Specification
Operating temperature/ humidity	 Operating temperature: -20°C to +55°C (when installed horizontally), -20°C to +45°C (when installed non-horizontally) Relative humidity: < 95% RH (without condensation)
	Note: Install a fan or air conditioner in the direction of the cooling hole when the operating temperature is greater than the maximum temperature.

Item	Specification
Installation position and limit	Installation position: The PLC can be installed in four directions as shown in "1.3.2 Installation Position" on page 23. Limit:
	When installed horizontally:
	• When installed horizontally.
	Input derating: The PLC can operate with full load at ambient temperature of 45°C. Derate the number of ON input points to 75% (lower than or equal to six ON input points) at ambient temperature of 55°C. Derate the number of ON input points by 2.5% for every additional 1°C above 45°C.
	Oceaning of ON Input Points (%)
	. 45 55
	Amblent temperature (°C)
	Output derating: The PLC can operate with full load (total current of eight channels not exceeding 2 A) at ambient temperature of 45° C. Derate the total output current of ON output points to 50% (total current of eight channels not exceeding 1 A) at ambient temperature of 55°C. Derate the total output current of ON output points by 5% for every additional 1°C above 45°C.
	Desting of total output current (%)
	Ambient temperature (°C)
	When installed non-horizontally: The maximum number of input points connected cannot exceed six and the maximum output current cannot


exceed 1 A.

1.3.2 Installation Position

The PLC can be mounted horizontally, vertically, on top or at the bottom of the electric control cabinet. Different installation positions require different operating temperatures, see "1.3.1 Installation Environment" on page 19.

Optimal installation position

It is recommended to install the PLC horizontally, with natural convection as the cooling mode. To ensure normal ventilation and heat dissipation and allow sufficient wiring space, reserve enough clearance around the PLC, as shown in the following figure.




Note

Keep the PLC away from high-temperature heating sources (heater, transformer, large resistor, etc.) by at least 100 mm.

Other installation positions

The surrounding clearance required on other installation positions are the same as the optimal one. Other installation positions are shown in the diagram below.





In case of vertical installation:

- Install the PLC below all I/O modules.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate. Failure to comply may cause displacement of the PLC from the DIN rail, leading to maloperation of the PLC.

1.3.3 Installation Precaution

 Before installing or removing the master and module, ensure that the master and module are powered off.




Do not connect/disconnect the module with power ON. This may lead to master restart or user data loss or damage.

 Prevent the master, module enclosure, or terminals from dropping or suffering from impact or shock.


1.3.4 Installation Dimensions

The installation dimensions (in mm) are shown in the figure below.



1.3.5 Installation Methods

The controller is mounted onto a DIN rail that complies with IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (unit: mm) are shown below.







When installed on a DIN rail other than the recommended one (especially the one whose thickness is not 1.0 mm), the product will not fit in place as the mounting hook does not work.

■ Installing the master

 Align the controller with the DIN rail and push the controller in the direction indicated by the arrow until you hear a clicking sound, as shown below.



Make sure the DIN rail mounting hook of the controller is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- $\bullet \hspace{0.1in}$ If the mounting hook is lifted up, it is unlocked.


Press down the mounting hook to lock the controller to the DIN rail.




Keep the mounting hook locked when the controller is not mounted on the rail. If the mounting hook is kept unlocked for an extended period of time, it may malfunction.

Installing the module to the master

Install the extension module to the master through top and bottom rails, as shown below.




Install an DIN rail end plate to both sides of the master or module. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



■ Removing the module

Pry the mounting hook upwards with a tool such as a straight screwdriver or similar, and pull out the module forwardly. Then press down the top of the mounting hook.



1.4 电气安装

1.4.1 Layout of Terminals




Signal on the left	Terminals on the left	Terminals on the right	Signals on the right
X0 input	X0	Y0	Y0 output
X1 input	X1	Y1	Y1 output
X2 input	X2	Y2	Y2 output
X3 input	Х3	Y3	Y3 output
X4 input	X4	Y4	Y4 output
X5 input	X5	Y5	Y5 output
X6 input	X6	Y6	Y6 output
X7 input	X7	Y7	Y7 output
Common terminal for input	SS	СОМ	Common terminal for output




- Check the silk print on both sides of the terminals to prevent wrong connection. Failure to comply may result in short circuit and damage to the device.
- The length of a high-speed I/O interface extension cable must be within 3.0 m.
- To prevent interference, route the I/O interface extension cable and the power cable (high-voltage/high-current cables) through different and nonparallel routes.

1.4.2 Wiring of Input Terminals


SINK input wiring



SOURCE input wiring



1.4.3 Wiring of Output Terminals



Note

Connect a flywheel diode when connecting the external inductive load. Diodes can be 1N4001 or similar.

1.5 通信连接


1.5.1 Cable Selection

Power cable

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		KST		Suzhou Yuanli	
name	a	area				
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
	0.3	22	E0308		0308	
	0.5	20	E0508		0508	
Tubular lug	0.75	18	E7508	KST2000L	7508	YAC-5
8	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

If you use other types of tubular lug, crimp the lug to the cable as shown below.




Communication cable

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		KST		Suzhou Yuanli	
name	area					
	GB/mm ²	AWG	Model	Crimping tool	Model	Crimping tool
Tubular	0.3	22	E0308	KST2000L	0308	VAC 5
lug	0.5	20	E0508		0508	YAC-5

If you use other types of tubular lug, crimp the lug to the twisted pairs as shown below.



1.5.2 Cable Connection

■ RS485&RS232 communication

The RS485 communication port and the RS232 communication port share the same terminal block, with RS485 communication port on the left and RS232 communication port on the right.



■ RS485&RS232 terminal assignment

Description	Left terminal	Right terminal	Description
RS485 differential pair (+)	485+	TX	RS232 signal transmission
RS485 differential pair (-)	485-	RX	RS232 signal reception
RS485 ground	GND	GND	RS232 ground



Check the silk print on both sides of the terminal to prevent wrong connection. Do not connect the GND cable to the lower I/O terminal. Failure to comply can result in short circuit and damage to the device.

■ RS485 communication specifications

Item	Description
Number of channel supported	1
Hardware interface	2 x 12-pin terminal (shared with DI/DO)
Isolation mode	Non-isolation
Termination resistor	Without termination resistor
Number of slaves connected	Up to 31 slaves (The length of each slave branch must be shorter than 3 m.)
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s
Short circuit protection	Providing protection against improper connection of 24 V power supply

■ RS232 communication specifications

Item	Description
Number of channel supported	1
Hardware interface	2 x 12-pin terminal (shared with DI/DO)
Isolation mode	Non-isolation
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s


■ Wiring

Select the communication cable according to "1.5.1 Cable Selection" on page 31. Insert the communication cable to the communication port.

1.5.3 Instructions on RS485 Communication

It is recommended to use a shielded twisted pair cable as the RS485 bus. Connect a $120\,\Omega$ termination resistor to both ends of the bus respectively to prevent signal reflection. Connect the signal reference grounds of all nodes together. Up to 31 nodes can be connected and the distance between nodes must be less than 3 m.

The RS485 bus topology is shown in the figure below.



1.6 Operation and Maintenance

1.6.1 Start and Stop

After programming the PLC, follow the steps below to start and stop it.

The PLC is programmed when it is in STOP state. To start PLC:

- Set the system to RUN state.
 Check that the RUN indicator is solid ON in yellow green.
- To stop the PLC, set the system to STOP state. Alternatively, you can stop it in the software tool of the host controller.

2 Easy302 Programmable Logic Controller

User Guide

2.1 Preface

Introduction

The Easy302 series PLC, a new generation of small-scale PLC developed by Inovance, carries RS485 and RS232 interfaces to achieve multi-layer network communication. It allows process packaging and reuse with FB/FC function and supports extension of up to 16 modules. The RS485/RS232/CAN/DI/DO/AI/AO/RTC clock/TF card functions can also be extended through the extension card.

This guide describes installation and wiring of the PLC, including product information, mechanical installation, and electrical installation.

Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the certifications compliant with, see the certification marks on the product nameplate.

Certification	Dii	rective	Standard
CE certification	EMC	2014/30/EU	24 VDC products:
	Directive		EN 61131-2
			220 VAC products:
			EN 61131-2
			EN 61000-3-2
			EN 61000-3-3
	Low Voltage	2014/35/EU	EN 61010-1
	Directive (LVD)		EN 61010-2-201
	RoHS Directive	2011/65/EU amended by (EU)2015/863	EN IEC 63000
UL/cUL certification	-		UL 61010-1
			UL 61010-2-201
			UL 61010-2-030
			CAN/CSA-C22.2 No. 61010-1
			CSA C22.2 NO. 61010-2-201
			CSA C22.2 NO. 61010-2-030
KCC certification	-		-
EAC certification	-		-

■ More Documents

Document Name	Data Code	Description
GE20 Series Extension Card User Guide		Provides product information, installation and wiring, programming examples and for GE20 series extension card.

Revision history

Date	Version	Revision
March 2023	A02	Updated DIN rail mounting hook diagram and product specifications.
October 2022	A01	Added CAN communication function.Made minor corrections.
August 2022	A00	First release

Document acquisition

This guide is not in the scope of delivery. If necessary, you can download the PDF file in two ways:

- Log in to Inovance's website (<u>www.inovance.com</u>), choose Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

Warranty Instructions

The warranty period of the product is 18 months as of the date of manufacture (refer to the barcode on the equipment). If otherwise agreed upon, the agreed terms and conditions shall prevail. After the warranty period expires, maintenance will be charged.

Within the warranty period, maintenance will be charged for damages caused by the following:

- Operations not following instructions in the user guide
- Fire, flood, and abnormal voltage
- Unintended use
- Improper use outside the designed scope of application
- Force majeure (such as natural disaster, earthquake, and lightning strike) and the secondary damage caused thereof

The maintenance fee is charged according to the latest Maintenance Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail.

For details, see Product Warranty Card.

2.2 产品信息

2.2.1 Model and Nameplate

■ Model

Easy 302 - 0808 TN 3 4

Product series

Easy: Easy series programmable logic controller

3 Inputs/Outputs 08: 8 inputs 08: 8 outputs

Series No.

3: Without EtherCAT


0: Without Ethernet

2: Model serial number

4 Output type


TN: SINK transistor

■ Nameplate



Model	Description	Code
Easy302-0808TN	Easy300 series programmable controller with 8 inputs and 8 outputs	01440324

2.2.2 Components



No.	Terminal Type	Terminal Code	Assignment	Indicator color	Description
		PWR	Power supply	Yellow-green	 Solid ON: Indicates that the power supply is normal. OFF: Indicates that the power supply is abnormal.
1	Operation status indicator	RUN	Operation	Yellow-green	 Solid ON: Indicates that the user program is running. OFF: Indicates that the user program has been stopped.
		ERR	Operation error	Red	 OFF: Indicates no critical errors occur. Flashing: Indicates a critical error has occurred.
2	DIP switch	RUN/STOP	Used to control start/stop of the master.	-	-
3	Type-C interface	æ	Communication with PC	-	-
		485+	RS485 communica- tion signal+	-	-
4	RS485	485-	RS485 communica- tion signal-	-	-
		GND	RS485 communica- tion GND	-	-
⑤/- ⑦	Extension card slot	EXP-A/ EXP-B	Used for function extension.	-	Extension card options are available in "2.7 Appendix: Extension Card Options" on page 64.
6	I/O terminal	_	8 inputs and 8 outputs	-	See details in "2.4.1 Layout of Terminals" on page 56.

No.	Terminal Type	Terminal Code	Assignment	Indicator color	Description
	Power	+24V	24 VDC power supply (+)	-	-
8	supply interface	0V	24 VDC power supply (-)	-	-
		4	PE	-	-
9	I/O indicator	X/Y	I/O status display	Yellow-green	Solid ON: Indicates the input or output is active. OFF: Indicates the input or output is inactive.
		TX	RS232 signal transmis- sion	-	-
10	RS232	RX	RS232 signal reception	-	-
		GND	RS232 ground	-	-

2.2.3 Specifications

2.2.3.1 General Specifications

Item	Specifications
Program data capacity	128 k-step user program 1 Mb user-defined variables, in which 128 kb variables are retentive at power failure About 150 k soft elements (Elements after No. 1000 are retentive at power failure.)
Speed reference	20 k-step user program executed in 2 ms
Bit operation	0.144 μs/reference

Item	Specifications
Word transmission	0.338 μs/reference
Float operation	0.779 μs/reference
Ethernet	-
EtherCAT communication	-
Serial communication	Supports up to 3 channels (two channels in the main unit and one channel extended in the expansion card).
CAN communica-	Supports 1 master through the extension card (firmware version 5.65.2.0 and later, software version AutoShop4.6.5.0 and later).
tion	CANlink: Supports up to 63 slaves.CANopen Supports up to 30 slaves.
High-speed input	Single-phase: 8-channel 200 k
High-speed output	5-axis 200 k, PWM pulse width modulation supported
Extension module	Supports up to 16 local extension modules.
Extension card	Supports up to two extension cards.
Program language	LD, SFC, FB/FC function (LD) supported
Type-C	Supports user program download/upload and firmware upgrade through type-C or GE20–TF extension card.
IP rating	IP20
Dimensions (W x H x D)	40 mm x 100 mm x 83 mm
Weight	About 157 g

2.2.3.2 Power Supply Specifications

Item	Specifications
Rated voltage of terminal input power supply	24 VDC±10% (21.6 VDC to 26.4 VDC)
Rated current of terminal input power supply	1 A (maximum value at 24 V)
24 V input power supply protection	Providing protection against short circuit and reverse connection
Hot-plugging	Not supported


2.2.3.3 Input Specifications

	Item	Specifications	
Input type		Digital input	
Number of i	nput channels	8	
Input mode		Sink/Source	
Input voltag	e class	24 VDC±10% (21.6 VDC to 26.4 VDC)	
	Input current at input ON	> 4 mA	
High-speed	Input current at input OFF	< 2.5 mA	
input	Hardware response time	2 μs (RC time)	
(X0-X7)	Max. input frequency	200 kHz	
	Input impedance	2.7 K	
ON voltage		≥ 15 VDC	
OFF voltage		≤ 5 VDC	
Software filter time		 Low-speed: 2 ms to 1000 ms High speed: 2 μs to 1000 μs 	
Isolation mode		Isolated by digital isolator chip	
Common terminal mode		8-point/common terminal (The polarity +/- of input power supply is changeable.)	
Input action display		The input indicator lights up (controlled by software) when the input is in drive state.	

2.2.3.4 Output Specifications

	Item	Specifications	
Output type		Transistor NPN	
Number of C	Output Channels	8	
Output volta	ige class	24 VDC±10% (21.6 VDC to 26.4 VDC)	
	Output load (resistive load)	0.5 A/point; 2 A/8-point	
	Output load (inductive load)	7.2 W/point; 24 W/8-point	
High-speed output	Output load (lamp load)	5 W/point, 18 W/8-point	
(Y0 to Y7)	Hardware response time ON/OFF	< 1 us (OFF→ON); < 2 us (ON→OFF)	
	Load current requirements	Load current ≥ 12 mA when used with outputs greater than 10 kHz	
	Max. output frequency	200 kHz for resistive load; 0.5 Hz for inductive load; 10 Hz for lamp load	
PWM output		Maximum frequency 200 kHz, minimum pulse width 2.5 μ s, minimum resolution 2.5 μ s, adjustable duty cycle $^{[1]}0.01\%$ to 99.99%	
Leakage cur	rent at OFF	Less than 30 uA at 24 V	
Max. residua	l voltage during ON	Less than 0.5 VDC	
Isolation mo	ode	Digital isolator	
Common ter	rminal mode	8-point/common terminal ("-" of power supply)	
Short circuit protection		Providing protection against short circuit of each circuit (The short circuit protection state can be cancelled through a power cycle.)	
External inductive load protection		Connect a flywheel diode ^[2] when connecting the external inductive load.	
Output action display		The output indicator lights up (controlled by software) when the output is in drive state.	

- [1]: The duty cycle setting is frequency dependent, and the pulse width corresponding to the duty cycle is not less than the minimum pulse width.
- [2]: D: 1N4001 or similar diodes, as shown in the following figure.



2.3 Mechanical Installation

2.3.1 Installation Environment

Take the operability, serviceability, and adaptability to environment into account when installing the PLC.

Item	Specification
Working environment	Free from corrosive and flammable gas, as well as excessive conductive dust
Altitude	Up to 2000 m (80 kPa)
Pollution degree	PD2
Immunity	2 kV on power supply line (compliant with IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2
Vibration resistance	IEC 60068-2-6, 5 Hz to 8.4 Hz, 3.5 mm, 8.4 Hz to 150 Hz, 1 g, 10 cycles in each of X, Y and Z directions
Shock resistance	IEC 60068-2-27 150 m/s², 11 ms, 3 times each in \pm X, \pm Y and \pm Z directions, 18 times in total
Overcurrent protection device	1.1 A fuse

Item	Specification
Storage Temperature and Humidity Range	 Storage temperature: -20°C to +60°C Relative humidity: < 90% RH (without condensation)
Shipping temperature/ humidity	 Shipping temperature: -40°C to +70°C Relative humidity: < 95% RH (without condensation)

Item	Specification
Operating temperature/ humidity	 Operating temperature: -20°C to +55°C (when installed horizontally), -20°C to +45°C (when installed non-horizontally) Relative humidity: < 95% RH (without condensation)
	Note: Install a fan or air conditioner in the direction of the cooling hole when the operating temperature is greater than the maximum temperature.

Item	Specification
Installation position and limit	Installation position: The PLC can be installed in four directions as shown in "2.3.2 Installation Position" on page 50. Limit:
	When installed horizontally:
	Input derating: The PLC can operate with full load at ambient temperature of 45°C. Derate the number of ON input points to 75% (lower than or equal to six ON input points) at an ambient temperature of 55°C. Derate the number of ON input points by 2.5% for every additional 1°C above 45°C.
	Denating of ON input points (N)
	Amblent temperature (°C) 45 55
	Output derating: The PLC can operate with full load (total current of eight output points not exceeding 2 A) at an ambient temperature of 45°C. Derate the total output current of ON output points to 50% (total current of eight output points not exceeding 1 A) at an ambient temperature of 55°C. Derate the total output current of ON output points by 5% for every additional 1°C above 45°C.
	Described of total output aurent (8)
	Ambient temperature (°C)
	When installed non-horizontally: The maximum number of input points connected cannot exceed six and the maximum output current cannot

-49-


exceed 1 A.

2.3.2 Installation Position

The PLC can be installed horizontally, vertically, or to top/bottom of the cabinet. It is recommended to install the PLC horizontally. Different installation positions require different operating temperatures and limits. For details, see "2.3.1 Installation Environment" on page 46.

Optimal installation position

It is recommended to install the PLC horizontally, with natural convection as the cooling mode. To ensure normal heat dissipation and sufficient wiring space, reserve minimum clearance around the PLC, as shown below.




Note

Keep the PLC away from high-temperature heating sources (heater, transformer, large resistor, etc.) by at least 100 mm.

■ Other installation positions

The surrounding clearance required on other installation positions are the same as the optimal one. Other installation positions are shown in the diagram below.





In case of vertical installation:

- Install the PLC below all I/O modules.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate. Failure to comply may cause displacement of the PLC from the DIN rail, leading to maloperation of the PLC.

2.3.3 Installation Precaution

 Before installing or removing the master and module, ensure that the master and module are powered off.




Do not connect/disconnect the module with power ON. This may lead to master restart or user data loss or damage.

 Prevent the master, module enclosure, or terminals from dropping or suffering from impact or shock.


2.3.4 Installation Dimensions

The installation dimensions (in mm) are shown in the figure below.



2.3.5 Installation Methods

The master is mounted onto a DIN rail that complies with IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (unit: mm) are shown below.






When installed on a DIN rail other than the recommended one (especially the one whose thickness is not 1.0 mm), the module will not fit in place as the mounting hook does not work.

■ Installing the master

 Align the master with the DIN rail and push the module in the direction indicated by the arrow until you hear a clicking sound, as shown below.



Make sure the DIN rail mounting hook of the master is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.


Press down the mounting hook to lock the master to the DIN rail.




Keep the mounting hook locked when the controller is not mounted on the rail. If the mounting hook is kept unlocked for an extended period of time, it may malfunction.

Installing the module to the master

Install the extension module to the master through top and bottom rails, as shown below.




Install an DIN rail end plate to both sides of the master or module. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



■ Removing the module

Pry the mounting hook upwards with a tool such as a straight screwdriver or similar, and pull out the module forwardly. Then press down the top of the mounting hook.



2.4 电气安装

2.4.1 Layout of Terminals




Signals on the left	Terminals on the left	Terminals on the right	Signals on the right
X0 input	X0	Y0	Y0 output
X1 input	X1	Y1	Y1 output
X2 input	X2	Y2	Y2 output
X3 input	Х3	Y3	Y3 output
X4 input	X4	Y4	Y4 output
X5 input	X5	Y5	Y5 output
X6 input	X6	Y6	Y6 output
X7 input	X7	Y7	Y7 output
Common terminal for input	SS	СОМ	Common terminal for output




- Check the silk print on both sides of the terminal to prevent wrong cable connection. Failure to comply may lead to short circuit, which can damage the components.
- The total extended length of high-speed I/O interface extension cable must be within 3 m.
- To prevent interference, route the I/O interface extension cable and the power cable (high-voltage/high-current cables) through different and nonparallel routes.

2.4.2 Wiring of Input Terminals


SINK input wiring



SOURCE input wiring



2.4.3 Wiring of Output Terminals



Note

Connect a flywheel diode when connecting the external inductive load. Diodes can be 1N4001 or similar.

2.5 通信连接


2.5.1 Cable Selection

Power cable

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		ŀ	(ST	Suzhou	ı Yuanli
name	a	rea				
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
	0.3	22	E0308		0308	
-	0.5	20	E0508		0508	
Tubular lug	0.75	18	E7508	KST2000L	7508	YAC-5
6	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

If you use other types of tubular lug, crimp the lug to the cable as shown below.




Communication cable

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		ŀ	(ST	Suzhou	ı Yuanli
name	area					
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
Tubular	0.3	22	E0308	KST2000L	0308	VAC E
lug	0.5	20	E0508		0508	YAC-5

If you use other types of tubular lug, crimp the lug to the twisted pairs as shown below.



2.5.2 Cable Connection

■ RS485&RS232 communication

The RS485 communication port and the RS232 communication port share the same terminal block, with RS485 communication port on the left and RS232 communication port on the right. The signal on the left side of the terminal is RS485 communication, and the signal on the right side is RS232 communication.



■ RS485&RS232 terminal assignment

Description	Terminals on the left	Terminals on the right	Description
RS485 differential pair (+)	485+	TX	RS232 signal transmission
RS485 differential pair (-)	485-	RX	RS232 signal reception
RS485 ground	GND	GND	RS232 ground



Check the silk print on both sides of the terminal to prevent wrong cable connection. Do not connect the GND cable to the I/O terminal on the lower side. Failure to comply can lead to short circuit and damage the components.

■ RS485 communication specifications

Item	Description
Number of channels supported	Two channels at most (one built-in and one extended in the extension card, three serial ports can be connected at most including RS232)
Hardware interface	2 x 12-pin terminal (shared with the DIDO)
Isolation mode	Non-isolated
Termination resistor	Without termination resistor
Number of slaves connected	Up to 31 slaves (The length of each slave branch must be shorter than 3 m.)
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s
Short circuit protection	Providing protection against improper connection of 24 V power supply

■ RS232 communication specifications

Item	Description
Number of channels supported	Two channels at most (one built-in and one extended in the extension card, three serial ports can be connected at most including RS232)
Hardware interface	2 x 12-pin terminal (shared with the DIDO)
Isolation mode	Non-isolated
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s


■ Wiring

See "2.5.1 Cable Selection" on page 58 to select the communication cable and insert it into the communication port.

2.5.3 RS485 Communication Instructions

It is recommended to use a shielded twisted pair cable as the RS485 bus. Connect a $120\,\Omega$ termination resistor to both ends of the bus respectively to prevent signal reflection. Connect the signal reference grounds of all nodes together. Up to 31 nodes can be connected and the distance between nodes must be less than 3 m.

The RS485 bus topology is shown in the figure below.



2.6 Operation and Maintenance

2.6.1 Start and Stop

After programming the PLC, follow the steps below to start and stop it.

The PLC is programmed when it is in STOP state. To start PLC:

- Set the system to RUN state.
 Check that the RUN indicator is solid ON in yellow green.
- To stop the PLC, set the system to STOP state. Alternatively, you can stop it in the software tool of the host controller.

2.6.2 Programming of SD Card User Programs

- Save the SD card programming file compiled by Autoshop to the directory "PLCProgram" of the SD card (maximum capacity 32 GB, file formate FAT32).
- 2. Load the SD card onto the TF extension card and install the card to the PLC.



Install the TF extension card with power off.

- 3. Power on the PLC again and start programming the user programs in the SD card to the PLC. The RUN indicator flashes at a frequency of 4 Hz during programming.
- 4. After programming is done, the RUN indicator flashes at a frequency of 1 Hz and this PLC enters the STOP state. You can remove the SD card now.

 If the ERR indicator flashes should programming fails. Check that the model of the
 - If the ERR indicator flashes slowly, programming fails. Check that the model of the programming file is consistent with the actual model and the login password of the programming file is the same as that of the PLC. If the model and password are both correct but the programming failure still occurs, contact Inovance for technical support.
- 5. Power off and on again.

2.6.3 SD Card Firmware Upgrade

1. Load the SD card (maximum capacity 32 GB, file format FAT32) to the TF extension card and the PLC



Install the TF extension card with power off.

- 2. Power on the PLC again.
 - The RUN and ERR indicators flash quickly for 3s, indicating that the firmware upgrade begins. The RUN and ERR indicators remain solid ON, indicating that the firmware is being upgraded. The RUN and ERR indicators flash slowly, indicating that the firmware upgrade is done.
- 3. After firmware upgrade is done, power off the PLC and remove the SD card.
- 4. Power on the PLC again.

2.7 Appendix: Extension Card Options

Model	Туре	Description	Slot	ID
GE20-4DI	Digital input/ output	4 inputs 24 VDC input Source/Sink	A/B	13
GE20-4DO-TN		4 transistor sink outputs 24 VDC output	A/B	5
GE20- 2AD1DA-I	Analog input/ output	2 analog inputs and 1 analog output (current type)	A/B	11
GE20- 2AD1DA-V		2 analog inputs and 1 analog output (voltage type)	A/B	3
GE20-CAN-485	Communication extension	CAN and 485 communication (RJ45 interface)	A	15
GE20-232/485		RS232 or RS485 communication	A/B	7
GE20-232/ 485-RTC		RS232 or RS485 communication (with RTC)	В	14
GE20-TF	Storage extension	TF extension card	В	1
GE20-RTC	Clock extension	Clock extension card	В	9

Note

The ID is "0" when there is no extension card.

3 Easy320 Programmable Logic Controller

User Guide

3.1 Preface

Introduction

The Easy320 series PLC, a new generation of small PLC developed by Inovance, supports network switchover through two network ports and allows process packaging and reuse through FB/FC function. With RS485 and EtherCAT, a multi-layer network communication can be realized through this PLC, with 16 modules extendable. RS485/RS232/CAN/DI/DO/AI/AO/RTC clock/TF card functions can also be extended through the extension card.

This guide describes installation and wiring of the PLC, including product information, mechanical installation, and electrical installation.

Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the certifications compliant with, see the certification marks on the product nameplate.

Certification	Dire	ective	Standards compliance
CE certification	EMC Directive	2014/30/EU	24 VDC products:
			EN 61131-2
			220 VAC products:
			EN 61131-2
			EN 61000-3-2
			EN 61000-3-3
	Low Voltage	2014/35/EU	EN 61010-1
	Directive (LVD)		EN 61010-2-201
	RoHS Directive	2011/65/EU amended by	EN IEC 63000
		(EU)2015/863	
UL/cUL certification	-		UL 61010-1
			UL 61010-2-201
			UL 61010-2-030
			CAN/CSA-C22.2 No. 61010-1
			CSA C22.2 NO. 61010-2-201
			CSA C22.2 NO. 61010-2-030
KCC certification	-		-
EAC certification	-		-

■ More Documents

Document Name	Data Code	Description
GE20 Series Extension Card User Guide	PS00006443	Provides product information, installation and wiring, programming examples and for GE20 series extension card.

Revision history

Date	Version	Revision
March 2023	A02	Updated DIN rail mounting hook diagram and product specifications.
October 2022	A01	Added CAN communication function.Made minor corrections.
August 2022	A00	First release

Document acquisition

This guide is not delivered along with the product. You can download the PDF version in the following means:

- Log in to Inovance's website (<u>www.inovance.com</u>), choose Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

■ Warranty

Inovance provides an 18-month warranty to the equipment from the date of shipment (subject to the barcode on the product) for failure or damage that occurs during normal use. If otherwise agreed upon, the agreed terms and conditions shall prevail. When the warranty period expires, reasonable maintenance fee will be charged.

The warranty does not cover any damage caused by:

- Operations not following instructions in the user guide
- Fire, flood, and abnormal voltage
- Unintended use
- Improper use outside the designed scope of application
- Force majeure (such as natural disaster, earthquake, and lightning strike) and the secondary damage caused thereof

The maintenance fee is charged according to the latest Maintenance Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail. For details, see Product Warranty Card.

3.2 产品信息

3.2.1 Model and Nameplate

■ Model

Easy 320 - 0808 TN (4)

① Product series

Easy: Easy series programmable logic controller

③ Inputs/Outputs

08: 8 inputs 08: 8 outputs

2 Series No.

3: Without EtherCAT


2: Two Ethernet interfaces

0: Model serial number

4 Output type


TN: SINK transistor

■ Nameplate



Model	Description	Code	
Easy320-0808TN	Easy300 series programmable controller with 8 inputs and 8 outputs	01440325	

3.2.2 Components



No.	Terminal	Terminal	Assignment	Indicator	Description
	Туре	Code		color	
1	I/O indicator	IN/OUT	I/O status display	Yellow- green	 Solid ON: Indicates the input or output is active. OFF: Indicates the input or output is inactive.
Operation ② status indicator		PWR	Power supply	Yellow- green	 Solid ON: Indicates that the power supply is normal. OFF: Indicates that the power supply is abnormal.
	RUN	Operation	Yellow- green	 Solid ON: Indicates that the user program is running. OFF: Indicates that the user program has been stopped. 	
	On anation	ERR	Operation error	Red	 OFF: Indicates no critical errors occur. Flashing: Indicates a critical error has occurred.
	status	ETH1	EtherNET1 Link	Yellow- green	 Solid ON: Indicates that the link has been established. Flashing: Indicates communication is in progress. OFF: Indicates that the link is not established.
		ETH2	EtherNET2 Link	Yellow- green	 Solid ON: Indicates that the link has been established. Flashing: Indicates communication is in progress. OFF: Indicates that the link is not established.
3	DIP switch	RUN/STOP	Start/Stop control of the master	-	-
4	Type-C interface	æ	Communica- tion with PC	-	-

No.	Terminal	Terminal	Assignment	Indicator	Description
	Туре	Code		color	
\$/- 6	Extension card slot	EXP-A/EXP-B	Function extension	-	For details of extension card options, see "2.7 Appendix: Extension Card Options" on page 64.
		485+	RS485 communica- tion signal+	-	-
⑦	RS485	485-	RS485 communica- tion signal-	-	•
		GND	RS485 communica- tion GND	-	-
	Power	+24V	24 VDC power supply (+)	-	-
8	supply interface	OV	24 VDC power supply (-)	-	
		<u></u>	PE	-	-
9	I/O terminal	-	8 inputs and 8 outputs	-	See details in "3.4.1 Layout of Terminals" on page 84.
①/- ①	Ethernet port	EtherNET1/ EtherNET2	RJ45 interface	-	-

3.2.3 Specifications

3.2.3.1 General Specifications

Item	Specifications
Program data capacity	128 k-step user program 1 Mb user-defined variables, in which 128 kb variables are retentive at power failure About 150 k soft elements (Elements after No. 1000 are retentive at power failure.)
Speed reference	20 k-step user program executed in 2 ms

Item	Specifications
Bit operation	0.144 μs/reference
Word transmission	0.338 μs/reference
Float operation	0.779 μs/reference
Ethernet	Supports Ethernet/IP, ModbusTCP, Socket, program download/upload, and firmware upgrade.
EtherCAT communication	-
Serial communica- tion	Supports up to 3 channels (one channel in the main unit and two channels extended in the extension card).
CAN communica-	Supports 1 master (firmware version 5.65.2.0 and later, software version AutoShop4.6.5.0 and later).
tion	CANlink: Supports up to 63 slaves.CANopen Supports up to 30 slaves.
High-speed input	Single-phase: 8-channel 200 k
High-speed output	5-axis 200 k, PWM pulse width modulation supported
Extension module	Supports up to 16 local extension modules.
Extension card	Supports up to two extension cards.
Program language	LD, SFC, FB/FC function (LD) supported
Type-C	Supports user program download/upload and firmware upgrade through type-C or GE20–TF extension card.
IP rating	IP20
Dimensions (W x H x D)	53 mm x 100 mm x 80 mm
Weight	About 184 g

3.2.3.2 Power Supply Specifications

Item	Specifications
Rated voltage of terminal input power supply	24 VDC±10% (21.6 VDC to 26.4 VDC)
Rated current of terminal input power supply	1 A (maximum value at 24 V)
24 V input power supply protection	Providing protection against short circuit and reverse connection
Hot-plugging	Not supported


3.2.3.3 Input Specifications

ltem		Specifications		
Input type		Digital input		
Number of i	nput channels	8		
Input mode		SINK/SOURCE		
Input voltag	e class	24 VDC±10% (21.6 VDC to 26.4 VDC)		
	Input current at input ON	> 4 mA		
High-speed	Input current at input OFF	< 2.5 mA		
input	Hardware response time	2 us (RC time)		
(X0-X7)	Max. input frequency	200 kHz		
	Input impedance	3.4 k		
ON voltage		≥ 15 VDC		
OFF voltage		≤ 5 VDC		
Software filter time		• Low-speed: 2 ms to 1000 ms • High speed: 2 μs to 1000 μs		
Isolation mode		Isolated by digital isolator chip		
Common terminal mode		8-point/common terminal (The polarity +/- of input power supply is changeable.)		
Input action	display	The input indicator lights up (controlled by software) when the input is in drive state.		

3.2.3.4 Output Specifications

	Item	Specifications	
Output type		Transistor NPN	
Number of c	utput channels	8	
Output volta	ige class	24 VDC±10% (21.6 VDC to 26.4 VDC)	
	Output load (resistive load)	0.5 A/point; 2 A/8-point	
	Output load (inductive load)	7.2 W/point; 24 W/8-point	
High-speed	Output load (lamp load)	5 W/point, 18 W/8-point	
output (Y0 to Y7)	Hardware response time ON/OFF	< 1 us (OFF→ON); < 2 us (ON→OFF)	
	Load current requirements	Load current \geqslant 12 mA when used with outputs greater than 10 kHz	
	Max. output frequency	200 kHz for resistive load; 0.5 Hz for inductive load; 10 Hz for lamp load	
Leakage cur	rent at OFF	Less than 30 uA at 24 V	
Max. residua ON	l voltage during	Less than 0.5 VDC	
Isolation mo	ode	Digital isolator	
Common ter	rminal mode	8-point/common terminal ("-" of power supply)	
Short circuit protection		Providing protection against short circuit of each circuit (The short circuit protection state can be cancelled throug a power cycle.)	
External inductive load protection		Connect a flywheel diode $^{[1]}$ when connecting the external inductive load.	
Output action	on display	The output indicator lights up (controlled by software) when the output is in drive state.	

[1]: D: 1N4001 or similar diodes are shown in the following figure.



3.3 Mechanical Installation

3.3.1 Installation Environment

Take the operability, service ability, and adaptability to environment into account when installing the $\mbox{PLC}.$

Item	Specification
Working environment	Free from corrosive and flammable gas, as well as excessive conductive dust
Altitude	Up to 2000 m (80 kPa)
Pollution degree	PD2
Immunity	2 kW on power supply line (IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2
Vibration resistance	IEC 60068-2-6, 5 Hz to 8.4 Hz, 3.5 mm, 8.4 Hz to 150 Hz, 1 g, 10 cycles in each of X, Y and Z directions
Shock resistance	IEC 60068-2-27 150 m/s², 11 ms, 3 times in each of \pm X, \pm Y and \pm Z directions, 18 times in total
Overcurrent protection device	1.1 A fuse
Storage temperature and humidity range	• Storage temperature: -20 °C to +60 °C • Relative humidity: $<$ 90% RH (without condensation)

Item	Specification
Shipping temperature/ humidity	 Shipping temperature: -40 °C to +70 °C Relative humidity: < 95% RH (without condensation)
Operating temperature/ humidity	 Operating temperature: -20 °C to +55 °C (horizontally), -20 °C to +45 °C (non-horizontally) Relative humidity: < 95% RH (without condensation)
	Note: Install a fan or air conditioner in the direction of the cooling hole when the operating temperature is greater than the maximum temperature.

Item	Specification					
Installation position and limit	Installation position: The PLC can be installed in four directions as shown in "3.3.2 Installation Position" on page 78. Limit:					
	When installed horizontally:					
	Input derating: The PLC can operate with full load at ambient temperature of 45°C. Derate the number of ON input points to 75% (lower than or equal to six ON input points) at ambient temperature of 55°C. Derate the number of ON input points by 2.5% for every additional 1°C above 45°C.					
	Derating of ON input points (%)					
	Ambient temperature (°C) 45 55					
	Output derating: The PLC can operate with full load (total current of eight output points not exceeding 2 A) at ambient temperature of 45°C. Derate the total output current of ON output points to 50% (total current of eight output points not exceeding 1 A) at ambient temperature of 55°C. Derate the total output current of ON output points by 5% for every additional 1°C above 45°C.					
	Densiting of tools output current (%)					
	45 55 Ambient temperature (*C)					
	When installed non-horizontally: The maximum number of input					

current cannot exceed 1 A.


channels connected cannot exceed six and the maximum output

3.3.2 Installation Position

This product can be installed in four positions (namely four installation directions): horizontally, vertically, and top or bottom of the cabinet. It is recommended to install the PLC horizontally. Different installation positions require different operating temperatures and limits. For details, see "3.3.1 Installation Environment" on page 75.

Optimal installation position

It is recommended to install the PLC horizontally, with natural convection as the cooling mode. To ensure normal heat dissipation and sufficient wiring space, reserve minimum clearance surrounding the PLC, as shown below.




Note

Keep the PLC away from high-temperature heating sources (heater, transformer, large resistor, etc.) by at least 100 mm.

Other installation positions

The surrounding clearance required on other installation positions are the same as the optimal one. Other installation positions are shown in the diagram below.





In case of vertical installation:

- Install the PLC below all I/O modules.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate. Failure to comply may cause displacement of the PLC from the DIN rail, leading to maloperation of the PLC.

3.3.3 Installation Precaution

 Before installing or removing the master and module, ensure that the master and module are powered off.




Do not connect/disconnect the module with power ON. This may lead to master restart or user data loss or damage.

 Prevent the master, module enclosure, or terminals from dropping or suffering from impact or shock.


3.3.4 Installation Dimensions

The installation dimensions (in mm) are shown in the figure below.



3.3.5 Installation Methods

The module is mounted onto a DIN rail that complies with IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (unit: mm) are shown below.






When installed on a DIN rail other than the recommended one (especially the one whose thickness is not 1.0 mm), the module will not fit in place as the mounting hook does not work.

■ Installing the master

1. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a clicking sound, as shown below.



Make sure the DIN rail mounting hook of the module is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.


When the mounting look is unlocked, press it down to lock the module to the DIN rail.




Keep the mounting hook locked when the controller is not mounted on the rail. If the mounting hook is kept unlocked for an extended period of time, it may malfunction.

Installing the module to the master

Install the extension module to the master through top and bottom rails, as shown below.




Install an DIN rail end plate to both sides of the master or module. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



Removing the module

Pry the mounting hook upwards with a tool such as a straight screwdriver or similar, and pull out the module forwardly. Then press down the top of the mounting hook.



3.4 电气安装

3.4.1 Layout of Terminals




Signals on the left	Terminals on the left	Terminals on the right	Terminals on the right
X0 input	1A	1B	Y0 output
X1 input	2A	2B	Y1 output
X2 input	3A	3B	Y2 output
X3 input	4A	4B	Y3 output
X4 input	5A	5B	Y4 output
X5 input	6A	6B	Y5 output
X6 input	7A	7B	Y6 output
X7 input	8A	8B	Y7 output
Common terminal of input	9A	9B	Common terminal of output




- Check the silk print on both sides of the terminal to prevent wrong cable connection. Failure to comply may lead to short circuit, which can damage the components.
- The total extended length of high-speed I/O interface extension cable must be within 3 m.
- To prevent interference, route the I/O interface extension cable and the power cable (high-voltage/high-current cables) through different and nonparallel routes.

3.4.2 Wiring of Input Terminals


SINK input wiring



■ SOURCE input wiring



3.4.3 Wiring of Output Terminals



Note


Connect a flywheel diode when connecting the external inductive load. Diodes can be 1N4001 or similar.

3.5 通信连接

3.5.1 Networking

This PLC can be connected to other sites, ERP, MES and other systems through Ethernet interface, or communicate with PC and HMI through GE20-232/485 extension

card. With GE20-CAN-485 extension card and CAN bus communication, an all-in-one network can be achieved in MD800, as shown below.




3.5.2 Cable Selection

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		KST		Suzhou Yuanli	
name	area					
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
	0.3	22	E0308		0308	
Tubular lug	0.5	20	E0508	KST2000L	0508	YAC-5
	0.75	18	E7508		7508	
	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

If you use other types of tubular lug, crimp the lug to the twisted pair as shown below.



3.5.3 Cable Connection

■ RS485 communication

The RS485 communication port and power supply port share the same terminal block, with RS485 communication port on the left and 24 V power supply port on the right.



Assignment

Description	Terminals on the left	Terminals on the right	Description
RS485 differential pair (+)	485+	+24V	24 VDC power supply (+)
RS485 differential pair (-)	485-	OV	24 VDC power supply (-)
Communication grounding terminal of RS485	GND	Ţ	PE

Communication specifications

Item	Description
Number of channels supported	Three channels at most (one built-in and two extended in the extension card, including RS232)
Hardware interface	2 x 3-pin terminal (shared with the power supply)
Isolation mode	Non-isolated
Termination resistor	Without termination resistor, can be master or slave
Number of slaves connected	Up to 31 slaves (The length of each slave branch must be shorter than 3 m.)
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s
Short circuit protection	Providing protection against improper connection of 24 V power supply

Wiring

See "3.5.2 Cable Selection" on page 87 when selecting the communication cable, Insert the communication cable into the communication port.

■ Ethernet communication

To improve communication reliability, use Cat 5e cables with injection molded and iron shell as Ethernet cables.


Connection: Insert the registered jack on the cable into the Ethernet port (RJ45 interface) until hearing a clicking sound.

• Disconection: Pull out the connector by pressing the tail of the registered jack.

3.5.4 RS485 Communication Instructions

It is recommended to use a shielded twisted pair cable as the RS485 bus. Connect a $120\,\Omega$ termination resistor to both ends of the bus respectively to prevent signal reflection. Connect the signal reference grounds of all nodes together. Up to 31 nodes can be connected and the distance between nodes must be less than 3 m.

The RS485 bus topology is shown in the figure below.



3.6 Operation and Maintenance

3.6.1 Start and Stop

After programming the PLC, follow the steps below to start and stop it.

The PLC is programmed when it is in STOP state. To start PLC:

1. Set the system to RUN state.

Check that the RUN indicator is solid ON in yellow green.

To stop the PLC, set the system to STOP state. Alternatively, you can stop it in the software tool of the host controller.

3.6.2 Programming of SD Card User Programs

- Save the SD card programming file compiled by Autoshop to the directory "PLCProgram" of the SD card (maximum capacity 32 GB, file formate FAT32).
- 2. Load the SD card onto the TF extension card and install the card to the PLC.



Install the TF extension card with power off.

- Power on the PLC again and start programming the user programs in the SD card to the PLC. The RUN indicator flashes at a frequency of 4 Hz during programming.
- 4. After programming is done, the RUN indicator flashes at a frequency of 1 Hz and this PLC enters the STOP state. You can remove the SD card now. If the ERR indicator flashes slowly, programming fails. Check that the model of the programming file is consistent with the actual model and the login password of the
 - programming file is consistent with the actual model and the login password of the programming file is the same as that of the PLC. If the model and password are both correct but the programming failure still occurs, contact Inovance for technical support.
- 5. Power off and on again.

3.6.3 SD Card Firmware Upgrade

 Load the SD card (maximum capacity 32 GB, file format FAT32) to the TF extension card and the PLC.



Install the TF extension card with power off.

2. Power on the PLC again.

The RUN and ERR indicators flash quickly for 3s, indicating that the firmware upgrade begins. The RUN and ERR indicators remain solid ON, indicating that the firmware is being upgraded. The RUN and ERR indicators flash slowly, indicating that the firmware upgrade is done.

- 3. After firmware upgrade is done, power off the PLC and remove the SD card.
- 4. Power on the PLC again.

3.7 Appendix: Extension Card Options

Model	Type	Description	Slot	ID
GE20-4DI	Digital input/ output	4 inputs 24 VDC input Source/Sink	A/B	13
GE20-4DO-TN		4 transistor sink outputs 24 VDC output	A/B	5
GE20- 2AD1DA-I	Analog input/ output	2 analog inputs and 1 analog output (current type)	A/B	11
GE20- 2AD1DA-V		2 analog inputs and 1 analog output (voltage type)	A/B	3
GE20-CAN-485	Communication extension	CAN and 485 communication (RJ45 interface)	A	15
GE20-232/485		RS232 or RS485 communication	A/B	7
GE20-232/ 485-RTC		RS232 or RS485 communication (with RTC)	В	14
GE20-TF	Storage extension	TF extension card	В	1
GE20-RTC	Clock extension	Clock extension card	В	9

Note

The ID is "0" when there is no extension card.

4 Easy501/Easy502 Programmable Logic

Controller User Guide

4.1 Preface

■ Introduction

The Easy501/Easy502 series PLC, the new generation of small PLC developed by Inovance, supports EtherCAT bus control and RS485 function and allows multi-layer network communication through RS485 and EtherCAT interfaces. With the FB/FC function, it can achieve process packaging and reuse, with up to 16 modules extendable. RS485/RS232/CAN/DI/DO/AI/AO/RTC clock/TF card functions can also be extended through the extension card.

This guide describes installation and wiring of the PLC, including product information, mechanical installation, and electrical installation.

Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the certifications compliant with, see the certification marks on the product nameplate.

Certification	Dire	ective	Standards compliance
CE certification	EMC Directive	2014/30/EU	24 VDC products:
			EN 61131-2
			220 VAC products:
			EN 61131-2
			EN 61000-3-2
			EN 61000-3-3
	Low Voltage	2014/35/EU	EN 61010-1
	Directive (LVD)		EN 61010-2-201
	RoHS Directive	2011/65/EU	EN IEC 63000
		amended by (EU)2015/863	
UL/cUL certification	-		UL 61010-1
			UL 61010-2-201
			UL 61010-2-030
			CAN/CSA-C22.2 No. 61010-1
			CSA C22.2 NO. 61010-2-201
			CSA C22.2 NO. 61010-2-030
KCC certification	-		-
EAC certification	_		-

■ More Documents

Document Name	Data Code	Description
GE20 Series Extension Card User Guide		Provides product information, installation and wiring, programming examples and for GE20 series extension card.

■ Revision history

Date	Version	Revision
March 2023	A01	Updated DIN rail mounting hook diagram and product specifications.
October 2022	A00	First release

Document acquisition

This guide is not delivered along with the product. You can download the PDF version in the following means:

- Log in to Inovance's website (<u>www.inovance.com</u>), choose Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

■ Warranty

Inovance provides an 18-month warranty to the equipment from the date of shipment (subject to the barcode on the product) for failure or damage that occurs during normal use. If otherwise agreed upon, the agreed terms and conditions shall prevail. When the warranty period expires, reasonable maintenance fee will be charged.

The warranty does not cover any damage caused by:

- Operations not following instructions in the user guide
- Fire, flood, and abnormal voltage
- Unintended use
- Improper use outside the designed scope of application
- Force majeure (such as natural disaster, earthquake, and lightning strike) and the secondary damage caused thereof

The maintenance fee is charged according to the latest Maintenance Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail. For details, see Product Warranty Card.

4.2 产品信息


4.2.1 Model and Nameplate

■ Model

1	Product series	3	Inputs/Outputs
	Easy: Easy series programmable logic		08: 8 inputs
	controller		08: 8 outputs
2	Series No.	4	Output type
	X stands for 1 and 2, i.e. 501, 502		TN: SINK transistor
	5: With EtherCAT		
	0: Without Ethernet		


■ Nameplate

1/2: 8-axis/16-axis



Model	Description	Code
Easy501-0808TN	Easy500 series programmable controller with 8 inputs and 8 outputs	01440384
Easy502-0808TN	Easy500 series 16-axis programmable controller with 8 inputs and 8 outputs	01440336

4.2.2 Components



No.	Terminal type	Terminal code	Assignment	Indicator color	Description
1	I/O indicator	IN/OUT	I/O status display	Yellow- green	 Solid ON: Indicates the input or output is active. OFF: Indicates the input or output is inactive.
		PWR	Power supply	Yellow- green	 Solid ON: Indicates that the power supply is normal. OFF: Indicates that the power supply is abnormal.
2	Operation status indicator	RUN	Operation	Yellow- green	Solid ON: Indicates that the user program is running. OFF: Indicates that the user program has been stopped.
		ERR	Operation error	Red	OFF: Indicates no critical errors occur. Flashing: Indicates a critical error has occurred.
3	DIP switch	RUN/STOP	Used to control the operation of the master.	-	-
4	Type-C interface	æ	Used for communication with PC.	-	-
⑤/- ⑥	Extension card slot	EXP-A/ EXP-B	Used for function extension.	-	For details of extension card options, see "3.7 Appendix: Extension Card Options" on page 92.

No.	Terminal type	Terminal code	Assignment	Indicator color	Description
		485+	RS485 communication signal+	-	-
7	RS485	485-	RS485 communication signal-	-	-
		GND	RS485 communication GND	-	-
	Power	+24V	24 VDC power supply (+)	-	-
8	supply interface	OV	24 VDC power supply (-)	-	-
		\(\rightarrow\)	PE	-	-
9	I/O terminal	-	8 inputs and 8 outputs	-	See details in "4.4.1 Layout of Terminals" on page 112.
10	EtherCAT interface	EtherCAT	Used for EtherCAT communica- tion.	-	-

4.2.3 Specifications

4.2.3.1 General Specifications

Item	Easy501-0808TN specifications	Easy502-0808TN specifications	
Program data capacity	200 k-step user program 2 Mb user-defined variables, of which power failure; About 150 k soft elements (Elements failure.)		
Speed reference	20 k-step user program executed in 2 ms		
Bit operation	0.144 μs/reference		

Item	Easy501-0808TN specifications	Easy502-0808TN specifications	
Word transmission	0.338 μs/reference		
Float operation	0.779 μs/reference		
Ethernet	-		
EtherCAT communication	Supports 1 EtherCAT master with up	to 72 EtherCAT slaves.	
Number of axes available (pulse + bus)	8-axis	16-axis	
Serial communication	Supports up to 3 channels (one chan channels extended in the extension c		
CAN communica- tion	Supports 1 master through the extension card (firmware version 5.65.2.0 and later, software version AutoShop4.6.5.0 and later). • CANlink: Supports up to 63 slaves. • CANopen Supports up to 30 slaves.		
High-speed input	Single-phase: 8-channel 200 k		
High-speed output	5-axis 200 k, PWM pulse width modulation supported		
Extension module	Supports up to 16 local extension modules.		
Extension card	Supports up to two extension cards.		
Program language	LD, SFC, FB/FC function (LD) supported		
Type-C	Supports user program download/upload and firmware upgrade through GE20–TF extension card.		
IP rating	IP20		
Dimensions (W x H x D)	53 mm x 100 mm x 80 mm		
Weight	About 177 g		

4.2.3.2 Power Supply Specifications

Item	Specifications
Rated voltage of terminal input power supply	24 VDC±10% (21.6 VDC to 26.4 VDC)
Rated current of terminal input power supply	1 A (maximum value at 24 V)
24 V input power supply protection	Providing protection against short circuit and reverse connection
Hot-plugging	Not supported


4.2.3.3 Input Specifications

ltem		Specifications
Input type		Digital input
Number of input channels		8
Input mode		SINK/SOURCE
Input voltage class		24 VDC±10% (21.6 VDC to 26.4 VDC)
High-speed	Input current at input ON	> 4 mA
	Input current at input OFF	< 2.5 mA
input	Hardware response time	2 μs (RC time)
(X0-X7)	Max. input frequency	200 kHz
	Input impedance	3.4 k
ON voltage		≥ 15 VDC
OFF voltage		≤ 5 VDC
Software filter time		Low-speed: 2 ms to 1000 msHigh speed: 2 μs to 1000 μs
Isolation mode		Isolated by digital isolator chip
Common terminal mode		8-point/common terminal (The polarity +/- of input power supply is changeable.)
Input action display		The input indicator lights up (controlled by software) when the input is in drive state.

4.2.3.4 Output Specifications

Item		Specifications
Output type		Transistor NPN
Number of output channels		8
Output voltage class		24 VDC±10% (21.6 VDC to 26.4 VDC)
High-speed output (Y0 to Y7)	Output load (resistive load)	0.5 A/point; 2 A/8-point
	Output load (inductive load)	7.2 W/point; 24 W/8-point
	Output load (lamp load)	5 W/point, 18 W/8-point
	Hardware response time ON/OFF	< 1 us (OFF→ON); < 2 us (ON→OFF)
	Load current requirements	Load current ≥ 12 mA when used with outputs greater than 10 kHz
	Max. output frequency	200 kHz for resistive load; 0.5 Hz for inductive load; 10 Hz for lamp load
PWM output		Maximum frequency 200 kHz, minimum pulse width 2.5 us, minimum resolution 2.5 us, adjustable duty cycle 0.01% to 99.99%
Leakage current at OFF		Less than 30 uA at 24 V
Max. residual voltage during ON		Less than 0.5 VDC
Isolation mode		Digital isolator
Common terminal mode		8-point/common terminal ("-" of power supply)
Short circuit protection		Providing protection against short circuit of each circuit (The short circuit protection state can be cancelled through a power cycle.)
External inductive load protection		Connect a flywheel diode ^[1] when connecting the external inductive load.
Output action display		The output indicator lights up (controlled by software) when the output is in drive state.

[1]:D: 1N4001 or similar diodes are shown in the following figure.



4.3 Mechanical Installation

4.3.1 Installation Environment

Take the operability, service ability, and adaptability to environment into account when installing the $\mbox{PLC}.$

Item	Specification
Working environment	Free from corrosive gas and flammable gas, as well as excessive conductive dust
Altitude	Up to 2000 m (80 kPa)
Pollution degree	PD2
Immunity	2 kV on the power supply line (IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2
Vibration resistance	IEC 60068-2-6, 5 Hz to 8.4 Hz, 3.5 mm, 8.4 Hz to 150 Hz, 1 g, 10 cycles in each of X, Y and Z directions
Shock resistance	IEC 60068-2-27 150 m/s², 11 ms, 3 times in each of \pm X, \pm Y and \pm Z directions, 18 times in total
Overcurrent protection device	1.1 A fuse
Storage temperature and humidity range	• Storage temperature: -20 °C to +60 °C • Relative humidity: $<$ 90% RH (without condensation)

Item	Specification
Shipping temperature/ humidity	 Shipping temperature: -40 °C to +70 °C Relative humidity: < 95% RH (without condensation)
Operating temperature/ humidity	 Operating temperature: -20 °C to +55 °C (horizontally), -20 °C to +45 °C (non-horizontally) Relative humidity: < 95% RH (without condensation)
	Note: Install a fan or air conditioner in the direction of the cooling hole when the operating temperature is greater than the maximum temperature.

Item	Specification
Installation position and limit	Installation position: The PLC can be installed in four directions as shown in "4.3.2 Installation Position" on page 106. Limit: • When installed horizontally:
	Input derating: The PLC can operate with full load at ambient temperature of 45°C. Derate the number of ON input points to 75% (lower than or equal to six ON input points) at ambient temperature of 55°C. Derate the number of ON input points by 2.5% for every additional 1°C above 45°C.
	Derading of ON input points (%)
	Amblent temperature (°C) 45 55
	Output derating: The PLC can operate with full load (total current of eight channels not exceeding 2 A) at ambient temperature of 45°C. Derate the total output current of ON output points to 50% (total current of eight channels not exceeding 1 A) at ambient temperature of 55°C. Derate the total output current of ON output points by 5% for every additional 1°C above 45°C.
	Densiting of total output current (%)
	45 55 Ambient temperature (°C)


 When installed non-horizontally: The maximum number of input channels connected cannot exceed six and the maximum output current cannot exceed 1 A.

4.3.2 Installation Position

This product can be installed in four positions (namely four installation directions): Horizontally, vertically, and top or bottom of the cabinet. It is recommended to install the PLC horizontally. Different installation positions require different operating temperatures and limits. For details, see "4.3.1 Installation Environment" on page 103.

Optimal installation position

It is recommended to install the PLC horizontally, with natural convection as the cooling mode. To ensure normal heat dissipation and sufficient wiring space, reserve minimum clearance around the PLC, as shown below.




Note

Keep the PLC away from high-temperature heating sources (heater, transformer, large resistor, etc.) by at least 100 mm.

Other installation positions

The surrounding clearance required on other installation positions are the same as the optimal one. Other installation positions are shown in the diagram below.





In case of vertical installation:

- Install the PLC below all I/O modules.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate. Failure to comply may cause displacement of the PLC from the DIN rail, leading to maloperation of the PLC.

4.3.3 Installation Precaution

 Before installing or removing the master and module, ensure that the master and module are powered off.




Do not connect/disconnect the module with power ON. This may lead to master restart or user data loss or damage.

 Prevent the master, module enclosure, or terminals from dropping or suffering from impact or shock.

4.3.4 Installation Dimensions

The installation dimensions (in mm) are shown in the figure below.



4.3.5 Installation Methods

The module is mounted onto a DIN rail that complies with IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (unit: mm) are shown below.






When installed on a DIN rail other than the recommended one (especially the one whose thickness is not 1.0 mm), the module will not fit in place as the mounting hook does not work.

■ Installing the master

1. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a clicking sound, as shown below.



Make sure the DIN rail mounting hook of the module is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.


When the mounting look is unlocked, press it down to lock the module to the DIN rail.




Keep the mounting hook locked when the controller is not mounted on the rail. If the mounting hook is kept unlocked for an extended period of time, it may malfunction.

Installing the module to the master

Install the extension module to the master through top and bottom rails, as shown below.




Install an DIN rail end plate to both sides of the master or module. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



Removing the module

Pry the mounting hook upwards with a tool such as a straight screwdriver or similar, and pull out the module forwardly. Then press down the top of the mounting hook.



4.4 电气安装

4.4.1 Layout of Terminals




Signals on the left	Terminals on the left	Terminals on the right	Signals on the right
X0 input	1A	1B	Y0 output
X1 input	2A	2B	Y1 output
X2 input	ЗА	3B	Y2 output
X3 input	4A	4B	Y3 output
X4 input	5A	5B	Y4 output
X5 input	6A	6B	Y5 output
X6 input	7A	7B	Y6 output
X7 input	8A	8B	Y7 output
Common terminal of input	9A	9B	Common terminal of output




- Check the silk print on both sides of the terminal to prevent wrong cable connection. Failure to comply may lead to short circuit, which can damage the components.
- The total extended length of high-speed I/O interface extension cable must be within 3 m.
- To prevent interference, route the I/O interface extension cable and the power cable (high-voltage/high-current cables) through different and nonparallel routes.

4.4.2 Wiring of Input Terminals


SINK input wiring



SOURCE input wiring



4.4.3 Wiring of Output Terminals



Note


Connect a flywheel diode when connecting the external inductive load. Diodes can be 1N4001 or similar.

4.5 通信连接

4.5.1 Networking

This PLC can be connected to other slaves (such as MD520/MD800 AC drives and SV630N/SV660N servo drives) through the EtherCAT interface or connected to other

modules with EtherCAT. With GE20-CAN-485 extension card and CAN bus communication, an all-in-one network can be achieved in MD800. Meanwhile, the point-to-point communication can be realized between the PLC and PC/HMI through GE20-232/485 extension card, as shown below.




4.5.2 Cable Selection

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable o	ross sectional	ŀ	(ST	Suzhou	ı Yuanli
name	a	rea				
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
	0.3	22	E0308		0308	
	0.5	20	E0508		0508	
Tubular lug	0.75	18	E7508	KST2000L	7508	YAC-5
0	1.0	18	E1008		1008	
	1.5	16	E1508		1508	


If you use other types of tubular lug, crimp the lug to the twisted pair as shown below.



4.5.3 Cable Connection

■ RS485 communication

The RS485 communication port and power supply port share the same terminal block, with RS485 communication port on the left and 24 V power supply port on the right.



Assignment

Description	Terminals on the left	Terminals on the right	Description
RS485 differential pair (+)	485+	+24V	24 VDC power supply (+)
RS485 differential pair (-)	485-	OV	24 VDC power supply (-)
Communication grounding terminal of RS485	GND	Ţ	PE

Communication specifications

Item	Description
Number of channels supported	Three channels at most (one built-in and two extended in the extension card, including RS232)
Hardware interface	2 x 3-pin terminal (shared with the power supply)
Isolation mode	Non-isolated
Termination resistor	Without termination resistor, can be master or slave
Number of slaves connected	Up to 31 slaves (The length of each slave branch must be shorter than 3 m.)
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s
Short circuit protection	Providing protection against improper connection of 24 V power supply

Wiring

See "4.5.2 Cable Selection" on page 115 when selecting the communication cable. Insert the communication cable into the communication port.

■ EtherCAT Communication

- Connection: Insert the registered jack on the cable into the Ethernet port (RJ45 interface) until hearing a clicking sound.
- Disconnection: Pull out the connector by pressing the tail of the registered jack.

4.5.4 EtherCAT Communication


■ EtherCAT Specifications

Item	Description
Communication protocol	EtherCAT
Available services	CoE (PDO, SDO)
Synchronization mode	Distributed clock for the drive and synchronous input/output for I/O
Physical layer	100BASE-TX
Baud rate	100 Mbit/s (100Base-TX)
Duplex mode	Full duplex
Topology	Linear topology
Transmission medium	Network cable
Transmission distance	Less than 100 m between two nodes
Number of slaves	Up to 72 (8-axis supported by Easy501; 16-axis supported by Easy502)
EtherCAT Frame length	44 to 1498 bytes
Process data	1486 bytes at most for an individual Ethernet frame

■ Wiring

The PLC enables EtherCAT bus communication through CN3, which requires the following communication cable:

Communication cable requirements



Signal pin assignment

Pin	Signal	Signal direction	Description
1	TD+	Output	Data transmission+
2	TD-	Output	Data transmission-
3	RD+	Input	Receive data (+)
4	-	-	Not used
5%	-	-	Not used
6	RD-	Input	Receive data (-)
7	-	-	Not used
08	-	-	Not used

Length requirement

The cable between devices cannot exceed 100 m when the EtherCAT bus is used, exceeding of which may attenuate the signal and affect normal communication.

Technical requirements


Short circuit, open circuit, misalignment, or poor contact does not occur during 100% continuity test. Cables compliant with the following specifications are recommended.

Item	Specification
Cable type	Flexible crossover cable, S-FTP, Cat5e
Standards compliance	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB EIA/TIA SB40-A&TSB36
Cross sectional area of the cable	26AWG
Cable category	Twisted pair
Number of pairs	4

4.5.5 RS485 Communication Instructions

It is recommended to use a shielded twisted pair cable as the RS485 bus. Connect a $120\,\Omega$ termination resistor to both ends of the bus respectively to prevent signal reflection. Connect the signal reference grounds of all nodes together. Up to 31 nodes can be connected and the distance between nodes must be less than 3 m.

The RS485 bus topology is shown in the figure below.



4.6 Operation and Maintenance

4.6.1 Start and Stop

After programming the PLC, follow the steps below to start and stop it.

The PLC is programmed when it is in STOP state. To start PLC:

- Set the system to RUN state.
 Check that the RUN indicator is solid ON in yellow green.
- To stop the PLC, set the system to STOP state. Alternatively, you can stop it in the software tool of the host controller.

4.6.2 Programming of SD Card User Programs

- Save the SD card programming file compiled by Autoshop to the directory "PLCProgram" of the SD card (maximum capacity 32 GB, file formate FAT32).
- 2. Load the SD card onto the TF extension card and install the card to the PLC.



Install the TF extension card with power off.

- 3. Power on the PLC again and start programming the user programs in the SD card to the PLC. The RUN indicator flashes at a frequency of 4 Hz during programming.
- 4. After programming is done, the RUN indicator flashes at a frequency of 1 Hz and this PLC enters the STOP state. You can remove the SD card now.

If the ERR indicator flashes slowly, programming fails. Check that the model of the programming file is consistent with the actual model and the login password of the programming file is the same as that of the PLC. If the model and password are both correct but the programming failure still occurs, contact Inovance for technical support.

5. Power off and on again.

4.6.3 SD Card Firmware Upgrade

 Load the SD card (maximum capacity 32 GB, file format FAT32) to the TF extension card and the PLC.



Install the TF extension card with power off.

2. Power on the PLC again.

The RUN and ERR indicators flash quickly for 3s, indicating that the firmware upgrade begins. The RUN and ERR indicators remain solid ON, indicating that the firmware is being upgraded. The RUN and ERR indicators flash slowly, indicating that the firmware upgrade is done.

- 3. After firmware upgrade is done, power off the PLC and remove the SD card.
- 4. Power on the PLC again.

4.7 Appendix: Extension Card Options

Model	Туре	Description	Slot	ID
GE20-4DI	Digital input/ output	4 inputs 24 VDC input Source/Sink	A/B	13
GE20-4DO-TN		4 transistor sink outputs 24 VDC output	A/B	5
GE20- 2AD1DA-I	Analog input/ output	2 analog inputs and 1 analog output (current type)	A/B	11
GE20- 2AD1DA-V		2 analog inputs and 1 analog output (voltage type)	A/B	3
GE20-CAN-485	Communication extension	CAN and 485 communication (RJ45 interface)	A	15
GE20-232/485		RS232 or RS485 communication	A/B	7
GE20-232/ 485-RTC		RS232 or RS485 communication (with RTC)	В	14
GE20-TF	Storage extension	TF extension card	В	1
GE20-RTC	Clock extension	Clock extension card	В	9

Note

The ID is "0" when there is no extension card.

5 Easy521/Easy522/Easy523 Programmable

Logic Controller User Guide

5.1 Preface

■ Introduction

The Easy521/Easy522/Easy523 series PLC, the new generation of small PLC developed by Inovance, supports network switchover through two network ports and allows process packaging and reuse through FB/FC function. With RS485, Ethernet, and EtherCAT, a multi-layer network communication can be realized through this PLC, with 16 modules extendable. RS485/RS232/CAN/DI/DO/AI/AO/RTC clock/TF card functions can also be available through the extension card.

This guide describes installation and wiring of the PLC, including product information, mechanical installation, and electrical installation.

Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the certifications compliant with, see the certification marks on the product nameplate.

Certification	Dii	rective	Standards compliance
CE certification	EMC Directive	2014/30/EU	24 VDC products:
			EN 61131-2
			220 VAC products:
			EN 61131-2
			EN 61000-3-2
			EN 61000-3-3
	Low Voltage	2014/35/EU	EN 61010-1
	Directive (LVD)		EN 61010-2-201
	RoHS Directive	2011/65/EU	EN IEC 63000
		amended by (EU) 2015/863	
UL/cUL certification	-		UL 61010-1
			UL 61010-2-201
			UL 61010-2-030
			CAN/CSA-C22.2 No. 61010-1
			CSA C22.2 NO. 61010-2-201
			CSA C22.2 NO. 61010-2-030
KCC certification	-		-
EAC certification	-		-

■ More Documents

Document Name	Data Code	Description
GE20 Series Extension Card User Guide	PS00006443	Provides product information, installation and wiring, programming examples and for GE20 series extension card.

Revision history

Date	Version	Revision
March 2023	A02	Updated DIN rail mounting hook diagram and product specifications.
October 2022	A01	Added CAN communication function.Made minor corrections.
August 2022	A00	First release

Document acquisition

This guide is not delivered along with the product. You can download the PDF version in the following means:

- Log in to Inovance's website (<u>www.inovance.com</u>), choose Support > Download, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

■ Warranty

Inovance provides an 18-month warranty to the equipment from the date of shipment (subject to the barcode on the product) for failure or damage that occurs during normal use. If otherwise agreed upon, the agreed terms and conditions shall prevail. When the warranty period expires, reasonable maintenance fee will be charged.

The warranty does not cover any damage caused by:

- Operations not following instructions in the user guide
- Fire, flood, and abnormal voltage
- Unintended use
- Improper use outside the designed scope of application
- Force majeure (such as natural disaster, earthquake, and lightning strike) and the secondary damage caused thereof

The maintenance fee is charged according to the latest Maintenance Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail. For details, see Product Warranty Card.

5.2 产品信息

5.2.1 Model and Nameplate

■ Model

Easy $\frac{52X}{9} - \frac{0808}{9} = \frac{TN}{4}$

Product series

Easy: Easy series programmable logic controller

② Series No.

X stands for 1, 2, 3, i.e. 521, 522, 523

5: With EtherCAT

2: Two Ethernet interfaces 1/2/3: 8-axis/16-axis/32-axis

③ Inputs/Outputs


08: 8 inputs

08: 8 outputs

4 Output type


TN: SINK transistor

■ Nameplate



Model	Description	Code
Easy521-0808TN	Easy500 series 8-axis programmable controller with 8 inputs and 8 outputs	01440385
Easy522-0808TN	Easy500 series 16-axis programmable controller with 8 inputs and 8 outputs	01440383
Easy523-0808TN	Easy500 series 32-axis programmable controller with 8 inputs and 8 outputs	01440326

5.2.2 Components



No.	Terminal type	Terminal code	Assignment	Indicator color	Description
1)	I/O indicator	IN/OUT	I/O status display	Yellow- green	 Solid ON: Indicates the input or output is active. OFF: Indicates the input or output is inactive.

No.	Terminal	Terminal code	Assignment	Indicator	Description
	type			color	
	RUN Ope	PWR	Power supply	Yellow- green	 Solid ON: Indicates that the power supply is normal. OFF: Indicates that the power supply is abnormal.
		RUN	Operation	Yellow- green	Solid ON: Indicates that the user program is running. OFF: Indicates that the user program has been stopped.
		ERR	Operation error	Red	OFF: Indicates no critical errors occur. Flashing: Indicates a critical error has occurred.
2		EtherNET1 Link	Yellow- green	Solid ON: Indicates that the link has been established. Flashing: Indicates communication is in progress. OFF: Indicates that the link is not established.	
		ETH2	EtherNET2 Link	Yellow- green	 Solid ON: Indicates that the link has been established. Flashing: Indicates communication is in progress. OFF: Indicates that the link is not established.

No.	Terminal	Terminal code	Assignment	Indicator	Description
	type			color	
3	DIP switch	RUN/STOP	Used to control the operation of the master.	-	-
4	Type-C interface	÷	Used for communication with PC.	-	-
5/- 6	Extension card slot	01/02	Used for function extension.	-	For details of extension card options, see "4.7 Appendix: Extension Card Options" on page 122.
		485+	RS485 communication signal+	-	-
7	RS485	485-	RS485 communication signal-	-	-
		GND	RS485 communication GND	-	-
	Power	+24V	24 VDC power supply (+)	-	-
8	supply interface	OV	24 VDC power supply (-)	-	-
		4	PE	-	-
9	EtherCAT interface	EtherCAT	Used for EtherCAT communica- tion.	-	-
10	I/O terminal	_	8 inputs and 8 outputs	-	See details in "5.4.1 Layout of Terminals" on page 144.
①/- ②	Ethernet port	EtherNET1/ EtherNET2	Ethernet RJ45 interface	-	-

5.2.3 Specifications

5.2.3.1 General Specifications

Item	Easy521-0808TN	Easy522-0808TN	Easy523-0808TN
Program data capacity	200 k-step user program 2 Mb user-defined variables, in which 128 kb variables are retentive at power failure; About 150 k soft elements (Elements after No. 1000 are retentive at power failure.)		
Reference speed	20 k-step user prograr	m executed in 1.6 ms	
Bit operation	0.113 μs/instruction		
Word transmission	0.232 μs/instruction		
Float operation	0.578 μs/instruction		
Ethernet	Supports Ethernet/IP, ModbusTCP, Socket, program download/ upload, and firmware upgrade.		
EtherCAT communication	Supports 1 EtherCAT master with up to 72 EtherCAT slaves.		
Number of axes available (pulse + bus)	8-axis	16-axis	32-axis
Serial communication	Supports up to 3 channels (one channel in the main unit and two channels extended in the extension card).		
CAN communication	Supports 1 master through the extension card (firmware version 5.66.0.0 and later, software version AutoShop4.8.0.0 and later). • CANlink: Supports up to 63 slaves. • CANopen Supports up to 30 slaves.		
High-speed input	Single-phase: 8-channel 200 k		
High-speed output	5-axis 200 k, PWM pulse width modulation supported		
Extension module	Supports up to 16 local extension modules.		
Extension card	Supports up to two extension cards.		
Program language	LD, SFC, FB/FC function (LD) supported		
Type-C	Supports user program download/upload and firmware upgrade through GE20–TF extension card.		

Item	Easy521-0808TN	Easy522-0808TN	Easy523-0808TN
IP rating	IP20		
Dimensions (W x H x D)	53 mm x 100 mm x 80	mm	
Weight	About 197 g		

5.2.3.2 Power Supply Specifications

Item	Specifications
Rated voltage of terminal input power supply	24 VDC±10% (21.6 VDC to 26.4 VDC)
Rated current of terminal input power supply	1 A (max. value at 24 VDC)
24 V input power supply protection	Providing protection against short circuit and reverse connection
Hot-plugging	Not supported

5.2.3.3 Input Specifications

Item		Specifications	
Input type		Digital input	
Number of i	nput channels	8	
Input mode		SINK/SOURCE	
Input voltag	e class	24 VDC±10% (21.6 VDC to 26.4 VDC)	
	Input current at input ON	> 4 mA	
High-speed	Input current at input OFF	< 2.5 mA	
input	Hardware response time	2 us (RC time)	
(X0-X7)	Max. input frequency	200 kHz	
	Input impedance	3.4 k	
ON voltage		≥ 15 VDC	
OFF voltage		≤ 5 VDC	


Item	Specifications
Software filter time	Low-speed: 2 ms to 1000 msHigh speed: 2 μs to 1000 μs
Isolation mode	Isolated by digital isolator chip
Common terminal mode	8-point/common terminal (The polarity +/- of input power supply is changeable.)
Input action display	The input indicator lights up (controlled by software) when the input is in drive state.

5.2.3.4 Output Specifications

Item		Specifications
Output type		Transistor NPN
Number of o	output channels	8
Output volta	ige class	24 VDC±10% (21.6 VDC to 26.4 VDC)
	Output load (resistive load)	0.5 A/point; 2 A/8-point
	Output load (inductive load)	7.2 W/point; 24 W/8-point
High-speed	Output load (lamp load)	5 W/point, 18 W/8-point
output (Y0 to Y7)	Hardware response time ON/OFF	<1 us (OFF→ON); < 2 us (ON→OFF)
	Load current requirements	Load current \geqslant 12 mA when used with outputs greater than 10 kHz
	Max. output frequency	200 kHz for resistive load; 0.5 Hz for inductive load; 10 Hz for lamp load
Leakage current at OFF		Less than 30 uA at 24 V
Max. residual voltage during ON		Less than 0.5 VDC
Isolation mode		Digital isolator
Common terminal mode		8-point/common terminal ("-" of power supply)

Item	Specifications
Short circuit protection	Providing protection against short circuit of each circuit (The short circuit protection state can be cancelled through a power cycle.)
External inductive load protection	Connect a flywheel diode $^{[1]}$ when connecting the external inductive load.
Output action display	The output indicator lights up (controlled by software) when the output is in drive state.

[1]: D: 1N4001 or similar diodes are shown in the following figure.



5.3 Mechanical Installation

5.3.1 Installation Environment

Take the operability, service ability, and adaptability to environment into account when installing the $\mbox{PLC}.$

Item	Specification
Working environment	Free from corrosive gas and flammable gas, as well as excessive conductive dust
Altitude	Up to 2000 m (80 kPa)
Pollution degree	PD2
Immunity	2 kV on the power supply line (IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2

Item	Specification
Vibration resistance	IEC 60068-2-6, 5 Hz to 8.4 Hz, 3.5 mm, 8.4 Hz to 150 Hz, 1 g, 10 cycles in each of X, Y and Z directions
Shock resistance	IEC 60068-2-27 150 m/s², 11 ms, 3 times in each of \pm X, \pm Y and \pm Z directions, 18 times in total
Overcurrent protection device	1.1 A fuse
Storage temperature and humidity range	 Storage temperature: -20 °C to +60 °C Relative humidity: < 90% RH (without condensation)
Shipping temperature/ humidity	 Shipping temperature: -40 °C to +70 °C Relative humidity: < 95% RH (without condensation)

Item	Specification
Operating temperature/ humidity	 Operating temperature: -20 °C to +55 °C (horizontally), -20 °C to +45 °C (non-horizontally) Relative humidity: < 95% RH (without condensation)
	Note: Install a fan or air conditioner in the direction of the cooling hole when the operating temperature is greater than the maximum temperature.

Item	Specification
Installation position and limit	Installation position: The PLC can be installed in four directions as shown in "5.3.2 Installation Position" on page 138. Limit: • When installed horizontally:
	Input derating: The PLC can operate with full load at ambient temperature of 45°C. Derate the number of ON input points to 75% (lower than or equal to six ON input points) at ambient temperature of 55°C. Derate the number of ON input points by 2.5% for every additional 1°C above 45°C.
	Output derating: The PLC can operate with full load (total current of eight output points not exceeding 2 A) at ambient temperature of 45°C. Derate the total output current of ON output points to 50% (total current of eight output points not exceeding 1 A) at ambient temperature of 55°C. Derate the total output current of ON output points by 5% for every additional 1°C above 45°C.
	Amblent temperature (°C)


 When installed non-horizontally: The maximum number of input points connected cannot exceed six, the maximum output current cannot exceed 1 A, and the number of modules cannot exceed six.

5.3.2 Installation Position

This product can be installed in four positions (namely four installation directions): Horizontally, vertically, and top or bottom of the cabinet. It is recommended to install the PLC horizontally. Different installation positions require different operating temperatures and limits. For details, see "5.3.1 Installation Environment" on page 134.

Optimal installation position

It is recommended to install the PLC horizontally, with natural convection as the cooling mode. To ensure normal heat dissipation and sufficient wiring space, reserve minimum clearance around the PLC, as shown below.




Note

Keep the PLC away from high-temperature heating sources (heater, transformer, large resistor, etc.) by at least 100 mm.

■ Other installation positions

The surrounding clearance required on other installation positions are the same as the optimal one. Other installation positions are shown in the diagram below.





In case of vertical installation:

- Install the PLC below all I/O modules.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate. Failure to comply may cause displacement of the PLC from the DIN rail, leading to maloperation of the PLC.

5.3.3 Installation Precaution

 Before installing or removing the master and module, ensure that the master and module are powered off.




Do not connect/disconnect the module with power ON. This may lead to master restart or user data loss or damage.

 Prevent the master, module enclosure, or terminals from dropping or suffering from impact or shock.


5.3.4 Installation Dimensions

The installation dimensions (in mm) are shown in the figure below.



5.3.5 Installation Methods

The module is mounted onto a DIN rail that complies with IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (unit: mm) are shown below.






When installed on a DIN rail other than the recommended one (especially the one whose thickness is not 1.0 mm), the module will not fit in place as the mounting hook does not work.

Installing the master

1. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a clicking sound, as shown below.



Make sure the DIN rail mounting hook of the module is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.


When the mounting look is unlocked, press it down to lock the module to the DIN rail.




Keep the mounting hook locked when the controller is not mounted on the rail. If the mounting hook is kept unlocked for an extended period of time, it may malfunction.

Installing the module to the master

Install the extension module to the master through top and bottom rails, as shown below.




Install an DIN rail end plate to both sides of the master or module. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



■ Removing the module

Pry the mounting hook upwards with a tool such as a straight screwdriver or similar, and pull out the module forwardly. Then press down the top of the mounting hook.



5.4 电气安装

5.4.1 Layout of Terminals




Signals on the left	Terminals on the left	Terminals on the right	Signals on the right
X0 input	1A	1B	Y0 output
X1 input	2A	2B	Y1 output
X2 input	3A	3B	Y2 output
X3 input	4A	4B	Y3 output
X4 input	5A	5B	Y4 output
X5 input	6A	6B	Y5 output
X6 input	7A	7B	Y6 output
X7 input	8A	8B	Y7 output
Common terminal of input	9A	9B	Common terminal of output




- The length of a high-speed I/O interface extension cable must be within 3.0 m.
- To prevent interference, route the I/O interface extension cable and the power cable (high-voltage/high-current cables) through different nonparallel routes.

5.4.2 Wiring of Input Terminals


SINK input wiring



■ SOURCE input wiring



5.4.3 Wiring of Output Terminals



Note


Connect a flywheel diode when connecting the external inductive load. Diodes can be 1N4001 or similar.

5.5 通信连接

5.5.1 Networking

This PLC can be connected to other sites, ERP, MES and other systems through Ethernet interface, or connected to other slaves (such as MD520, MD800, SV630N and

SV660N drives) or other modules with EtherCAT function through EtherCAT interface. With GE20 series extension cards, this PLC can also be connected to H5U, SV630C, and IR311 series industrial robots through RS485, RS232, or CAN communication, as shown below




5.5.2 Cable Selection

The cable lug and cross sectional area of the cable listed in the following table are for reference only.

Material	Applicable cross sectional		KST		Suzhou Yuanli	
name	area					
	GB/mm ²	AWG	Model	Crimping	Model	Crimping
				tool		tool
	0.3	22	E0308		0308	
	0.5	20	E0508		0508	
Tubular lug	0.75	18	E7508	KST2000L	7508	YAC-5
lug.	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

If you use other types of tubular lug, crimp the lug to the twisted pair as shown below.



5.5.3 Cable Connection

■ RS485 communication

The RS485 communication port and power supply port share the same terminal block, with RS485 communication port on the left and 24 V power supply port on the right.



Assignment

Description	Terminals on the left	Terminals on the right	Description
RS485 differential pair (+)	485+	+24V	24 VDC power supply (+)
RS485 differential pair (-)	485-	OV	24 VDC power supply (-)
Communication grounding terminal of RS485	GND	4	PE

Communication specifications

Item	Description
Number of channels supported	Three channels at most (one built-in and two extended in the extension card, including RS232)
Hardware interface	2 x 3-pin terminal (shared with the power supply)
Isolation mode	Non-isolated
Termination resistor	Without termination resistor, can be master or slave
Number of slaves connected	Up to 31 slaves (The length of each slave branch must be shorter than 3 m.)
Communication baud rate	9600 bit/s, 19200 bit/s, 38400 bit/s, 57600 bit/s, and 115200 bit/s
Short circuit protection	Providing protection against improper connection of 24 V power supply

Wiring

See "5.5.2 Cable Selection" on page 147 when selecting the communication cable, Insert the communication cable into the communication port.

■ Ethernet communication

To improve communication reliability, use Cat 5e cables with injection molded and iron shell as Ethernet cables.

- Connection: Insert the registered jack on the cable into the Ethernet port (RJ45 interface) until hearing a clicking sound.
- Disconection: Pull out the connector by pressing the tail of the registered jack.

5.5.4 EtherCAT Communication Description


■ EtherCAT Specifications

Item	Description
Communication protocol	EtherCAT Protocol
Available services	CoE (PDO, SDO)
Synchronization mode	Distributed clock for the drive and synchronous input/output for I/O

Item	Description
Physical layer	100BASE-TX
Baud rate	100 Mbit/s (100Base-TX)
Duplex mode	Full duplex
Topology	Linear topology
Transmission medium	Network cable
Transmission distance	Less than 100 m between two nodes
Number of slaves	Up to 72 slaves
EtherCAT Frame length	44 to 1498 bytes
Process data	1486 bytes at most for an individual Ethernet frame

■ Wiring

The PLC achieves EtherCAT bus communication through CN3, which requires the following communication cable:



Signal pin assignment

Pin	Signal	Signal direction	Description
1	TD+	Output	Data transmission+
2	TD-	Output	Data transmission-
3	RD+	Input	Receive data (+)
4	-	-	Not used
5	-	-	Not used

Pin	Signal	Signal direction	Description
6	RD-	Input	Receive data (-)
7	-	-	Not used
08	-	-	Not used

Length requirement

The cable between devices cannot exceed 100 m when the EtherCAT bus is used, exceeding of which may attenuate the signal and affect normal communication.

Technical requirements:


Short circuit, open circuit, misalignment, or poor contact does not occur during 100% continuity test. Cables compliant with the following specifications are recommended.

Item	Specification
Cable type	Flexible crossover cable, S-FTP, Cat5e
Standards compliance	EIA/TIA568A, EN50173, ISO/IEC11801 EIA/TI Abulletin TSB EIA/TIA SB40-A&TSB36
Cross sectional area of the cable	26AWG
Cable category	Twisted pair
Number of pairs	4

5.5.5 RS485 Communication Instructions

It is recommended to use a shielded twisted pair cable as the RS485 bus. Connect a $120\,\Omega$ termination resistor to both ends of the bus respectively to prevent signal reflection. Connect the signal reference grounds of all nodes together. Up to 31 nodes can be connected and the distance between nodes must be less than 3 m.

The RS485 bus topology is shown in the figure below.



5.6 Operation and Maintenance

5.6.1 Start and Stop

After the PLC is programmed, start and stop it as follows.

To run the PLC:

- 1. Set the system to RUN.
- 2. Check that the RUN indicator is solid on in yellow-green.
- 3. To stop the PLC, set the system to STOP state. Alternatively, you can stop it in the software tool of the host controller.

5.6.2 Programming of SD Card User Programs

- Save the SD card programming file compiled by Autoshop to the directory "PLCProgram" of the SD card (maximum capacity 32 GB, file formate FAT32).
- 2. Load the SD card onto the TF extension card and install the card to the PLC.



Install the TF extension card with power off.

- 3. Power on the PLC again and start programming the user programs in the SD card to the PLC. The RUN indicator flashes at a frequency of 4 Hz during programming.
- 4. After programming is done, the RUN indicator flashes at a frequency of 1 Hz and this PLC enters the STOP state. You can remove the SD card now.

If the ERR indicator flashes slowly, programming fails. Check that the model of the programming file is consistent with the actual model and the login password of the programming file is the same as that of the PLC. If the model and password are both correct but the programming failure still occurs, contact Inovance for technical support.

5. Power off and on again.

5.6.3 SD Card Firmware Upgrade

 Load the SD card (maximum capacity 32 GB, file format FAT32) to the TF extension card and the PLC.



Install the TF extension card with power off.

2. Power on the PLC again.

The RUN and ERR indicators flash quickly for 3s, indicating that the firmware upgrade begins. The RUN and ERR indicators remain solid ON, indicating that the firmware is being upgraded. The RUN and ERR indicators flash slowly, indicating that the firmware upgrade is done.

- 3. After firmware upgrade is done, power off the PLC and remove the SD card.
- 4. Power on the PLC again.

5.7 Appendix: Extension Card Options

Model	Туре	Description	Slot	ID
GE20-4DI	Digital input/ output	4 inputs 24 VDC input Source/Sink	A/B	13
GE20-4DO-TN		4 transistor sink outputs 24 VDC output	A/B	5
GE20- 2AD1DA-I	Analog input/ output	2 analog inputs and 1 analog output (current type)	A/B	11
GE20- 2AD1DA-V		2 analog inputs and 1 analog output (voltage type)	A/B	3
GE20-CAN-485	Communication extension	CAN and 485 communication (RJ45 interface)	A	15
GE20-232/485		RS232 or RS485 communication	A/B	7
GE20-232/ 485-RTC		RS232 or RS485 communication (with RTC)	В	14
GE20-TF	Storage extension	TF extension card	В	1
GE20-RTC	Clock extension	Clock extension card	В	9

Note

The ID is "0" when there is no extension card.