



## SV660F Series Servo Drive Commissioning Guide



Industrial  
Automation



Intelligent  
Elevator



New Energy  
Vehicle



Industrial  
Robot



Rail  
Transit



Data code 19011668 A01

# Preface

## About this guide

The SV660F series high performance AC servo drive provides a power range from 0.05 kW to 7.5 kW. It supports Profinet communication protocol and carries Ethernet communication interfaces to work with the host controller for a networked operation of multiple servo drives.

The SV660N series servo drive supports stiffness level setting, inertia auto-tuning and vibration suppression to simplify the operation process. It allows a quiet and stable operation through cooperating with the MS1 series medium-to-small inertia high-response servo motors configured with a 23-bit multi-turn absolute encoder.

It is suitable for lithium battery PACK, printing and packaging, logistics, automobile manufacturing, tobacco and other industries to achieve fast and accurate collaborative control.

This manual presents drive commissioning, parameter descriptions, including the operating panel, commissioning software, commissioning procedure and a parameter list.

## More documents

Name	Data Code	Description
SV660F Series Servo Drive Selection Guide	19011667	Provides instructions on product selection, including the list of supporting components, technical data on the drive and motor, and the selection guide of cables.
SV660F Series Servo Drive Hardware Guide	19011666	Presents electrical design guidance of the equipment, description of terminals, required certificates and standards and solutions to common EMC problems.
SV660F Series Servo Drive Commissioning Guide	19011668	Presents servo commissioning, parameter descriptions, including the operating panel, commissioning software, commissioning procedure and a parameter list.
SV660F Series Servo Drive Communication Guide	19011670	Presents functions and parameters of the servo drive, including Profinet communication configuration, parameter description, and communication application cases.
SV660F Series Servo Drive Function Guide	19011669	Presents functions and parameters, including function overview, basic servo functions, adjustment and parameter list.

Name	Data Code	Description
SV660F Series Servo Drive installation Guide	19012103	Presents installation of the servo drive, including installation steps, mechanical installation, and electrical installation.
SV660F Series Servo Drive Troubleshooting Guide	19012104	Introduces faults and fault levels, the troubleshooting process, warning codes and fault codes.
SV660F Series Servo Drive Maintenance Guide	19012105	Provides instructions on maintenance and repair of the equipment.
SV660F Series Servo Drive Safety Guide	19012110	Presents the safety function and related certifications and standards, wiring, commissioning process, troubleshooting, and functions.
SV660F Series Servo Drive Manual Package	PS00005951	Provides information on selection, installation, commissioning, function, troubleshooting and parameters of the equipment.

## Revision History

Date of Revision	Version	Revision
2022-11	A01	<ul style="list-style-type: none"> <li>Added warranty information in the preface.</li> <li>Changed the MS1-Z motor to MS1-R motor.</li> <li>Adjusted of the structure of section Commissioning and Operation.</li> <li>Optimized the description of H02.18, and groups H03, H07.07, H0A.27, H0A.90, H0A.91, H0A.92, H17 and H29.27.</li> </ul>
2022-07	A00	First release.

## Access to the guide

This guide is not delivered with the product. You can obtain the PDF version in either of the following ways:

- Do keyword search at <http://www.inovance.com>.
- Scan the QR code on the equipment to acquire more.

## Warranty

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. You will be charged for any repair work after the warranty period expires.

Within the warranty period, you will be charged if the product is damaged due to the following causes.

- Failure to operate this product as specified in this guide.

- Fire, flood, or abnormal voltage.
- Unintended use of the product.
- Operation beyond the product's ratings.
- Force majeure (natural disaster, earthquake, and lightning strike).

The maintenance fee is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

For details, see Product Warranty Card.



# Table of Contents

Preface .....	1
General Safety Instructions .....	7
1 Commissioning Tool .....	14
1.1 Operating Panel .....	14
1.1.1 Components of Servo Drives and Servo Motors .....	14
1.1.2 Display Panel Indicators .....	15
1.1.3 Parameter Settings .....	20
1.2 Commissioning Software .....	24
1.2.1 Overview .....	24
1.2.2 Installation .....	25
1.2.3 Connection .....	29
1.2.4 Introduction to the Software Tool .....	32
1.2.5 Multi-drive Adjustment .....	35
2 Commissioning and Operation .....	39
2.1 Commissioning Flowchart .....	39
2.2 Preliminary Check .....	40
2.3 Power-on .....	40
2.4 Jog .....	41
2.5 Setting Parameters .....	44
2.6 Drive Operation .....	59
2.7 Servo OFF .....	69
3 Adjustment .....	73
3.1 Overview .....	73
3.2 Inertia Identification .....	76
3.2.1 Offline Inertia Auto-tuning .....	78
3.2.2 Online Inertia Auto-tuning .....	79
3.3 Auto Gain Tuning .....	81
3.3.1 ETune .....	81
3.3.2 STune .....	88
3.3.3 ITune .....	96
3.4 Manual Gain Tuning .....	97
3.4.1 Basic Parameters .....	97
3.4.2 Gain Switchover .....	101
3.4.3 Position Reference Filter .....	106
3.4.4 Feedforward gain .....	106
3.4.5 PDFF Control .....	109
3.4.6 Torque disturbance observer .....	111
3.4.7 Speed Observer .....	111

3.4.8 Model Tracking .....	114
3.4.9 Friction Compensation .....	116
3.5 DSC Mode Adjustment .....	117
3.6 Parameter Adjustment in Different Control Modes .....	118
3.6.1 Parameter Adjustment in the Position Control Mode .....	118
3.6.2 Parameter Adjustment in the Speed Control Mode .....	120
3.6.3 Parameter Adjustment in the Torque Control Mode .....	121
3.7 Vibration suppression .....	121
3.7.1 Low-Frequency Resonance Suppression at the Mechanical End .....	122
3.7.2 Mechanical Resonance Suppression .....	124
3.8 Mechanical Characteristic Analysis .....	130
4 Description of Parameters .....	132
4.1 H00 Servo Motor Parameters .....	132
4.2 H01 Servo Drive Parameters .....	134
4.3 H02 Basic Control Parameters .....	139
4.4 H03 Terminal Input Parameters .....	150
4.5 H04 Terminal Output Parameters .....	163
4.6 H05 Position Control Parameters .....	169
4.7 H06 Speed Control Parameters .....	185
4.8 H07 Torque Control Parameters .....	192
4.9 H08 Gain Parameters .....	200
4.10 H09 Auto-tuning Parameters .....	217
4.11 H0A Fault and Protection Parameters .....	231
4.12 H0b Monitoring Parameters .....	247
4.13 H0d Auxiliary Parameters .....	265
4.14 H0E Communication Function Parameters .....	269
4.15 H12 Multi-Speed .....	275
4.16 H17 Virtual DI/DO .....	291
4.17 H18 Position Comparison Output .....	312
4.18 H19 Target Position Parameters .....	317
4.19 H24 PN Bus Communication Parameters .....	339
4.20 H25 AC3 Control Parameters .....	349
4.21 H27 Program Block Parameters .....	353
4.22 H28 Program Block Parameters .....	370
4.23 H29 PN Message Value .....	384
4.24 H30 Related Variables Read through Communication .....	400

4.25 H31 Communication Setting .....	401
5 Parameter List. ....	403
5.1 Parameter Group H00 .....	403
5.2 Parameter Group H01 .....	403
5.3 Parameter Group H02 .....	405
5.4 Parameter Group H03 .....	410
5.5 Parameter Group H04 .....	414
5.6 Parameter Group H05 .....	415
5.7 Parameter Group H06 .....	419
5.8 Parameter Group H07 .....	421
5.9 Parameter Group H08 .....	423
5.10 Parameter Group H09 .....	428
5.11 Parameter Group H0A .....	432
5.12 Parameter Group H0b .....	436
5.13 Parameter Group H0d .....	442
5.14 Parameter Group H0E .....	443
5.15 Parameter Group H12 .....	444
5.16 Parameter Group H17 .....	447
5.17 Parameter Group H18 .....	453
5.18 Parameter Group H19 .....	455
5.19 Parameter Group H24 .....	461
5.20 Parameter Group H25 .....	463
5.21 Parameter Group H27 .....	464
5.22 Parameter Group H28 .....	467
5.23 Parameter Group H29 .....	471
5.24 Parameter Group H30 .....	480
5.25 Parameter Group H31 .....	480
6 Appendix .....	481
6.1 Display of Monitoring Parameters .....	481
6.2 DIDO Function Assignment .....	488

# General Safety Instructions

## Safety Precautions

- This section explains the safety precautions that need to be observed to use this product correctly. Before using this product, please read the instruction manual and correctly understand the relevant information of safety precautions. Failure to comply with the safety precautions may result in death, serious injury, or equipment damage.
- "CAUTION", "WARNING", and "DANGER" items in the guide only indicate some of the precautions that need to be followed; they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper use.

## Safety Levels and Definitions



Indicates that failure to comply with the notice will result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

## General Safety Instructions

- Drawings in the selection guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions. Install the covers or protective guards as specified, and use the equipment in accordance with the instructions described in the user guide.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.

### Unpacking

#### WARNING

- Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.
- Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.

#### CAUTION

- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.
- Check whether the package contents are consistent with the packing list before unpacking.

### Storage and Transportation

#### WARNING

- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.

**CAUTION**

- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply will result in equipment damage.
- Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

**Installation****DANGER**

- The equipment can be operated by well-trained and qualified professionals only. Non-professionals are not allowed.

**WARNING**

- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure providing both electrical and mechanical protections must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing devices with strong electromagnetic interference, such as a transformer, install a shielding device for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.

**CAUTION**

- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

**Wiring****DANGER**

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off power connections with all equipment. Residual voltage exists after power cut-off. Therefore, wait at least the time designated on the equipment warning label before further operations. Measure the DC voltage of the main circuit and make sure it is below the safe voltage, otherwise there will be the danger of electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply will result in an electric shock.

**WARNING**

- Do not connect the input power supply to the output end of the equipment. Failure to comply will result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.

**CAUTION**

- During wiring, follow the proper electrostatic discharge (ESD) procedure, and wear an antistatic wrist strap. Failure to comply will damage the equipment or the internal circuits of the equipment.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

**Power-on**

**DANGER**

- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.

**WARNING**

- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, make sure that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

**Operation****DANGER**

- The equipment must be operated only by professionals. Failure to comply will result in death or personal injuries.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.





**WARNING**

- Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.

**Maintenance****DANGER**

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.



 <b>WARNING</b> <ul style="list-style-type: none"> <li>• Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.</li> </ul>
<b>Repair</b>
 <b>DANGER</b> <ul style="list-style-type: none"> <li>• Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.</li> <li>• Do not repair the equipment with power ON. Failure to comply will result in an electric shock.</li> <li>• Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.</li> </ul>
 <b>WARNING</b> <ul style="list-style-type: none"> <li>• Submit the repair request according to the warranty agreement.</li> <li>• When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injuries or equipment damage.</li> <li>• When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly.</li> <li>• Replace quick-wear parts of the equipment according to the replacement instructions.</li> <li>• Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage.</li> <li>• After the equipment is replaced, check the wiring and set parameters again.</li> </ul>
<b>Disposal</b>
 <b>WARNING</b> <ul style="list-style-type: none"> <li>• Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death.</li> <li>• Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.</li> </ul>

## Additional Precautions


### Cautions for the dynamic brake

- Dynamic braking can only be used for emergency stop in case of failure and sudden power failure. Do not trigger failure or power failure frequently.
- Ensure that the dynamic braking function has an operation interval of more than 5 minutes at high speed, otherwise the internal dynamic braking circuit may be damaged.

- Dynamic braking is common in rotating mechanical structures. For example, when a motor has stopped running, it keeps rotating due to the inertia of its load. In this case, this motor is in the regenerative state and short-circuit current passes through the dynamic brake. If this situation continues, the drive, and even the motor, may be burned.

## Safety Label

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. See the following table for descriptions of the safety labels.

Safety Label	Description
	<ul style="list-style-type: none"> <li>• Never fail to connect the protective earth (PE) terminal. Read through the guide and follow the safety instructions before use.</li> <li>• Never fail to connect Protective Earth (PE) terminal. Read the manual and follow the safety instructions before use.</li> <li>• Do not touch terminals within 15 minutes after disconnecting the power supply to prevent the risk of electric shock.</li> <li>• Do not touch terminals with 15 minutes after Disconnect the power. Risk of electrical shock.</li> <li>• Do not touch the heatsink with power ON to prevent the risk of burn.</li> <li>• Do not touch heatsink when power is ON. Risk of burn.</li> </ul>

# 1 Commissioning Tool

## 1.1 Operating Panel

### 1.1.1 Components of Servo Drives and Servo Motors









Figure 1-1 Magnified view of the keypad

The operation panel of the SV660F Series servo drive consists of an LED (5-digit, 8-segment) and five buttons. The keypad is used for value display, parameter setting, user password setting and general function execution. The following table takes parameter setting as an example to describe the general functions of the keys.

Table 1-1 Descriptions of keys

Name	Symbol	Description
MODE		Switches among different modes. Returns to the previous menu.
UP		Increases the value of the blinking digit for the LED.
DOWN		Decreases the value of the blinking digit for the LED.
SHIFT		Shifts the blinking digit for the LED. You can view the high digits of the number consisting of more than 5 digits.
SET		Switches to the lower-level menu. Executes commands such as storing parameter setting value.

### 1.1.2 Display Panel Indicators

The operating panel can display the running status, parameter, faults, and monitoring information during running of the servo drive.

- Status display: Displays current servo drive status, such as servo ready or servo running.
- Parameter display: Displays parameters and their setpoints
- Fault display: Displays faults and warnings that occurred on the servo drive.
- Monitored value display: Displays values of monitoring parameters.

#### Transition relation between the panel display and the operation object of the host controller

The mapping relation between the parameter displayed on the keypad (in decimal) and the object dictionary operated by the host controller (in hexadecimal, "Index" and "Sub-index") is as follows.

Object dictionary index = 0x2000 + Parameter group number

Object dictionary sub-index = Hexadecimal offset within the parameter group + 1 For example:

Display Panel Indicators	Object dictionary operated by the host controller
H02.15	2002.10h

### Note

The following section only describes the display and parameter settings on the keypad side (in decimal), which are different from those displayed in the software tool (in hexadecimal). Make necessary value conversions during use.

#### Display mode switchover












Figure 1-2 Switchover among different display modes

- The keypad enters status display immediately upon power-on.

- Press MODE to switch among different display modes based on the conditions shown in "Figure 1-2 " on page 15 .
- In status display, set H02.32 to select the parameter to be monitored. When the motor rotates, the keypad automatically switches to monitored value display. After the motor stops, the keypad automatically returns to status display.
- In the parameter display mode, after you select the parameter to be monitored in group H0b, the keypad switches to monitored value display.
- Once a fault occurs, the keypad switches to fault display immediately, with all the five LEDs blinking. Press SET to stop the LEDs from blinking, and then press MODE to switch to parameter display.

### Status display

Display	Name	Applicable Occasion	Meaning
	reset Servo drive initializing	Upon power-on	The servo drive is in the initialization or reset status. After initialization or reset is done, the servo drive automatically switches to other status.
	nr Servo not ready	Initialization done, but servo drive not ready.	The servo drive is not ready to run because the main circuit is not powered on. For details, see the Troubleshooting Guide.
	ry Servo ready	Servo drive ready	The servo drive is ready to run and waits for the enabling signal from the host controller.
	rn Servo running	Servo ON (S-ON) signal activated (S-ON signal switched on)	The servo drive is running.
	1-4: operation modes	-	Displays present operation mode of the servo drive in hexadecimal digits. 1: AC1 3: AC3 4: AC4
	1-4: communica tion statuses	-	Displays the status of the Profinet state machine of a slave in characters. 1: Initialization 2: Pre-operational 4: Running

Display	Name	Applicable Occasion	Meaning
	- CN4 connection indication	CN4 indicates Profinet output connection status.	OFF: no communication connection is detected in the physical layer.
	- CN3 connection indication	CN3 indicates successful Profinet input connection.	ON: communication connection is detected in the physical layer.


## Parameter Display

Parameters are divided into 14 groups based on their functions. A parameter can be located quickly based on the parameter group it belongs to.

- Display of parameter groups

Display	Name	Description
HXX.YY	Parameter group	XX: Parameter group No. (Hexadecimal) YY: Offset within the parameter group (decimal)

For example, "H02.00" is displayed as follows.

Display	Name	Description
	H02.00	02: Parameter group No. 00: Offset within the parameter group


- Display of negative numbers and numbers with different lengths
  - Signed number with 4 digits and below or unsigned number with 5 digits and below

Such numbers are displayed in a single page (five digits). For signed numbers, the highest bit "-" represents the negative symbol.

For example, "-9999" is displayed as follows:



For example, "65535" is displayed as follows:



- Signed number with more than 4 digits or unsigned number with more than 5 digits  
Such numbers are displayed from low to high bits in several pages (5 digits per page): current page + values on current page, as shown in the following figure. Hold down SHIFT for more than 2s to switch to the next page.

For example, "-1073741824" is displayed as follows:




Figure 1-3 Display of "-1073741824"

Example: "1073741824" is displayed as follows:








Figure 1-4 Display of "1073741824"

- Display of the decimal point  
The segment "." of the ones indicates the decimal point, which does not blink.

Display	Name	Description
	Decimal point	100.0


- Display of parameter setting status

Display	Name	Applicable Occasion	Meaning
	Done Parameter setting completed	The parameter is set successfully.	The parameter is set and saved to the servo drive (Done). The servo drive can execute other operations.
	F.InIt (Restored to default settings)	Parameter initialization is in progress (H02.31 = 1).	The servo drive is in the process of parameter initialization. After parameter initialization is done, switch on the control power supply again.
	Error (wrong password)	The user password (H02.30) is activated and the password entered is wrong.	A wrong password is entered. You need to enter the password again.
	TunE	Auto-tuning with one-key enabled	The function of auto-tuning with one-key is in progress.
	FAIL	Auto-tuning with one-key enabled	The function of auto-tuning with one-key fails.

## Fault Display

- The panel displays the active or history faults and warning codes. For troubleshooting, see the Troubleshooting Guide.
- When a fault or warning occurs, the operating panel displays the corresponding fault or error code immediately. When multiple faults or errors occur, the keypad displays the fault or error code of the highest fault level.
- You can select the previous fault/warning to be viewed through H0b.33 and view the code of the selected fault/warning in H0b.34.
- You can clear the latest 10 faults or warnings saved in the servo drive by setting H02.31 to 2.

For example, "E941.0" is displayed as following:



Display	Name	Description
	E941.0 Warning code	E: A fault or warning occurs on the servo drive. 941.0: Warning code



Monitored value display

- Group H0b: Displays parameters used to monitor the operating state of the servo drive.
- Set H02.32 (Default keypad display) properly. After the motor operates normally, the keypad switches from status display to parameter display. The parameter group number is H0b and the offset within the group is the setpoint of H02.32.
- For example, if H02.32 is set to 00 and the motor speed is not 0 rpm, the keypad displays the value of H0b.00.

The following table describes the monitoring parameters in H0b.00.

Parameter	Name	Unit	Meaning	Example
H0b.00	Actual motor speed	RPM	Displays the actual value of the motor speed after round-off, which can be accurate to 1 rpm.	Display of 3000 rpm:  -3000 rpm: 

1.1.3 Parameter Settings

Example of parameter settings

You can set parameters through the keypad. For details on parameters, see Chapter "List of Parameters". The following figure shows how to switch from position control mode to speed control mode using the keypad after power-on.




Figure 1-5 Example of parameter setting

- MODE: Used to switch the keypad display mode and return to the previous interface.
- UP/DOWN: Used to increase or decrease the value of the blinking digit.
- SHIFT: Used to shift the blinking digit.
- SET: Used to save the present setpoint or switch to the next interface.

After parameter setting is done, that is, "donE" is displayed on the keypad, press MODE to return to the parameter group interface (interface of "H02.00").

## Forced DI/DO signals

There are five DI and DO signals on the CN1 terminal. Users can allocate the DI/DO function and terminal logic to parameters in group H03/H04 by using the keypad (or host controller communication), so that the host controller can control corresponding servo functions through the DI or use the DO signal output by the servo drive.

The servo drive also provides the forced DI feature. The forced DIs can be used to test the DI functions of the servo drive. Forced DO is not available for the PN bus.

- Forced DI signal input

After this function is enabled, all DI signal levels are controlled by the forced DI setting (H0d.18), independent of external DI signal status.

- Operating procedure:




Figure 1-6 Procedure for setting forced DI function

Related parameters:

See "[H0d\\_en.17](#)" on page 267 for details.

H0d.18 is used to set the forced DI level. The keypad displays the value in hexadecimal. After the hexadecimal value is converted to a binary value, the value "1" indicates high level and "0" indicates low level.

The DI logic is defined by parameters in group H03. H0b.03 is used to monitor the DI level status. The keypad displays the level, and the value of H0b.03 (Monitored DI signal) read in the software tool is hexadecimal.

■ Example:

To activate the DI function allocated to DI1 and deactivate DI functions allocated to DI2 to DI5 (all the DIs are active at low level), set as follows:

As the value "1" indicates high level and the value "0" indicates low level, the corresponding binary value and hexadecimal value are "11110" and "1E" respectively. Therefore, set H0d.18 to "1E" through the keypad.




Figure 1-7 Meaning of the H0d.18 setpoint

Monitoring the DI level status through H0b.03:

If the DI function is normal, the display value of H0b.03 is always the same as that of H0d.18.

In this case, DI1 is displayed as low level and DI2 to DI5 are displayed as high level on the keypad, and the value of H0b.03 read by the software is 1E (hexadecimal).

Display on the operating panel:




Figure 1-8 DI level status corresponding to H0b.03

- Exit  
The forced DI signal function is not retentive upon power-off. Normal DIs apply after restart, or you can set H0d.17 to 0 (No operation) to return to the normal DI mode.

## User password

After the user password (H02.30) is activated, only authorized operators can set parameters.

Set bit5 of H0A. 71 to 1. After setting the user password, you can't view and change the parameters after H02 group through the panel and Inovance servo commissioning platform.

- Setting the user password  
The following figure shows how to set the user password to "00001".




Figure 1-9 Procedure for setting the user password

To change the user password, input current password first to authorize the access to parameter setting. Next, enter H02.30 again to set a new password based on the procedure shown in the preceding figure.

## Note

If the last bit does not blink, the access to parameters is password protected. If the last bit blinks, password is not needed or the password entered is correct.

- **Canceling user password**  
Enter the set user password, and set H02.30 to "00000" to cancel the user password.

## 1.2 Commissioning Software


### 1.2.1 Overview


The software tool InoDriverShop can be downloaded from <http://www.inovance.com>.

Use an S6-L-T00-3.0 communication cable for communication between the drive and the PC.


InoDriverShop supports 32-bit/64-bit Windows 7 and 64-bit Windows 10 operating systems. For details on how to use InoDriverShop, see the help document of InoDriverShop.

## 1.2.2 Installation

1. Software
  - a. Visit the official website of Inovance as shown below.  
<http://www.inovance.com>
  - b. Choose Support → Download, and then type in the keyword InoDriverShop and click Search.
  - c. Click Download.
2. Unzip the package downloaded.
3. Click  **InoDriverShop.exe** to start installing InoDriverShop.



4. Click Next.



5. You can select the directory for installation as needed through the Browse button. The default directory for installation is "C:\Program Files\Inovance\InoDriverShop". In online upgrade, InoDriverShop will be upgraded directly in the original directory. After selecting the directory for installation, click Next.

## InoDriverShop(MD) - InstallShield Wizard

**Choose Destination Location**

Select folder where setup will install files.

Setup will install InoDriverShop(MD) in the following folder.

To install to this folder, click Next. To install to a different folder, click Browse and select another folder.

Destination Folder

C:\Inovance\InoDriverShop

Browse...

InstallShield

< Back

Next >

Cancel

6. Click Install to start installation.

## InoDriverShop(MD) - InstallShield Wizard

**Ready to Install the Program**

The wizard is ready to begin installation.

Click Install to begin the installation.

If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.

InstallShield

< Back


Install

Cancel




## InoDriverShop(MD) - InstallShield Wizard

## Setup Status



7. After installation is done, click Finish.




8. A shortcut icon for InoDriverShop will be generated automatically on the desktop.



### 1.2.3 Connection

1. Start InoDriverShop.



- Double-click  to start the InoDriverShop.
- If there is no shortcut for InoDriverShop on your desktop, click Start and search for InoDriverShop.

2. Create a project.

a. Click ① shown in the following figure to create a project.




Figure 1-10 Start interface

### Note

You can click 2 or 3 shown in the preceding figure to open the project saved before.

b. Open the Project Guide interface.

Click Online or Offline in area ①. Next, click the product series in area ②. Finally, load default communication parameters in area ③ based on the product series selected.



Figure 1-11 Project Guide interface

- c. Click Next page to create a project.
- Creating a project for online device brings you to the following interface. The device is scanned automatically. Select the device to be commissioned and click Finish.




Figure 1-12 Scan interface

- Creating a project for offline device brings you to the following interface. You can select the Slave ID, Object Type, and Software Version as needed and add different standards or customized devices. You can also designate the directory for storage or create multiple offline devices.




Figure 1-13 Project Guide interface for offline device

## Note

- ① Station No., ④ Project name, and the storage directory can be changed as needed.

- d. The project has been created.
3. The main interface is shown as follows.





Figure 1-14 Main interface

## 1.2.4 Introduction to the Software Tool

InoDriverShop features the following functions:


- Oscilloscope: Detects and saves the instantaneous data during operation.




- Parameter management: Reads and downloads parameters in batches.


Parameter Group	Global read (current page)	Global read (next page)	Open ratio	Page settings (read & write)	Write all data group (read & write)	Write all with current page (read & write)	VS Compare	Global all current page	Auto-correct	Find	Global user
As	Port	Description	Setting value	Current value	Unit	Minium	Maximum	Unit	Modified type	Effective node	Position
MC0000	MC0000	Master code	0000	0000	0	0	0	0	Read only	Slave node	0
MC0001	MC0001	Command ID	0000	0000	0	0	0	0	Read only	Slave node	0
MC0002	MC0002	Serial-2-way master code	0000	0000	0	0	0	0	Read only	Slave node	0
MC0003	MC0003	Serial-2-way slave code	0000	0000	0	0	0	0	Read only	Slave node	0
MC0004	MC0004	Serial-2-way ID	0000	0000	0	0	0	0	Read only	Slave node	0
MC0005	MC0005	STP version	0.00	0.00	0.00	0.00	0.00	35	Read only	Slave node	2
MC0006	MC0006	Serial-2-way mode type	0000	0000	0	0	0	0	Read only	Slave node	0
MC0007	MC0007	MTF software version	0.00	0.00	0.00	0.00	0.00	5	Read only	Slave node	1
MC0008	MC0008	TFM software version	0.00	0.00	0.00	0.00	0.00	5	Read only	Slave node	1
MC0009	MC0009	Serial SW version	0	0	0	0	0	0	Read only	Slave node	0
MC0010	MC0010	Serial SW version	0	0	0	0	0	0	Read only	Slave node	0
MC0011	MC0011	MC0000 change sheet	220	220	0	0	0	0	Read only	Slave node	0
MC0012	MC0012	MC0001 change sheet	10710240 3F	10710240 3F	0	0	0	0	Read only	Slave node	0
MC0013	MC0013	MC0002 change sheet	0.40	0.40	0.00	0.40	0.00	0.40	Read only	Slave node	3F
MC0014	MC0014	MC0003 change sheet	0.40	0.40	0.00	0.40	0.00	0.40	Read only	Slave node	3F
MC0015	MC0015	MC0004 change sheet	0.40	0.40	0.00	0.40	0.00	0.40	Read only	Slave node	3F
MC0016	MC0016	MC0005 change sheet	10710240 3F	10710240 3F	0	0	0	0	Read only	Slave node	2
MC0017	MC0017	MC0006 change sheet	4000	4000	0	0	0	0	Read only	Slave node	2
MC0018	MC0018	MC0007 current loop amplifi.	1.00	1.00	0.00	1.00	0.00	35	Read only	Slave node	2
MC0019	MC0019	MC0008 current temperature	40	40	0	0	0	0	Read only	Slave node	2
MC0020	MC0020	Control mode	1	1	0	1	1	1	Read only	Slave node	0
MC0021	MC0021	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0022	MC0022	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0023	MC0023	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0024	MC0024	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0025	MC0025	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0026	MC0026	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0027	MC0027	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0028	MC0028	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0029	MC0029	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0030	MC0030	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0031	MC0031	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0032	MC0032	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0033	MC0033	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0034	MC0034	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0035	MC0035	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0036	MC0036	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0037	MC0037	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0038	MC0038	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0039	MC0039	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0040	MC0040	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0041	MC0041	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0042	MC0042	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0043	MC0043	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0044	MC0044	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0045	MC0045	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0046	MC0046	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0047	MC0047	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0048	MC0048	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0049	MC0049	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0050	MC0050	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0051	MC0051	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0052	MC0052	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0053	MC0053	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0054	MC0054	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0055	MC0055	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0056	MC0056	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0057	MC0057	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0058	MC0058	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0059	MC0059	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0060	MC0060	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0061	MC0061	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0062	MC0062	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0063	MC0063	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0064	MC0064	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0065	MC0065	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0066	MC0066	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0067	MC0067	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0068	MC0068	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0069	MC0069	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0070	MC0070	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0071	MC0071	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0072	MC0072	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0073	MC0073	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0074	MC0074	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0075	MC0075	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0076	MC0076	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0077	MC0077	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0078	MC0078	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0079	MC0079	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0080	MC0080	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0081	MC0081	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0082	MC0082	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0083	MC0083	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0084	MC0084	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0085	MC0085	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0086	MC0086	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0087	MC0087	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0088	MC0088	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0089	MC0089	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0090	MC0090	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0091	MC0091	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0092	MC0092	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0093	MC0093	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0094	MC0094	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0095	MC0095	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0096	MC0096	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0097	MC0097	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0098	MC0098	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0099	MC0099	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0100	MC0100	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0101	MC0101	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0102	MC0102	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0103	MC0103	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0104	MC0104	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0105	MC0105	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0106	MC0106	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0107	MC0107	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0108	MC0108	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0109	MC0109	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0110	MC0110	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0111	MC0111	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0112	MC0112	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0113	MC0113	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0114	MC0114	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0115	MC0115	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0116	MC0116	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0117	MC0117	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0118	MC0118	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0119	MC0119	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0120	MC0120	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0121	MC0121	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0122	MC0122	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0123	MC0123	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0124	MC0124	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0125	MC0125	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0126	MC0126	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0127	MC0127	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0128	MC0128	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0129	MC0129	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0130	MC0130	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0131	MC0131	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0132	MC0132	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0133	MC0133	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0134	MC0134	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0135	MC0135	Slave code	0	0	0	0	0	0	Read only	Slave node	0
MC0136	MC0136	Slave code	0	0	0	0	0</				

- Inertia auto-tuning: Generates the load inertia ratio automatically.






- Mechanical characteristic analysis: Analyzes the resonance frequency of the mechanical system.



- Motion JOG: Generates position references to make the motor reciprocate.



- Gain tuning: Adjusts the stiffness level and monitors the motion data.

## 1.2.5 Multi-drive Adjustment

1. Click the SV660F icon, select **TCP\_DCP** on the right, and then click **Next**.



2. In the next page, devices are scanned with the default network card. If the network card connected to the device is not the currently selected network card, click **Stop Scan** and select the correct network card from the drop-down box on the left.





The screenshot shows the 'Project Guide' window with a blue header bar. Below the header, there is a dropdown menu set to 'Microsoft', a 'Stop' button, a 'Setting' button, and a button labeled 'Automatically assign IP'. The INOVANCE logo is in the top right corner. Below these controls is a table with the following columns: 'Row...', 'Object type', 'Object name', 'IP Address', 'Subnet mask', 'Gateway', and 'MAC Address'. The table is currently empty. At the bottom of the window, there are 'Pre Page' and 'Next page' buttons.

3. Click **Scan** and wait the connected device to be displayed. The network requires that the IP of the network card and that of the device are in the same network segment. You can modify the device name, IP, subnet mask, and default segment in this screen. Click the **Set** button to write the modifications to the device. Then click **Next**.

## Note

After modifying the IP of the device, if the IP of the network card is not on the same network segment as the device, you need to manually adjust the IP of the network card.

The screenshot shows the 'Project Guide' window with a blue header bar. Below the header, there is a dropdown menu set to 'USB3.0 to Gigabit Ethernet Adaptor', a 'Scan' button, a 'Setting' button, and a button labeled 'Automatically assign IP'. The INOVANCE logo is in the top right corner. Below these controls is a table with the following columns: 'Row...', 'Object type', 'Object name', 'IP Address', 'Subnet mask', 'Gateway', and 'MAC Address'. The table is currently empty. At the bottom of the window, there are 'Pre Page' and 'Next page' buttons.



4. Enter the scan screen. The scan result is displayed in the screen. After the scan is correct, click the **Finish** button. You can create a multi-drive project.

Project Guide

Device List


Begin scanning  Slave Id  -

Row...	Object type	Object name	IP Address	Subnet mask	Gateway	MAC Address
<input checked="" type="checkbox"/> 1	SV660F	sv660f2	192.168.0.3	255.255.255.0	192.168.0.3	70-CA-4D-00-00-10
<input checked="" type="checkbox"/> 2	SV660F	sv660f	192.168.0.2	255.255.255.0	192.168.0.2	70-CA-4D-FE-17-21
<input type="checkbox"/> 3		plxbid0ed	192.168.0.1	255.255.255.0	192.168.0.1	28-63-36-CA-F9-7C

Object Online: 3 Scanning, waiting...

Project dir

Project name:

Storage path:  

The screenshot shows the EPLAN 2024 Project Manager interface. The 'EPLAN/Shop' window is open, displaying a list of components and their properties. The components are organized into a table with columns for 'Name', 'Description', 'Quantity', 'Unit', 'Price', 'Total Price', 'Status', 'Location', 'Date', and 'User'. The components are listed in a hierarchical manner, with 'EPLAN/Shop' at the top and various sub-components below it. The 'EPLAN/Shop' component is highlighted in red. The 'EPLAN/Shop' component is a 'Shop' component, and its properties are displayed in the 'Properties' window on the right. The 'Properties' window shows the 'General' tab, which includes fields for 'Name', 'Description', 'Quantity', 'Unit', 'Price', 'Total Price', 'Status', 'Location', 'Date', and 'User'. The 'EPLAN/Shop' component is a 'Shop' component, and its properties are displayed in the 'Properties' window on the right. The 'Properties' window shows the 'General' tab, which includes fields for 'Name', 'Description', 'Quantity', 'Unit', 'Price', 'Total Price', 'Status', 'Location', 'Date', and 'User'. The 'EPLAN/Shop' component is a 'Shop' component, and its properties are displayed in the 'Properties' window on the right. The 'Properties' window shows the 'General' tab, which includes fields for 'Name', 'Description', 'Quantity', 'Unit', 'Price', 'Total Price', 'Status', 'Location', 'Date', and 'User'.

## 2 Commissioning and Operation

### 2.1 Commissioning Flowchart




Figure 2-1 Commissioning flowchart of the drive

## 2.2 Preliminary Check

Check the following items before operating the servo drive and the servo motor.

Table 2-1 Checklist before operation

Record	No.	Description
Wiring		
<input type="checkbox"/>	1	The power input terminals (L1C, L2C, L1, L2, L3, R, S, T) of the servo drive are connected properly.
<input type="checkbox"/>	2	The main circuit cables (U, V, W) of the motor are connected to the U/V/W terminals of the drive correctly.
<input type="checkbox"/>	3	No short circuit exists in the power input terminals (L1, L2, L3, R, S, T) or main circuit output terminals (U, V, W) of the servo drive.
<input type="checkbox"/>	4	The control signal cables, such as the brake signal cable and overtravel protection signal cable, are connected properly.
<input type="checkbox"/>	5	The servo drive and servo motor are grounded properly.
<input type="checkbox"/>	6	The stress suffered by the cable is within the specified range.
<input type="checkbox"/>	7	All the wiring terminals are insulated properly.
Environment and Mechanical Conditions		
<input type="checkbox"/>	1	No unwanted objects (such as cable terminals and metal chippings) that may cause short circuit are present inside or outside the servo drive.
<input type="checkbox"/>	2	The servo drive and the external regenerative resistor are placed on incombustible objects.
<input type="checkbox"/>	3	The servo motor is installed properly. The motor shaft is connected to the machine securely.
<input type="checkbox"/>	4	The servo motor and the machine it is connected to are in good condition and ready to run.

## 2.3 Power-on

### Switching on the input power supply

The power input terminals are L1C/L2C (control circuit power input terminals) and L1/L2/L3 or R/S/T (main circuit power input terminals).

After the power supply is switched on, if the bus voltage indicator is in the normal state and the keypad displays "reset" → "nr" → "ry" in sequence, the servo drive is ready to run and waits for the S-ON signal.

---

## Note

- To connect the main circuit to a single-phase 220 VAC power supply, use any two of terminals L1, L2, L3.
  - If the operation panel keeps displaying "nr" or a fault code, rectify the fault according to the Troubleshooting Guide.
- 

## 2.4 Jog



### Caution

To use the jog function, deactivate the S-ON signal first.

---

The jog function can be used in trial run to check whether the motor rotates properly, without abnormal vibration or noise generated during rotation. You can activate the jogging function through the keypad, or the software tool.

### Jogging through the keypad

- Commissioning Steps




Figure 2-2 Procedure for setting the jog function

## Note

- [1] Press the UP or DOWN key to increase or decrease the jog speed. After exiting from the jog mode, the initial speed applies.
- [2] Press the UP or DOWN key to make the motor rotate forwardly or reversely. After you release the key, the motor stops immediately.

### • Procedure:

1. Enter the jog mode by setting H0d.11 through the keypad.

The keypad displays the default jog speed at this moment.

- Adjust the jog speed through the UP/DOWN key and press the SET key to enter the jog state.

The keypad displays "JOG".

- Press the UP/DOWN key to make the motor run forwardly or reversely.
- Press the MODE key to exit the jog mode and return to the upper-level menu.

The jogging speed returns to the default value.


- Exiting the jog running

Press the MODE key to exit from jog and return to the previous menu.

## Jogging through the software tool

Enter the jog interface of the software tool first, and then set the jog speed. After clicking the S-ON button, you can perform forward or reverse jog through the forward/reverse button.

When you close the jog interface to exit from the jog mode, the jogging speed returns to the default value, with previous setpoint abandoned.





## 2.5 Setting Parameters




Figure 2-3 General Parameter Setting Flowchart

### Identify and set the encoder.

Check whether parameter H00.00 (motor code) agrees with the motor.

Set H02.02 to change the direction of rotation directly.

☆ Related parameters:

See "[H00\\_en.00](#)" on [page 132](#) for details.

See "[H02\\_en.02](#)" on [page 139](#) for details.

The change of H02.02 does not affect the pulse output form or the sign (+/-) of monitoring parameter values.

The direction of "forward drive" in overtravel prevention is the same as that defined by H02.02.

### Stop mode

The stop modes include Brake setting, Servo stop mode at S-ON OFF, Stop mode at No.2 fault, Stop mode at overtravel, and Stop mode at No.1 fault.

1. Select the stop mode for stop at S-ON OFF.

☆ Related parameters:

See "[H02\\_en.05](#)" on [page 141](#) for details.

2. Select the stop mode at No.2 fault.  
☆ Related parameters:  
See "[H02\\_en.06](#)" on page 142 for details.
3. Select the stop mode at overtravel.  
☆ Related parameters:  
See "[H02\\_en.07](#)" on page 142 for details.
4. Select the stop mode at No.1 fault.  
☆ Related parameters:  
See "[H02\\_en.08](#)" on page 143 for details.

## Brake setting

The brake is used to prevent the motor shaft from moving and lock the position of the motor and the motion part when the drive is in the non-operational status.



### Caution

- Use the built-in brake for position-lock purpose only. Do not use this brake for any other purposes (such as braking) other than position lock in the stop state.
- The brake coil has no polarity.
- After the motor stops, switch off the S-ON signal.
- When the motor with brake runs, the brake may generate a click sound, which does not affect its function.
- If instruments such as a magnetic sensor is operating near the motor, flux leakage may occur on the motor shaft end when brake coils are energized (brake released).




Figure 2-4 Application of the brake

Table 2-2 Brake specifications

Motor Model	Holding Torque (N·m)	Supply Voltage (VDC) $\pm 10\%$	Rated power (W)	Coil Resistance ( $\Omega$ ) $\pm 7\%$	Exciting Current (A)	Release Time (ms)	Apply Time (ms)	Backlash (°)
MS1H1-05B/10B MS1H4-10B	0.32	24	6.1	94.4	0.25	$\leq 20$	$\leq 40$	$\leq 1.5$
MS1H1-20B/40B MS1H4-20B/40B	1.5		7.6	75.79	0.32	$\leq 20$	$\leq 60$	$\leq 1.5$
MS1H1-75B/10C MS1H4-75B/10C	3.2		10	57.6	0.42	$\leq 40$	$\leq 60$	$\leq 1$
MS1H2-10C/ 15C/20C/25C	8		17.6	32.73	0.73	$\leq 40$	$\leq 100$	$\leq 1$
MS1H2-30C/ 40C/50C	16		24	24	1	$\leq 60$	$\leq 120$	$\leq 1$
MS1H3-85B/ 13C/18C	16		24	24	1	$\leq 60$	$\leq 120$	$\leq 1$
MS1H3-29C/ 44C/55C/75C	50		31	18.58	1.29	$\leq 100$	$\leq 200$	$\leq 1$

## Note

- Do not use a holding brake for braking.
- The release time and operation time of the brake depend on the discharge circuit. Be sure to confirm the operation delay of your equipment before use.
- You need to prepare the 24 VDC power supply yourself.

- Brake sequence in normal state

The brake sequence in the normal state is further divided into the following two types:

- Standstill: The actual motor speed is lower than 20 RPM.
- Rotating: The motor speed is equal to or higher than 20 RPM.

- Brake sequence for motor at standstill

If the servo enabling (S-ON) signal changes from ON to OFF, and the present motor speed is lower than 20 RPM, the servo drive acts according to the brake time sequence in the static state of the motor.



## Caution

- After the brake output signal changes from "OFF" to "ON", do not input a position/speed/torque reference within the time defined by H00.61. Otherwise, reference loss or an operation error may occur. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)
- When the motor is used to drive a vertical axis, the motion part may move slightly under the influence of gravity or external force. If the S-ON signal is switched off, the brake output is set to "OFF" immediately when the motor is at standstill. However, within the time defined by H02.10, the motor is still energized, preventing the load from moving under the influence of gravity or external force.




Figure 2-5 Brake sequence for motor at standstill

## Note

- [1]: When the S-ON signal is switched on, the brake output is set to "ON" at a delay of about 80ms, with motor being energized at the same time.
- [2]: For delay of brake contactor actions, see ["Table 2-2 " on page 46](#).
- [3]: The interval time, starting from the moment when brake output is set to "ON" to the moment when a command is input, must be higher than the setpoint of H00.61. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)
- [4]: When the S-ON signal is switched off with motor at standstill (motor speed lower than 20 rpm), the brake output is set to "OFF". You can set in H02.10 the delay of the motor in entering the de-energized state after the brake output is set to "OFF".

---

☆ Related parameters:

See [" H02\\_en.09" on page 143](#) for details.

See [" H02\\_en.10" on page 143](#) for details.

- Brake sequence for motor in the rotation state  
If the S-ON signal changes from ON to OFF, and the present motor speed is equal to or higher than 20 RPM, the servo drive acts according to the brake time sequence in motor rotating state.



- When the S-ON signal is switched on, do not input a position/speed/torque reference within the time defined by H00.61. Otherwise, reference loss or an operation error may occur. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)
- If the S-ON signal is switched off when the motor is still rotating, the motor enters the "Stop at zero speed" state, but the brake output can be set to "OFF" only when one of the following conditions is met:
  - The motor has decelerated to the value defined by H02.11, but the time defined by H02.12 is not reached.
  - The time defined by H02.12 has been reached, but the motor speed is still higher than the value defined by H02.11.
- The motor is still energized within 50 ms after the brake output changes from "ON" to "OFF". This is to prevent the motion parts from moving under the influence of gravity or external force.




Figure 2-6 Brake sequence for a rotating motor

## Note

- [1]: When the S-ON signal is switched on, the brake output is set to "ON" at a delay of about 80ms, with motor being energized at the same time.
- [2]: For delay of brake contactor actions, see ["Table 2-2" on page 46](#).
- [3]: The interval time, starting from the moment when brake output is set to "ON" to the moment when a command is input, must be higher than the setpoint of H00.61. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)
- [4]: When the motor is rotating and S-ON is OFF, the motor enters a non-energized state when the brake outputs OFF after the delay set in H02.12 or the speed feedback is less than H02.11.

☆ Related parameters:

See ["H02\\_en.11" on page 144](#) for details.

See "[H02\\_en.12](#)" on page 144 for details.

- Brake sequence in the fault state  
Based on stop mode, servo faults are classified into class 1 (No.1) faults and class 2 (No.2) faults. For details, see the Troubleshooting Guide. The brake sequences in the fault state are further divided into the following two types:
  - In case of No. 1 faults:  
The condition for brake output is the same as the brake sequence for the motor in the rotation state. Which is to say: The brake output can be set to "OFF" only when any one of the following conditions is met:
    - The motor has decelerated to the value defined by H02.11, but the time defined by H02.12 is not reached.
    - The time defined by H02.12 has been reached, but the motor speed is still higher than the value defined by H02.11.
  - In case of No. 2 faults:  
When a No. 2 fault occurs and the brake is enabled, the stop mode is forced to "Stop at zero speed, keeping dynamic braking status".  
  
In this case, the servo motor stops at zero speed first. When the actual motor speed is lower than 20 RPM, the brake output signal immediately becomes OFF, but the motor is still in the energized state within the time defined by H02.10.

## Regenerative resistor setting

When the motor torque direction is opposite to the direction of rotation, the energy is fed back to the servo drive from the motor side, leading to bus voltage rise. Once the bus voltage rises to the braking threshold, the excessive energy must be consumed by a regenerative resistor. Otherwise, the servo drive will be damaged. The regenerative resistor can be a built-in or an external one. The internal and built-in regenerative resistors must not be used together. Specifications of the regenerative resistor are as follows.

Table 2-3 Specifications of the regenerative resistor

Servo Drive Model	Specifications of Built-in Regenerative Resistor			External regenerative resistor Min. Allowable Resistance (Ω) (H02.21)
	Resistance (Ω)	Power (Pr) (W)	Processing Power (Pa) (W)	
SV660FS1R6I	-	-	-	50
SV660FS2R8I	-	-	-	45
SV660FS5R5I	50	50	25	40

Servo Drive Model	Specifications of Built-in Regenerative Resistor			External regenerative resistor Min. Allowable Resistance ( $\Omega$ ) (H02.21)
	Resistance ( $\Omega$ )	Power (Pr) (W)	Processing Power (Pa) (W)	
SV660FS7R6I	25	80	40	20
SV660FS012I				15
SV660FT3R5I	100	80	40	80
SV660FT5R4I	100	80	40	60
SV660FT8R4I	50	80	40	45
SV660FT012I				40
SV660FT017I	35	100	50	35
SV660FT021I				25
SV660FT026I				

## Note

- The built-in braking resistor is not available in standard S1R6 or S2R8 models. You can install an external regenerative resistor as needed or contact Inovance to order customized S1R6 and S2R8 models that carry the built-in regenerative resistor.
- The processing power ( $P_a$ ) of the built-in regenerative resistor is affected by the ambient temperature and actual load rate of the drive.

- Without external load torque

The kinetic energy generated upon braking of a reciprocating motor is converted into electric energy that fed back to the bus capacitor. When the bus voltage rises above the braking voltage threshold, the regenerative resistor starts consuming the excessive energy fed back by the motor. The following figure shows the motor speed curve in no-load operation from 3000 rpm to a standstill.






Figure 2-7 Example of motor speed curve (without external load torque)

- Energy calculation  
The built-in braking resistor is not available in SV660FS1R6I and SV660FS2R8I models. The energy that can be absorbed by a capacitor is described in section "Design of Peripherals" in SV660F Series Servo Drive Hardware Guide. An external regenerative resistor is needed when the rotational energy of the motor and the load exceeds the values listed in the following table.

Drive Model	Regenerative Energy That Can Be Absorbed (W)	Remarks
SV660FS1R6I	13.15	The input voltage of the main circuit power supply is 220 VAC.
SV660FS2R8I	26.29	

- The following table shows the energy generated by a 220 V motor in decelerating from the rated speed to a standstill during no-load operation.

Capacity (kW)	Servo Motor Model MS1H*-*****-*****	Rotor Inertia J (10 <sup>-4</sup> kgm <sup>2</sup> )	EO Generated During Decelerating from Rated Speed to a Standstill (J)	Max. Braking Energy Absorbed by Capacitor E C (J)
0.05	MS1H1-05B30CB-A330Z MS1H1-05B30CB-A332Z	0.026 (0.028)	0.13 (0.14)	7.86
0.1	MS1H1-10B30CB-A330Z MS1H1-10B30CB-A332Z	0.041 (0.043)	0.20 (0.21)	
0.2	MS1H1-20B30CB-A331R MS1H1-20B30CB-A334R	0.0938 (0.106)	0.46 (0.52)	
0.4	MS1H1-40B30CB-A331R MS1H1-40B30CB-A334R	0.145 (0.157)	0.72 (0.78)	15.72
0.55	MS1H1-55B30CB-A331R	0.55	2.72	22.39
0.75	MS1H1-75B30CB-A331R MS1H1-75B30CB-A334R	0.68 (0.71)	3.36 (3.51)	22.39

Capacity (kW)	Servo Motor Model MS1H*-*****_*****	Rotor Inertia J ( $10^{-4}$ kgm <sup>2</sup> )	EO Generated During Decelerating from Rated Speed to a Standstill (J)	Max. Braking Energy Absorbed by Capacitor E C (J)
1	MS1H1-10C30CB-A331R MS1H1-10C30CB-A334R	0.82 (0.87)	4.05 (4.30)	32.39
1	MS1H2-10C30CB-A331R MS1H2-10C30CB-A334R	1.78 (2.6)	8.80 (12.86)	32.39
1.5	MS1H2-15C30CB-A331R MS1H2-15C30CB-A334R	2.35 (3.17)	11.6 (15.68)	32.39
2.0	MS1H2-20C30CB-A331R MS1H2-20C30CB-A334R	2.92 (3.74)	14.44 (18.49)	32.39
0.85	MS1H3-85B15CB-A331R MS1H3-85B15CB-A334R	13.56 (15.8)	16.45 (17.3)	32.39
1.3	MS1H3-13C15CB-A331R MS1H3-13C15CB-A334R	19.25 (21.5)	22 (22.86)	32.39
0.1	MS1H4-10B30CB-A330Z MS1H4-10B30CB-A332Z	0.102 (0.104)	0.50 (0.51)	7.86
0.2	MS1H4-20B30CB-A331R MS1H4-20B30CB-A334R	0.22 (0.23)	1.09 (1.14)	7.86
0.4	MS1H4-40B30CB-A331R MS1H4-40B30CB-A334R	0.43 (0.44)	2.13 (2.18)	15.72
0.55	MS1H4-55B30CB-A331R	1.12	5.54	22.39
0.75	MS1H4-75B30CB-A331R MS1H4-75B30CB-A334R	1.46 (1.51)	7.22 (7.47)	22.39
1.0	MS1H4-10C30CBA331R MS1H4-10C30CBA334R	1.87 (1.97)	9.25 (9.74)	32.39

- The following table shows the energy generated by a 380V motor in decelerating from the rated speed to a standstill during no-load operation.

Capacity (kW)	Servo Motor Model MS1H*-*****_*****	Rotor Inertia J ( $10^{-4}$ kgm <sup>2</sup> )	Braking Energy E O Generated During Decelerating from Rated Speed to a Standstill (J)	Max. Braking Energy Absorbed by Capacitor E C (J)
1.0	MS1H2-10C30CD-A331R MS1H2-10C30CD-A334R	1.78 (2.6)	8.8 (12.86)	28.18
1.5	MS1H2-15C30CD-A331R MS1H2-15C30CD-A334R	2.35 (3.17)	11.62 (15.68)	34.22
2.0	MS1H2-20C30CD-A331R MS1H2-20C30CD-A334R	2.92 (3.74)	14.44 (18.49)	50.32
2.5	MS1H2-25C30CD-A331R MS1H2-25C30CD-A334R	3.49 (4.3)	17.26 (21.26)	50.32
3.0	MS1H2-30C30CD-A331R MS1H2-30C30CD-A334R	6.4 (9.38)	31.65 (46.38)	50.32
4.0	MS1H2-40C30CD-A331R MS1H2-40C30CD-A334R	9 (11.98)	44.51 (59.24)	82.53

Values in




Figure 2-8 Flowchart for selecting the regenerative resistor

## Note

- Take the process in which the motor decelerates from 3000 RPM to 0 RPM as an example. Assume that the load inertia is ( $N \times$  Motor inertia), then the braking energy is  $(N + 1) \times E_O$  when the motor decelerates from 3000 RPM to 0 RPM. The energy consumed by the braking resistor is  $(N + 1) \times E_O - E_C$  ( $E_C$  represents the energy absorbed by the capacitor). Suppose the reciprocating cycle is  $T$ , then the power of the regenerative resistor needed is  $2 \times [(N + 1) \times E_O - E_C] / T$ . For values of  $E_O$  and  $E_C$ , see Calculated Energy Data in the Commissioning Guide.
  - Determine whether to use the regenerative resistor according to the preceding figure and select a built-in or an external regenerative resistor as needed. Then, set H02.25 accordingly.
  - The resistor with aluminum case is recommended.
- 

Take the H1 series 750 W model as an example. Assume that the reciprocating cycle ( $T$ ) is 2s, the maximum speed is 3000 RPM, and the load inertia is ( $4 \times$  Motor inertia), then the required power of the braking resistor is as follows:

$$P_b = \frac{2 \times [(N+1) \times E_O - E_C]}{T} = \frac{2 \times [(4+1) \times 6.824 - 32.422]}{2} = 1.698W$$

The calculated result is smaller than the processing capacity ( $P_a$  is 40 W) of the built-in braking resistor, so a built-in braking resistor is enough.

If the inertia ratio in the preceding example is changed to  $10 \times$  motor inertia, and other conditions remain the same, the power of the regenerative resistor required will be as follows:

$$P_b = \frac{2 \times [(N+1) \times E_O - E_C]}{T} = \frac{2 \times [(10+1) \times 6.824 - 32.422]}{2} = 42.642W$$

The calculation result is larger than the processing capacity ( $P_a$  is 40 W) of the built-in braking resistor, so an external braking resistor is required. The recommended power of the external braking resistor is  $P_b \div (1 - 70\%) = 142.14W$ .

☆ Related parameters:

See "[H02\\_en.21](#)" on [page 145](#) for details.

See "[H02\\_en.24](#)" on [page 147](#) for details.

See "[H02\\_en.25](#)" on [page 148](#) for details.

See "[H02\\_en.26](#)" on [page 148](#) for details.

See "[H02\\_en.27](#)" on [page 148](#) for details.

- Using an external regenerative resistor

When  $P_b$  is greater than  $P_a$ , use an external braking resistor. Set H02.25 to 1 or 2 based on the cooling mode of the braking resistor.

Use the external braking resistor with 70% derated, that is,  $P_r$  equals to  $P_b / (1 - 70\%)$ , and ensure the resistance of the braking resistor is higher than the minimum allowed resistance allowed by the servo drive. Remove the jumper bar between terminals P⊕ and D, and connect the external regenerative resistor between terminals P⊕ and C.

See section "Wiring of the Regenerative Resistor" in SV660F Series Servo Drive Hardware Guide for the wiring diagram of the external regenerative resistor and the specifications of the jumper bar. Set H02.25 to 1 or 2 based on the cooling mode of the braking resistor.

☆ Related parameters:

See "[H02\\_en.21](#)" on page 145 for details.

See "[H02\\_en.26](#)" on page 148 for details.

See "[H02\\_en.27](#)" on page 148 for details.



### Caution

- Set the power (H02.26) and resistance (H02.27) of the external regenerative resistor.
- Ensure the resistance of the external regenerative resistor is higher than or equal to the permissible minimum resistance.
- When the regenerative resistor is used at its rated power rather than the processing power (average value) in environments within the specified temperature range, the temperature of the resistor will rise to above 120°C under continuous braking. To ensure safety, cool the resistor down through forced air cooling, or use the resistor with thermal switch. For the load characteristics of the regenerative resistor, consult with the manufacturer.

---

Set the heat dissipation coefficient based on the heat dissipation condition of the external regenerative resistor.

☆ Related parameters:

See "[H02\\_en.24](#)" on page 147 for details.

---

## Note

Higher resistor heat dissipation coefficient indicates higher braking efficiency.

---

- Using the built-in braking resistor

When  $P_b$  is smaller than  $P_a$  and  $E_1$  is greater than  $E_c$ , use the built-in braking resistor. In this case, set H02.25 to 0.

When using the built-in regenerative resistor, connect terminals  $P\oplus$  and D with a jumper bar.

- Regenerative resistor not needed

When  $E_1$  is smaller than  $E_c$ , no braking resistor is required because the braking energy can be absorbed by the bus capacitor. In this case, set H02.25 to 3.

- External load torque applied, motor in generating state

When the motor direction of rotation is the same with the shaft direction of rotation, the motor outputs energy to the outside. In some applications where the motor direction of rotation is opposite to the shaft direction of rotation, the motor is in the generating state and feeds the electric energy back to the servo drive.

When the load is in the generating state continuously, it is recommended to adopt the common DC bus mode.




Figure 2-9 Example of the curve with external load torque

Take H1 series 750 W models (rated torque:  $2.39 \text{ N} \cdot \text{m}$ ) as an example. When the external load torque is 60% of the rated torque and the motor speed reaches 1500 RPM, the power fed back to the drive is  $(60\% \times 2.39) \times (1500 \times 2\pi/60) = 225 \text{ W}$ . As

the braking resistor needs to be derated by 70%, the power of the external braking resistor is  $225/(1 - 70\%) = 750 \text{ W}$ , with resistance being  $50 \Omega$ .

### Input/Output signal setting

The input/output signal setting is the same as "DI/DO setting mode selection".

See ["6.2 DIDO Function Assignment" on page 488](#) for details.

## 2.6 Drive Operation

Switch on the S-ON signal.

When the servo drive is ready to run, the keypad displays "run". If there is no reference input at this moment, the motor does not rotate and stays locked. After a reference is input, the motor starts rotating.

Table 2–4 Checklist before operating the drive

Log	No.	Description
<input type="checkbox"/>	1	During initial operation, set a proper command to make the motor run at low speed and check whether the motor rotates properly.
<input type="checkbox"/>	2	Observe whether the motor rotating direction is correct. If the direction of rotation is opposite to the expected direction, check the reference signal input and the reference direction setting signal.
<input type="checkbox"/>	3	If the motor rotates in the correct direction, you can view the actual speed in H0b.00 and the average load rate in H0b.12 through the keypad or the software tool.
<input type="checkbox"/>	4	After checking preceding conditions, adjust related parameters to make the motor operate as desired.
<input type="checkbox"/>	5	Commission the drive according to Chapter "Adjustment".



### Power-on sequence diagram




Figure 2-10 Power-on sequence diagram

### Note

- [1] The reset time is determined by the setup time of the +5V power supply of the microprocessor.
- [2] The dynamic brake is included in the standard configuration.
- [3] For delay of brake contactor actions, see ["Table 2-2" on page 46](#).
- [4] If the brake is not used, H00.61 is invalid. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)

### Sequence diagram for stop at warning or fault

- No. 1 fault: Coast to stop, keeping de-energized status




Figure 2-11 Sequence of "Coast to stop, keeping de-energized state" at No. 1 fault

## Note

- [1] If the brake is not used, H02.11 and H02.12 are ineffective.
- [2] For delay of brake contactor actions, see ["Table 2-2 " on page 46.](#)
- [3] The dynamic brake is included in the standard configuration.

- No. 1 fault: Dynamic braking stop, keeping de-energized state




Figure 2-12 Sequence of "Dynamic braking stop, keeping de-energized state" at No. 1 fault

## Note

- [1] If the brake is not used, H02.11 and H02.12 are ineffective.
- [2] For delay of brake contactor actions, see ["Table 2-2" on page 46](#).
- [3] The dynamic brake is included in the standard configuration.

- No. 1 fault: Dynamic braking stop, keeping dynamic braking state




Figure 2-13 Sequence of "Dynamic braking stop, keeping dynamic braking state" at No. 1 fault

## Note

- [1] If the brake is not used, H02.11 and H02.12 are ineffective.
- [2] For delay of brake contactor actions, see ["Table 2-2" on page 46](#).
- [3] The dynamic brake is included in the standard configuration.

- No. 2 fault (without brake): Coast to stop, keeping de-energized state




Figure 2-14 Sequence of "Coast to stop, keeping de-energized state" at No. 2 fault

- No. 2 fault (without brake): Stop at zero speed, keeping de-energized status




Figure 2-15 Sequence of "Stop at zero speed, keeping de-energized state" at No. 2 fault (without brake)

- No. 2 fault (without brake): Stop at zero speed, keeping dynamic braking state




Figure 2-16 Sequence of "Stop at zero speed, keeping dynamic braking state" at No. 2 fault (without brake)

- No. 2 fault (without brake): Dynamic braking stop, keeping dynamic braking state




Figure 2-17 Sequence of "Dynamic braking stop, keeping dynamic braking state" at No. 2 fault (without brake)

- No. 2 fault (without brake): Dynamic braking stop, keeping de-energized state




Figure 2-18 Sequence of "Dynamic braking stop, keeping de-energized state" at No. 2 fault (without brake)

- No. 2 fault (with brake): Stop at zero speed, keeping dynamic braking status




Figure 2-19 Sequence of "Stop at zero speed, keeping dynamic braking state" at No. 2 fault (with brake)

## Note

- [1]: If the brake is not used, H02.10 is invalid.
- [2] For delay of brake contactor actions, see ["Table 2-2 " on page 46.](#)
- When a No. 3 warning occurs on the servo drive, such as E900.0 (DI emergency braking), E950.0 (Positive limit switch warning), and E952.0 (Negative limit switch warning), the servo drive stops according to ["Figure 2-20 Sequence for warnings that cause stop" on page 67.](#)
- Warnings that cause stop: Stop at zero speed, keeping position lock status




Figure 2-20 Sequence for warnings that cause stop

The other warnings do not affect the operation state of the drive. The sequence diagram for these warnings is shown in ["Figure 2-21 Sequence for warnings that do not cause stop" on page 68](#).

- Warnings that do not cause stop






Figure 2-21 Sequence for warnings that do not cause stop

- Fault reset S-ON




Figure 2-22 Sequence for fault reset

## Note

- [1] The DI signal used for fault reset (FunIN.2: ALM-RST) is edge triggered.
- [2] For delay of brake contactor actions, see ["Table 2-2" on page 46](#).
- [3] If the brake is not used, H00.61 is invalid. (The system defaults to output position/speed reference after the time set in H00.61. When H01.91 bit = 1, the position/speed reference is output after the time set in H02.09.)

## 2.7 Servo OFF

Five type of stop modes are available for the servo drive: coast to stop, stop at zero speed, ramp to stop, stop at emergency-stop torque, and dynamic braking stop, along with three kinds of stop status: de-energized, position lock, and dynamic braking. See the following table for details.

Table 2-5 Comparison of the stop modes

Stop Mode	Description	Feature
Coast to stop	The motor is de-energized and coasts to 0 RPM. The deceleration time is affected by the mechanical inertia and mechanical friction.	This mode features smooth and slow deceleration with small mechanical shock.
Stop at zero speed	The motor decelerates to 0 rpm immediately and stops.	Features quick deceleration with obvious mechanical shock.
Ramp to stop	The motor decelerates to 0 rpm smoothly upon position/speed/torque reference input.	Features smooth and controllable deceleration with small mechanical shock.
Stop at emergency-stop torque	The servo drive outputs reverse braking torque to stop the motor.	Features quick deceleration with obvious mechanical shock.
Dynamic braking	The servo motor is in the dynamic braking status.	Features quick deceleration with obvious mechanical shock.

Table 2-6 Comparison of the stop status

Stop Status	Description
De-energized	The motor is de-energized and the motor shaft can be rotated freely after the motor stops rotating.
Position Lock	The motor shaft is locked and cannot be rotated freely after the motor stops rotating.
Dynamic Braking	The motor is de-energized and the motor shaft can be rotated freely after the motor stops rotating.

The stop events can be divided into the following types: stop at S-ON OFF, stop at fault, stop at overtravel, emergency stop, quick stop, and halt. See the following descriptions for details.

### Stop at S-ON OFF

Deactivate the S-ON signal through communication to make the drive stop according to the stop mode at S-ON OFF.

☆ Related parameters:

See the description of H02.05.

### Fault reaction

The stop mode varies according to the fault type. For fault classification, see SV660F Series Servo Drive Troubleshooting Guide.

☆ Related parameters:

See "[H02\\_en.06](#)" on [page 142](#) for details.

See "[H02\\_en.08](#)" on [page 143](#) for details.

### Stop at overtravel

★ Definition of terms:

- "Overtravel": The mechanical motion exceeds the designed range of safe movement.
- Stop at overtravel: When a motion part moves beyond the range of safe movement, the limit switch outputs a level change signal, and the servo drive forcibly stops the motor.

☆ Related parameters:

See "[H02\\_en.07](#)" on [page 142](#) for details.

When overtravel occurs on a motor used to drive a vertical axis, the workpiece may fall. To prevent the risk of falling, set H02.07 (Stop mode at overtravel) to 1. When the workpiece moves linearly, install the limit switch to prevent mechanical damage. When overtravel occurs, input a reverse running command to make the motor (workpiece) run in the opposite direction.




Figure 2-23 Installation of limit switches

To use the limit switches, assign FunIN.14 (P-OT, positive limit switch) and FunIN.15 (N-OT, negative limit switch) to two DIs of the servo drive and set the active logic of these DIs. This is to enable the servo drive to receive the level signals input from the limit switches. The servo drive determines whether to enable the limit switch function based on the state of the DI terminal level.

☆ Related parameters:

Code	Name	Function Name	Description
FunIN.14	P-OT	Positive limit switch	When the machine moves beyond the specified range, overtravel prevention applies. Inactive: Forward drive permitted Active: Forward drive inhibited
FunIN.15	N-OT	Negative limit switch	When the machine moves beyond the specified range, overtravel prevention applies. Inactive: Reverse drive permitted Active: Reverse drive inhibited

## Emergency stop

The servo drive supports two emergency stop modes:

- Using DI function 34: FunIN.34 (EmergencyStop)
- Using the auxiliary function: emergency stop (H0d.05)

When emergency stop is enabled, the motor stops according to the mode specified by the parameter H02.18.

☆ Related parameters:

Code	Name	Function Name	Description
FunIN.34	Emergency Stop	Braking	Inactive: Current operating state unaffected Active: Stop quickly as defined by H02.18, keeping position lock status, with E900.0 (DI emergency braking) reported.

☆ Related parameters:

See "[H02\\_en.05](#)" on page 141 for details.

See "[H02\\_en.15](#)" on page 144 for details.

See "[H02\\_en.18](#)" on page 145 for details.

## 3 Adjustment

### 3.1 Overview

The servo drive must drive the motor as quick and accurate as possible to follow the commands from the host controller or internal setting. Gain adjustment needs to be performed to meet such requirement.





Figure 3-1 Example of gain tuning

The gain is defined by a combination of multiple parameters that affect each other. Such parameters include the position loop gain, speed loop gain, filter and load moment of inertia ratio. The values of these parameters must be balanced against each other during gain tuning.

### Note

Before gain tuning, perform a trial run through jogging to ensure the motor operates properly.

The following figure shows the general flowchart for gain tuning.



### Figure 3-2 Steps

Table 3–1 Description of gain tuning

Steps			Description	Reference
1	Inertia Identification	Offline	The servo drive calculates the load inertia ratio automatically through inertia auto-tuning.	<a href="#">"3.2.1 Offline Inertia Auto-tuning" on page 78</a>
		Online	The host controller sends a command to make the motor rotate, and the servo drive calculates the load inertia ratio in real time.	<a href="#">"3.2.2 Online Inertia Auto-tuning" on page 79</a>
2	Gain auto-tuning		The servo drive generates a group of gain parameters based on the correct inertia ratio.	<a href="#">"3.3.1 ETune" on page 81,</a> <a href="#">"3.3.2 STune" on page 88</a> and <a href="#">"3.3.3 ITune" on page 96</a>
3	Manual gain adjustment	Basic gains	If the auto-tuned gain values fail to deliver desired performance, fine-tune the gains manually to improve the performance.	<a href="#">"3.4.1 Basic Parameters" on page 97</a>
		Reference filter	Smoothens the position, speed, and torque references.	<a href="#">"3.4.3 Position Reference Filter" on page 106</a>
		Feedforward gain	Improves the follow-up behavior.	<a href="#">"3.4.4 Feedforward gain" on page 106</a>
		Pseudo differential regulator	Adjusts the speed loop control mode to improve the anti-interference capability at low frequency range.	<a href="#">"3.4.5 PDFF Control" on page 109</a>
		Torque disturbance observer	Improves the resistance against torque disturbance.	<a href="#">"3.4.6 Torque disturbance observer" on page 111</a>



Steps			Description	Reference
4	Vibration suppression	Mechanical resonance	Suppresses mechanical resonance through the notch.	<a href="#">"3.7.2 Mechanical Resonance Suppression" on page 124</a>
		Low-frequency resonance	Activate the filter used to suppress low-frequency resonance.	<a href="#">"3.7.1 Low-Frequency Resonance Suppression at the Mechanical End" on page 122</a>

## 3.2 Inertia Identification

The load inertia ratio (H08.15) is calculated through the following formula:

$$\text{Load inertia ratio} = \frac{\text{Total mechanical load moment of inertia}}{\text{Motor moment of inertia}}$$

The load inertia ratio is a critical parameter of the servo system. A correct load inertia ratio facilitates commissioning.

You can set the load inertia ratio manually or get the inertia ratio through inertia auto-tuning.

The following two inertia auto-tuning modes are available:

- **Offline Inertia Auto-tuning**  
To enable offline inertia auto-tuning, use H0d.02 (Offline inertia auto-tuning) and make the motor rotate and execute inertia auto-tuning through the keypad. Offline inertia auto-tuning does not involve the host controller
- **Online Inertia Auto-tuning**  
Send a command to the servo drive through the host controller to make motor act accordingly to finish inertia auto-tuning. Online inertia auto-tuning involves the host controller.

---

## **Note**

The following conditions must be fulfilled for an accurate calculation of the load inertia ratio during inertia auto-tuning:

- The actual maximum speed of the motor is higher than 150 rpm.
  - The acceleration rate during acceleration/deceleration of the motor is higher than 3000 rpm/s.
  - The load torque is stable without dramatic changes.
  - The actual inertia ratio does not exceed 120.
  - Inertia auto-tuning may fail in case of a large backlash of the transmission mechanism.
-

### 3.2.1 Offline Inertia Auto-tuning




Figure 3-3 Offline inertia auto-tuning flowchart

Check the following before performing offline inertia auto-tuning:

The motor must meet the following requirements:

- A travel distance of more than one revolutions in the forward/reverse direction is available between the mechanical limit switches.  
Ensure limit switches are installed to the machine and a travel distance as described above is reserved to prevent overtravel during inertia auto-tuning.
- The required number of revolutions (H09.09) is fulfilled.

View the values of H09.06 (Maximum speed of inertia auto-tuning), H09.07 (Time constant for accelerating to the maximum speed during inertia auto-tuning), and H09.09 (Number of revolutions per inertia auto-tuning) to ensure the travel distance that starts from the stop position is larger than the value of H09.09.

Otherwise, decrease the value of H09.06 or H09.07 until this requirement is met.

Operating procedure:

1. Switch off the S-ON signal.
2. In parameter display mode, switch to H0d.02 and press SET to enable offline inertia auto-tuning.
3. Press the UP/DOWN key to perform offline inertia auto-tuning.
4. To stop the drive, release the UP/DOWN key. To restart auto-tuning, press the UP/DOWN key again.

The operating direction at start is determined by the UP/DOWN key. For applications requiring unidirectional movement, set H09.05 to 1.

5. Wait until the value displayed on the keypad is stabilized.
6. Hold the SET key down until the keypad displays "SAVE".
7. Press the MODE key to exit.

For applications requiring large load inertia, set H08.15 (Load moment of inertia) to the approximate value. preventing intense system vibration caused by a low initial inertia.

The following figure shows general flowchart for offline inertia auto-tuning.

☆ Related parameters:

See "[H0d\\_en.02](#)" on page 265 for details.

See "[H09\\_en.05](#)" on page 219 for details.

See "[H09\\_en.06](#)" on page 219 for details.

See "[H09\\_en.07](#)" on page 219 for details.

See "[H09\\_en.08](#)" on page 220 for details.

See "[H09\\_en.09](#)" on page 220 for details.

### 3.2.2 Online Inertia Auto-tuning

The servo drive supports online inertia auto-tuning. The online inertia auto-tuning flowchart is shown as follows.




Figure 3-4 Online inertia auto-tuning flowchart

## Note

H09.03 defines the real-time updating speed of the load inertia ratio (H08.15).

- H09.03 = 1: Applicable to cases where the actual load inertia ratio rarely changes, such as the machine tool and wood carving machine.
- H09.03 = 2: Applicable to cases where the load inertia ratio changes slowly.
- H09.03 = 3: Applicable to cases where the actual inertia ratio changes rapidly, such as handling manipulators.

☆Related parameter

See "[H09\\_en.03](#)" on page 218 for details.

## 3.3 Auto Gain Tuning

### 3.3.1 ETune

#### Overview

ETune is a wizard-type auto-adjustment function used to guide users to set corresponding curve trajectories and response parameters. After the curve trajectories and response parameters are set, the servo drive performs auto-tuning automatically to generate the optimal gain parameters. The auto-tuned parameters can be saved and exported as a recipe for use in other devices of the same model. The ETune function is intended to be used in applications featuring slight load inertia change.

#### Description of ITune operation

- Operation flowchart




Figure 3-5 Operation flowchart

- **Detailed Description**

1. Click Usability adjustment in the software tool, and then click ETune.

Select the corresponding tuning mode based on different scenarios.

☐ STune

☒ ETune

**ETune**

Scenarios:  
a. Small inertia change  
b. Torque mode not supported

Before Tuning      After Tuning

2. Select any of the following three operation modes based on the operating direction allowed by the machine.

- In the Reciprocating po... mode, the motor keeps reciprocating within the positive and negative position limits.
- In the One-way forward mode, the motor takes the difference between the positive and negative position limits as the maximum distance per action and keeps running in the forward direction.
- In the One-way forward mode, the motor takes the difference between the positive and negative position limits as the maximum distance per action and keeps running in the reverse direction.

**Tuning-ETUNE**

Position setting
Param configuration
Tuning
Recipe storage

Operating mode setting

☒ Reciprocating positive and negative  
 ☐ One-way forward  
 ☐ One-way reversal

Limit position setting

JOG speed:  rpm  
 Acceleration and deceleration time:  ms

Enable ON

Set to positive limit position

1P command unit

Current position

Set to negative limit position

1P command unit


Note: Before starting, please set the positive and negative limits (JOG motion setting or manual setting), the limit range is larger than the motor 1/8 circle

<Previous
Next>>




- Designate the positive and negative limit positions allowed by the motor. The difference between the positive and negative limits defines the position reference pulses for the motor, which is also the value before multiplication/division by the electronic gear ratio.

You can set the positive and negative position limits through the following two methods.

- Method 1: Click "Enable ON", and then click  to make the motor move to the positive position limit. Next, click "Set to positive limit position". Follow the same procedure for setting the negative position limit, and click "Enable OFF" (the "Enable ON" button turns to "Enable OFF" after a click).
- Method 2: Enter the positive and negative limits directly.

## Note

The difference between the positive and negative position limits must be larger than 1/8 of one revolution. The larger the value of the limit position, the better the adaptability of the auto-tuned parameters, but the longer will ETune adjustment take.



- Click Next to switch to the mode parameter setting interface.

The adjustment mode is divided into Positioning mode and Track mode.

Auto-tuning of the inertia ratio is optional. If you choose not to perform inertia auto-tuning, set the correct inertia ratio (the inertia ratio can be

modified directly). You can adjust the response level and position filter time constant based on the responsiveness needed and the position reference noise generated during operation. Then configure the motion profile by setting the maximum speed, acceleration/deceleration time and interval time for auto-tuning.


The screenshot shows the 'Tuning-ETUNE' software window. At the top, there is a navigation bar with four steps: 'Position setting' (highlighted in green), 'Parameter configurat', 'Tuning', and 'Recipe storage'. Below this, the 'Position setting' section contains several configuration options:

- Adjustment mode:** Two radio buttons, 'Positioning mode' (selected) and 'Track mode'.
- Response mode:** Three radio buttons, 'High', 'Center' (selected), and 'Low'.
- Position filtering:** A text input field containing '0' followed by 'ms[0, 6553.5]'.
- Inertia ratio setting:** A checkbox labeled 'No inertia identification' is unchecked. Below it, 'Inertia' is set to '3' with a range '[0, 120]'.
- Running curve parameter:**
  - Maximum: '1000' rpm
  - Acceleration: '100' ms
  - Waiting: '300' ms


At the bottom of the window, there are two buttons: '<<Previous' and 'Next>>'.


5. Click "Next" to start auto-tuning.

- If you choose to perform inertia auto-tuning, the drive starts inertia auto-tuning based on the set motion profile. After inertia auto-tuning is done, the drive starts gain auto-tuning.
- If you choose not to perform inertia auto-tuning on the start page, the drive starts gain auto-tuning directly after start.



6. During gain auto-tuning, if you modify the Response fine-tuning coefficient and click "Update", gain auto-tuning will be continued based on the fine-tuning coefficient entered. After gain auto-tuning is done, you can click "Done" to save parameters to EEPROM and export parameters as a recipe file.





## Precautions

- You can adjust the maximum speed and acceleration/deceleration time of the motion profile based on actual conditions. The acceleration/deceleration time can be increased properly because positioning will be quickened after auto-tuning.
- If the acceleration/deceleration time is too short, overload may occur. In this case, increase the acceleration/deceleration time properly.
- For vertical axes, take anti-drop measures beforehand and set the stop mode upon fault to "Stop at zero speed".
- For lead screw transmission, shorten the travel distance if the tuning duration is too long.

## Solutions to Common Faults

Fault Symptom	Cause	Solution
E662.0: ETune error	During ETune operation, the gain drops to the lower limit: Position loop gain < 5. Speed loop gain < 5. Model loop gain < 10.	Set the notch manually when vibration cannot be suppressed automatically.
		Modify the electronic gear ratio to improve the command resolution, increase the command filter time constant or in the parameter configuration interface.
		Increase the value of H09.11 as appropriate.
		Check whether the current of the machine fluctuates periodically.
		Check whether the positioning threshold is too low. Increase the reference acceleration/deceleration time.
E600.0: Inertia auto-tuning failure	Vibration cannot be suppressed.	Enable vibration suppression manually and perform the ETune operation.
	The auto-tuned values fluctuate dramatically.	Increase the maximum operating speed and decrease the acceleration/deceleration time. For the lead screws, shorten the travel distance.
	Mechanical couplings of the load are loose or eccentric.	Rectify the mechanical faults.
	A warning occurs during auto-tuning and causes interruption.	Clear the fault and perform ETune again.
	The position reference filter time is set to an excessively high value.	Decrease the values of H05.04...H05.06 and perform ETune again.

### 3.3.2 STune

#### Overview

STune performs gain auto-tuning based on the set stiffness level to fulfill the needs for rapidity and stability.

STune (mode 4) is turned on by default and will be turned off automatically after the drive operates as commanded for 5 min.

STune is intended to be used in applications featuring slight load inertia change. For applications featuring dramatic inertia change or where inertia auto-tuning is unavailable (due to low operating speed or low acceleration rate), turn off STune after initial power-on.

---

## Note

In STune modes 3, 4 and 6, you need to perform load inertia auto-tuning through online inertia auto-tuning and ensure the following conditions are met:

- The load inertia changes quickly.
  - The load torque changes quickly.
  - The motor is running at a speed lower than 120 r/min.
  - Acceleration/Deceleration is slow (lower than 1000 r/min per second).
  - The acceleration/deceleration torque is lower than the unbalanced load/viscous friction torque.
- 

If the conditions for online inertia auto-tuning cannot be fulfilled, set the correct inertia ratio manually.

## Description of ITune operation

- **Operation flowchart**




Figure 3-6 Operation flowchart

## ● Detailed Description

You can set the gain auto-tuning mode through the keypad or the software tool.

### 1. Select the gain auto-tuning mode.

- In modes 0, 1 and 2 shown in the following table, you need to set the inertia ratio before stiffness tuning. If the inertia is unknown, adjust the inertia manually. If vibration occurs on the machine, decrease the stiffness level before adjusting the inertia manually.

- In modes 3, 4, and 6 shown in the following table, you can perform adjustment through the wizard-type interface directly, without the need for setting an inertia ratio.

Mode	Name	Description
0	Inactive	The gains need to be adjusted manually.
1	Standard stiffness level mode	Gains are set automatically based on the set stiffness level.
2	Positioning mode	Gains are set automatically based on the set stiffness level. This mode is applicable to occasions requiring quick positioning.
3	Interpolation mode + Inertia auto-tuning	Gains are set automatically based on the set stiffness level. In this mode, inertia is auto-tuned and vibration is suppressed automatically. This mode is applicable to multi-axis interpolation.
4	Normal mode + Inertia auto-tuning	Gains are set automatically based on the set stiffness level. The inertia is auto-tuned and vibration is suppressed automatically.
6	Quick positioning mode + Inertia auto-tuning	Gains are set automatically based on the set stiffness level. Inertia is auto-tuned and vibration is suppressed automatically. This mode is applicable to occasions requiring quick positioning.

2. Adjust the stiffness level gradually during operation of the load. The present stiffness level value will be written to the drive automatically. Keep monitoring the operating waveform after increasing the stiffness level (increase by one level at a time) until desired performance is achieved.
3. In STune modes 3, 4, and 6, when the speed keeps higher than 100 r/min for more than 5 min, H09.00 returns to 0 automatically. In this case, the drive will exit from the STune mode.

After tuning, you can set H09.00 to 0 to exit the STune mode.


To modify the STune time, set H09.37.

4. In STune modes 3, 4, and 6, resonance will be suppressed automatically. If the performance of automatic resonance suppression is inadequate, set H09.58 to 1 to clear resonance suppression parameters, reduce the stiffness level, and perform STune again.
5. For multi-axis trajectories, perform single-axis commissioning first to determine the highest response of each axis and modify the response of each axis manually to ensure position responses of different axes are consistent.

In STune modes 3 and 4, determine the minimum value of H08.-02 (Position loop gain). Then set H09.00 of each axis to 0 and set H08.02 of each axis to the same value.



In STune mode 6, determine the minimum value of H08.43 (Model gain). Then set H09.00 of each axis to 0, and set H08.43 of each axis to the same value.



## Note

To ensure a stable operation of STune modes 3 and 4, gain parameters will be adjusted along with the inertia ratio when the inertia ratio is higher than 13. In multi-axis trajectories, responses may be inconsistent under the same stiffness level.

## Precautions

### Load inertia ratio range

- In scenarios requiring high response, the inertia ratio must be lower than 500% and should not exceed 1000%.
  - For belt pulley or gear rack requiring not high rigidity and accuracy, the inertia ratio should not exceed 1000%.
  - For lead screw or cardan shaft requiring high rigidity and accuracy, the inertia ratio should not exceed 500%.
  - In scenarios where high positioning accuracy or response is required, the inertia ratio should not exceed 200%.
- In scenarios requiring a certain accuracy and dynamic response, the inertia ratio should not exceed 3000%.

- When the inertia ratio exceeds 3000%, it is hard to adjust and the trajectory control cannot be performed. It is only applicable to mechanisms for point-to-point control and rotary motion but the acceleration/deceleration time should be large.

### Rigidity meter setting

The setting range of H09.01 (Stiffness level selection) is 0–41. The level 0 indicates the weakest stiffness and lowest gain and level 41 indicates the strongest stiffness and highest gain.

The following table lists the stiffness levels for different load types for your reference.

Table 3–2 Reference of stiffness levels

Recommended Stiffness Level	Load Mechanisms
Level 8 to level 12	Large-scale machineries
Level 12 to level 18	Applications with low stiffness such as the conveyors
Above level 18	Applications with high stiffness such as the ball screws and direct-connected motors

The following five gain auto-tuning modes are available.

- Standard rigidity meter mode (H09.00 set to 1)  
The 1st gain parameters (H08.00 to H08.02 and H07.05) are automatically updated and saved based on the rigidity level set in H09.01.

Table 3–3 Parameters updated automatically in the standard mode

Parameter	Name
H08.00	Speed loop gain
H08.01	Speed loop integral time constant
H08.02	Position loop gain
H07.05	Filter time constant of torque reference

- Positioning mode (H09.00 = 2)  
Based on ["Table 3–3 " on page 93](#), the 2nd gain parameters (H08.03 to H08.05 and H07.06) are also automatically updated and saved based on the rigidity level set in H09.01. In addition, the position loop gain in the 2nd gain parameters has a higher rigidity level than that in the 1st gain parameters.

Table 3-4 Parameters updated automatically in the positioning mode

Parameter	Name	Description
H08.03	2nd speed loop gain	-
H08.04	2nd speed loop integral time constant	If H08.04 is set to remain at 512.00 ms, the 2nd speed loop integral action is invalid and only proportional control is used in the speed loop.
H08.05	2nd position loop gain	-
H07.06	2nd torque reference filter time constant	-

Values of speed feedforward parameters are fixed.

Table 3-5 Parameters with fixed values in the positioning mode

Parameter	Name
H08.19	Speed feedforward gain
H08.18	Speed feedforward filter time constant

Values of gain switchover parameters are fixed.

Gain switchover is activated automatically in the positioning mode.

Parameter	Name	Value	Description
H08.08	2nd gain mode	1	Switchover between the 1st gain set (H08.00...H08.02, H07.05) and 2nd gain set (H08.03...H08.05, H07.06) is active in the positioning mode. In other modes, the original setting is used.
H08.09	Gain switchover condition	10	In positioning mode, the gain switchover condition is that H08.09 is set to 10. In other modes, the original setting is used.
H08.10	Gain switchover delay	5.0ms	In positioning mode, the gain switchover delay is 5.0 ms. In other modes, the original setting is used.
H08.11	Gain switchover level	50	In the positioning mode, the gain switchover level is 50. In other modes, the original setting is used.
H08.12	Gain switchover hysteresis	30	In the positioning mode, the gain switchover dead time is 30. In other modes, the original setting is used.

---

## Note

In the gain auto-tuning mode, parameters updated along with H09.01 and those with fixed setpoints cannot be modified manually. To modify these parameters, set H09.00 (Gain auto-tuning mode) to 0 first.

---

- In STune mode 3, 4, or 6, resonance suppression will be performed automatically. When the load changes or the mechanical structure is re-installed, the system resonance frequency changes accordingly. Set H09.58 to 1 (Enable) and enable the STune mode again after clearing resonance suppression parameters.

See "[H08\\_en.37](#)" on page 210 for details.

See "[H08\\_en.38](#)" on page 210 for details.

See "[H08\\_en.39](#)" on page 211 for details.

See "[H09\\_en.18](#)" on page 223 for details.

See "[H09\\_en.19](#)" on page 223 for details.

See "[H09\\_en.20](#)" on page 223 for details.

See "[H09\\_en.21](#)" on page 223 for details.

See "[H09\\_en.22](#)" on page 224 for details.

See "[H09\\_en.23](#)" on page 224 for details.

See "[H09\\_en.58](#)" on page 230 for details.

---

## Note

- If H09.00 is set to 3, 4, or 6, the drive will suppress vibration and perform inertia auto-tuning automatically within 10 min (or other time defined by H09.37) after power-on or stiffness level setting, and then the drive exits from auto-tuning. If inertia auto-tuning is deactivated automatically, switching to modes 3, 4, or 6 will not activate inertia auto-tuning.
  - Do not set H09.00 to 3, 4, or 6 in applications with slow acceleration/deceleration, strong vibration, and unstable mechanical couplings.
  - In applications where the inertia does not change, set H09.03 (Online inertia auto-tuning mode) to 1 (Enabled, changing slowly). In applications where the inertia changes quickly, set H09.03 to 3 (Enabled, changing quickly).
- 

## Solutions to Common Faults

E661.0: STune error

When the torque fluctuation detected by the drive exceeds the setpoint of H09.11 and cannot be suppressed, the rigidity level will be reduced automatically until reaching level 10 where E661 is reported.

- Vibration cannot be suppressed. Enable vibration suppression manually.
- The current fluctuates. Check whether the current of the machine fluctuates periodically.

See "[H08\\_en.37](#)" on page 210 for details.

See "[H08\\_en.38](#)" on page 210 for details.

See "[H08\\_en.39](#)" on page 211 for details.

See "[H09\\_en.58](#)" on page 230 for details.

### 3.3.3 ITune

#### Overview

ITune serves to stabilize responsiveness through auto-tuning based on the device and load types.

ITune is intended to be used in applications featuring slight load inertia change or where inertia auto-tuning is unavailable.

#### Description of ITune operation

Step	Para.	Name	Description
1	H09.27	ITune mode	Function: Setting H09.27 to 1 enables the ITune function. Note: ITune mode 2 is manufacturer commissioning mode, which should be used with caution.
2	H09.28 H09.29	Minimum inertia ratio of ITune Maximum inertia ratio of ITune	Function: Used to adjust the inertia ratio range controlled by ITune. Adjustment method: The minimum and maximum inertia ratios of ITune are 0.0 and 30.0 by default. If the actual maximum load inertia ratio is higher than 30.0, increase the value of H09.29 to prevent positioning jitter. If the actual load inertia change range is small, set H09.28 and H09.29 based on actual conditions to achieve optimal control effect.

Step	Para.	Name	Description
3	H09.26	ITune response	Function: Used to adjust the response capacity of ITune. Note: If the response capacity of ITune cannot deliver desired effect, increase H08.20 properly. If resonance cannot be suppressed, decrease H08.26 properly.

See "[H09\\_en.18](#)" on page 223 for details.

See "[H09\\_en.19](#)" on page 223 for details.

See "[H09\\_en.20](#)" on page 223 for details.

See "[H09\\_en.21](#)" on page 223 for details.

See "[H09\\_en.22](#)" on page 224 for details.

See "[H09\\_en.23](#)" on page 224 for details.

See "[H09\\_en.24](#)" on page 224 for details.

See "[H09\\_en.27](#)" on page 225 for details.

See "[H09\\_en.28](#)" on page 225 for details.

See "[H09\\_en.29](#)" on page 225 for details.

## Precautions

After ITune is enabled, inertia auto-tuning and gain switchover will be inhibited.

## Solutions to Common Faults

Fault Symptom	Cause	Solution
E663.0: ITune error	Check whether resonance that occurred during ITune operation cannot be suppressed.	Set the notch manually when vibration cannot be suppressed automatically.
		Modify the electronic gear ratio to improve the command resolution, increase the command filter time constant or in the parameter configuration interface.
		Increase the value of H09.11 as appropriate.
		Check whether the current of the machine fluctuates periodically.

## 3.4 Manual Gain Tuning

### 3.4.1 Basic Parameters

When gain auto-tuning cannot fulfill the application needs, perform manual gain tuning. to achieve better result.

The servo system consists of three control loops, which are position loop, speed loop, and current loop from external to internal. The basic control diagram is shown in the following figure.




Figure 3-7 Basic control for manual gain tuning



### Note

The response level of the inner loop must be higher than that of the outer loop. If it is not observed, the system may be unstable.


The current loop gain has been set with the highest level of responsiveness by default, avoiding the need for adjustment. you only need to adjust the position loop gain, speed loop gain and other auxiliary gains. For gain tuning in the position control mode, the position loop gain must be increased together with the speed loop gain, and the responsiveness of the former must be lower than the latter.


The following table describes how to adjust the basic gain parameters.

Table 3-6 Adjustment of gain parameters

Step	Parameter	Name	Description
1	H08.00	Speed loop gain	<p>Function: Determines the maximum frequency of a variable speed reference that can be followed by the speed loop.</p> <p>When H08.15 (Load inertia ratio) is set correctly, the maximum frequency that can be followed by the speed loop is the setpoint of H08.00.</p>  <p>Note:</p> <ul style="list-style-type: none"> <li>Increasing the setpoint without incurring extra noise or vibration shortens the positioning time, stabilizes the speed, and improves the follow-up behavior.</li> <li>If noise occurs, decrease the setpoint.</li> <li>If mechanical vibration occurs, enable mechanical resonance suppression. For details, see "<a href="#">Vibration suppression</a>" on page 121.</li> </ul>
2	H08.01	Speed loop integral time constant	<p>Function: Eliminates the speed loop deviation.</p>  <p>Note:</p> <p>Set H08.01 according to the following formula: <math>500 \leq H08.00 \times H08.01 \leq 1000</math></p> <p>For example, if H08.00 is set to 40.0 Hz, the setpoint of H08.01 must meet the following requirement: <math>12.50 \text{ ms} \leq H08.01 \leq 25.00 \text{ ms}</math></p> <p>Decreasing the setpoint strengthens the integral action and shortens the positioning time, but an excessively low setpoint may easily lead to mechanical vibration. An excessively high setpoint prevents the speed loop deviation from being cleared.</p> <p>When H08.01 is set to 512.00 ms, the integral is invalid.</p>



Step	Parameter	Name	Description
3	H08.02	Position loop gain	<p>Function: It sets the position reference maximum frequency followed by the position loop. The maximum follow-up frequency of the position loop equals the value of H08.02.</p>  <p>Note: To ensure system stability, the maximum follow-up frequency of the speed loop must be 3 to 5 times higher than that of the position loop.</p> $3 \leq \frac{2 \times \pi \times H08.00}{H08.02} \leq 5$ <p>For example, when H08.00 is set to 40.0 Hz, H08.02 must meet the following requirement: 50.2 Hz ≤ H08.02 ≤ 83.7 Hz Adjust the setting based on the positioning time. Increasing the setpoint shortens the positioning time and improves the anti-interference capacity of a motor at standstill. An excessively high setpoint may easily lead to system instability and oscillation.</p>

Step	Parameter	Name	Description
4	H07.05	Torque reference filter time constant	<p>Function: Eliminates the high-frequency noise and suppresses mechanical resonance.</p>  <p>Note: Ensure the cutoff frequency of the torque reference low-pass filter is 4 times higher than the maximum follow-up frequency of the speed loop, as shown in the following formula:</p> $\frac{1000}{2 \times \pi \times H07.05} \geq (H08.00) \times 4$ <p>For example, when H08.00 is set to 40.0 Hz, the setpoint of H07.05 must be lower than or equal to 1.00 ms. If vibration occurs after H08.00 is increased, adjust H07.05 to suppress the vibration. For details, see "<a href="#">Vibration suppression</a>" on page 121. An excessively high setpoint weakens the responsiveness of the current loop. To suppress vibration upon stop, increase the setpoint of H08.00 and decrease the setpoint of H07.05. If strong vibration occurs upon stop, decrease the setpoint of H07.05.</p>

☆ Related parameters:

See "[H07\\_en.05](#)" on page 194 for details.

See "[H08\\_en.00](#)" on page 200 for details.

See "[H08\\_en.01](#)" on page 200 for details.

See "[H08\\_en.02](#)" on page 201 for details.

### 3.4.2 Gain Switchover

Gain switchover, which is active in the position control and speed control modes only, is only effective in position and speed control modes. achieve the following purposes:

- Switching to the lower gain when the motor is at a standstill (servo ON) to suppress vibration
- Switching to the higher gain when the motor is at a standstill to shorten the positioning time
- Switching to the higher gain during operation of the motor to achieve better reference tracking performance

- Switching between different gain settings through an external signal to fit different conditions of the load devices

### H08.08 = 0

When H08.08 is set to 0, the 1st gain (H08.00 to H08.02 and H07.05) is used, but you can switch between proportional control and proportional integral control through FunIN.3 (GAIN\_SEL, gain switchover) for the speed loop.




Figure 3-8 Gain switchover flowchart when H08.08 is set to 0

### H08.08 = 1

You can switch between the 1st gain set (H08.00...H08.02, H07.05) and 2nd gain set (H08.03...H08.05, H07.06) based on the condition defined by H08.09.







Figure 3-9 Gain switchover flowchart when H08.08 is set to 1

Table 3-8 shows diagrams and parameters for 11 kinds of gain switchover conditions. The following table describes the diagrams and related parameters of different conditions.

Table 3-7 Conditions for gain switchover

Gain Switchover Condition			Related Parameters		
H08.09 Setpoint	Condition	Diagram	Delay Time (H08.10)	Gain switchover level (H08.11)	Switchover Dead Time (H08.12)
0	Fixed to the 1st gain set	-	Inactive	Inactive	Inactive
1	External DI signal	-	Inactive	Inactive	Inactive
2	Torque reference		Active	Active (%)	Active (%)
3	Speed reference		Active	Active	Active
4	Speed reference change rate		Active	Active (10 rpm/s)	Active (10 rpm/s)
5	Speed reference high/low-speed threshold		Inactive	Active (rpm)	Active (rpm)
6	Position deviation		Active	Active (encoder unit)	Active (encoder unit)


Gain Switchover Condition			Related Parameters		
H08.09 Setpoint	Condition	Diagram	Delay Time (H08.10)	Gain switchover level (H08.11)	Switchover Dead Time (H08.12)
7	Position reference		Active	Inactive	Inactive
8	Positioning uncompleted		Active	Inactive	Inactive
9	Actual speed		Active	Active (rpm)	Active (rpm)
10	Position reference + Actual speed	See the following note for details.	Active	Active (rpm)	Active (rpm)



## Caution

H08.10 (Gain switchover delay) is valid only during switching to the 1st gain set.

## Note



☆ Related parameters:

See "H08\_en.08" on page 202 for details.

See "H08\_en.09" on page 202 for details.

See "H08\_en.10" on page 204 for details.

See "H08\_en.11" on page 205 for details.

See "H08\_en.12" on page 205 for details.

See "H08\_en.13" on page 205 for details.

### 3.4.3 Position Reference Filter

Name	Description	Applicable Occasion	Impact of Excessive Filtering
Position reference filter	Filters the position references (encoder unit) divided or multiplied by the electronic gear ratio to smoothen the operation process of the motor and reduce shock to the machine.	The acceleration/ deceleration process is not performed on the position references sent from the host controller. The electronic gear ratio is larger than 10.	The response delay is prolonged.

### 3.4.4 Feedforward gain

#### Speed feedforward




Figure 3-10 Operating procedure for speed feedforward control

Speed feedforward can be applied to the position control mode. The speed feedforward function can be used to improve the speed reference responsiveness and reduce the position deviation at fixed speed.

Operating procedure for speed feedforward:

1. Set the speed feedforward signal source.

Set H05.19 (Speed feedforward control) to a non-zero value to enable the speed feedforward function. The corresponding signal source will be selected as well.

Parameter	Name	Setpoint	Remarks
H05.19	Speed feedforward control	0: No speed feedforward	-
		1: Internal speed feedforward	Defines the speed corresponding to the position reference (encoder unit) as the speed feedforward signal source.
		2: 60B1h used as speed offset	-
		3: Zero phase control	-

## 2. Set speed feedforward parameters.

Set the speed feedforward gain (H08.19) and speed feedforward filter time constant (H08.18).

See "[H08\\_en.18](#)" on page 206 for details.

See "[H08\\_en.19](#)" on page 207 for details.

## Zero phase control

Zero phase control is used to compensate for the position deviation generated upon start delay of the position reference, reducing the position deviation upon start/stop in the position control mode.

The loop calculation model is shown in the following figure.




Figure 3-11 Zero phase control

See "[H05\\_en.04](#)" on page 170 for details.

See "[H05\\_en.19](#)" on page 173 for details.

See "[H08\\_en.17](#)" on page 206 for details.



# Torque feedforward




Figure 3-12 Operation diagram of torque feedforward control

In the position control mode, torque feedforward can be used to improve torque reference responsiveness and reduce the position deviation during operation at constant acceleration/deceleration rate.

In the speed control mode, torque feedforward can be used to improve speed reference responsiveness and reduce the speed deviation during operation at constant speed.

The procedure for setting torque feedforward is as follows:

1. Set the torque feedforward signal source.  
Set H06.11 (Torque feedforward control) to 1 to enable the torque feedforward function. The corresponding signal source will be selected as well.

Parameter	Name	Setpoint	Remarks
H06.11	Torque feedforward control	0: No torque feedforward	-
		1: Internal torque feedforward	Use the speed reference as the source of the torque feedforward signal. In the position control mode, the speed reference is outputted from the position controller.

2. Set torque feedforward parameters.

Parameter	Name	Description
H08.20	Torque feedforward filter time constant	<p>Function:</p> <ul style="list-style-type: none"> <li>Increasing the value of H08.21 improves the response but may cause overshoot during acceleration/deceleration.</li> <li>Decreasing the value of H08.20 suppresses overshoot during acceleration/deceleration. Increasing the value of H08.20 suppresses the noise.</li> </ul> <p>Note:</p> <ul style="list-style-type: none"> <li>Keep H08.20 to the default value, and then gradually increase the value of H08.21 from 0 to a certain value at which torque feedforward achieves the desired effect.</li> <li>Adjust H08.20 and H08.21 repeatedly until a balanced performance is achieved.</li> </ul>
H08.21	Torque feedforward gain	See this section for details.

### 3.4.5 PDFF Control

The pseudo derivative feedback and feedforward (PDFF) control can be used to adjust speed loop control in the non-torque control modes.




Figure 3-13 Example of PDF control

Through adjusting the speed loop control method, PDF control enhances the anti-disturbance capacity of the speed loop and improves the performance in following the speed references.

Param. No.	Name	Description
H08.24	PDF control coefficient	<p>Function:</p> <ul style="list-style-type: none"> <li>Defines the control method of the speed loop in the non-torque control modes.</li> </ul> <p>Note:</p> <ul style="list-style-type: none"> <li>Setting H08.24 to an excessively low value slows down the responsiveness of the speed loop.</li> <li>When the speed feedback overshoots, gradually decrease the setpoint of H08.24 from 100.0 to a certain value at which the PDF control achieves the desired effect.</li> <li>When H08.24 is set to 100.0, the speed loop control method does not change and the default proportional integral control is used.</li> </ul>


### 3.4.6 Torque disturbance observer

This function is intended to be used in the non-torque control modes.

#### Disturbance observer

The disturbance observer is used to observe external disturbance. You can set different cutoff frequencies and compensation values to observe and suppress the disturbance within the frequency range.

The following figure depicts the control block diagram for disturbance observer 1.



#### Note

1/s: Integral element

Parameter	Name	Description
H08.31	Disturbance cutoff frequency	The higher the cutoff frequency, the more easily will vibration occur.
H08.32	Disturbance compensation gain	Defines the compensation percentage for the observer.
H08.33	Disturbance observer inertia correction coefficient	H08.33 needs to be changed only when the inertia ratio does not reflect the actual condition. The acting inertia is the product of the set inertia and H08.33. It is recommended to use the default value of H08.33.

#### ☆Related parameters

See "[H08\\_en.31](#)" on page 209 for details.

See "[H08\\_en.32](#)" on page 210 for details.


See "[H08\\_en.33](#)" on page 210 for details.

### 3.4.7 Speed Observer


The speed observer, which facilitates quick positioning, applies in applications with slight load characteristic change and constant inertia.

It improves the responsiveness and filters high frequencies automatically, improving the gains and shortening the positioning time without incurring high-frequency vibration.

The block diagram for the speed observer is as follows.



### Commissioning Steps



### Related parameters

See " [H08\\_en.00](#)" on page 200 for details.

See " [H08\\_en.27](#)" on page 208 for details.

See " [H08\\_en.28](#)" on page 209 for details.

See " [H08\\_en.29](#)" on page 209 for details.

See " [H08\\_en.40](#)" on page 211 for details.

## Note

- Before using the speed observer, set H08.15 (Load inertia ratio) to a proper value or perform inertia auto-tuning. A wrong inertia ratio can cause vibration.
- Setting H08.27, H08.28, or H08.29 to excessively low or high values can result in motor vibration.

### 3.4.8 Model Tracking


The model tracking control, which is only available in the position control mode, can be used to improve responsiveness and shorten the positioning time. It is only available in the position control mode.

Parameters used by model tracking are normally set automatically through ITune or ETune along with the gain parameters.


However, manual tuning is needed in the following situations:

- The auto-tuned values cannot deliver desired performance.
- Improving the responsiveness takes priority over the auto-tuned or customized values.
- User-defined gain parameters or model tracking control parameters are needed.

The block diagram for model tracking control is as follows.



### Commissioning Steps



### Related parameters

See "[H07\\_en.05](#)" on [page 194](#) for details.

See "[H08\\_en.00](#)" on [page 200](#) for details.

See "[H08\\_en.01](#)" on [page 200](#) for details.

See "[H08\\_en.02](#)" on [page 201](#) for details.

See "[H08\\_en.42](#)" on [page 211](#) for details.



See "[H08\\_en.43](#)" on page 211 for details.

See "[H08\\_en.46](#)" on page 212 for details.

## Note

Ensure the set inertia is accurate. Otherwise, motor vibration may occur.

### 3.4.9 Friction Compensation

Friction compensation is used to reduce the impact of the friction on the operating effect during mechanical transmission. Use different positive/negative compensation values according to the direction of operation.

## Note

Friction compensation is effective only in the position mode.

#### ☆Related parameters

See "[H09\\_en.32](#)" on page 226 for details.


See "[H09\\_en.33](#)" on page 226 for details.

See "[H09\\_en.34](#)" on page 226 for details.

See "[H09\\_en.35](#)" on page 226 for details.

See "[H09\\_en.36](#)" on page 227 for details.

The diagram for friction compensation is as follows.



## Note

Note: When the speed is less than the speed threshold, static friction applies. When the speed exceeds the speed threshold, dynamic friction applies. The compensation direction is determined by the direction of the actual position reference. Forward direction requires positive compensation value. Reverse direction requires negative compensation value.

### 3.5 DSC Mode Adjustment

The DSC feature (dynamic servo control) moves the position loop calculation and interpolation to the servo drive through telegram 105, and uses the servo fast speed control clock to improve positioning quality and performance. SV660F H01.00 = 802.8 and above support the DSC feature. You can select the DSC function by modifying the value of H24.32.

Table 3–8 DSC function selection

Parameter	Data	Description
H24.32	1	PLC position loop gain
	3	DSC manual adjustment

## Note

When  $H24.32 \neq 0$  (that is, in DSC mode), direct adjustment of parameter H09.00 is prohibited, otherwise there is a risk of injury or damage to the product!

- **PLC adjustment (H24.32 = 1)**

Dynamically adjusts the servo gain parameters by adjusting the pre-control and gain parameters of the PLC. When the servo is in non-STune mode, H09.00 must not be modified!




Figure 3-14 PLC side gain adjustment

- **Manual adjustment (H24.32 = 3)**  
The servo gain parameter can be manually adjusted.

### 3.6 Parameter Adjustment in Different Control Modes

Perform parameter adjustment in the sequence of "Inertia auto-tuning" => "Gain auto-tuning => "Manual gain tuning" in all the control modes.

#### 3.6.1 Parameter Adjustment in the Position Control Mode

Obtain the value of H08.15 (Load inertia ratio) through inertia auto-tuning.  
Gain parameters in the position control mode are listed in the following tables.

- 1st gain set:

Parameter	Name	Function	Default
H07.05	Torque reference filter time constant 1	Defines the torque reference filter time constant.	0.50 ms
H08.00	Speed loop gain	Defines the speed loop proportional gain.	40.0 Hz
H08.01	Speed loop integral time constant	Defines the integral time constant of the speed loop.	19.89 ms
H08.02	Position loop gain	Defines the position loop proportional gain.	64.0 Hz

- 2nd gain set:

Parameter	Name	Function	Default
H07.06	Torque reference filter time constant 2	Defines the torque reference filter time constant.	0.27 ms
H08.03	2nd speed loop gain	Defines the speed loop proportional gain.	75.0 Hz
H08.04	2nd speed loop integral time constant	Defines the integral time constant of the speed loop.	10.61 ms
H08.05	2nd position loop gain	Defines the position loop proportional gain.	120.0 ms
H08.08	2nd gain mode setting	Defines the mode of the 2nd gain set.	1
H08.09	Gain switchover condition	Defines the gain switchover condition.	0
H08.10	Gain switchover delay	Defines the gain switchover delay.	5.0 ms
H08.11	Gain switchover level	Defines the gain switchover level.	50
H08.12	Gain switchover dead time	Defines the dead time of gain switchover.	30
H08.13	Position gain switchover time	Defines the position loop gain switchover time.	3.0 ms

- Common gain set

Parameter	Name	Function	Default
H08.18	Speed feedforward filter time constant	Defines the filter time constant of the speed feedforward signal.	0.50 ms
H08.19	Speed feedforward gain	Defines the speed feedforward gain.	0.0%
H08.20	Torque feedforward filter time constant	Defines the filter time constant of the torque feedforward signal.	0.50 ms
H08.21	Torque feedforward gain	Defines the torque feedforward gain.	0.0%
H08.22	Speed feedback filtering option	Defines the speed feedback filtering function.	0
H08.23	Cutoff frequency of speed feedback low-pass filter	Defines the cutoff frequency of the first-order low-pass filter for speed feedback.	8000 Hz
H08.24	PDFF control coefficient	Defines the coefficient of the PDFF controller.	100.0%

Parameter	Name	Function	Default
H09.30	Torque disturbance compensation gain	Defines the torque disturbance compensation gain.	0.0%
H09.31	Filter time constant of torque disturbance observer	Defines the filter time constant of the disturbance observer.	0.5 ms
H09.04	Low-frequency resonance suppression mode	Defines the low-frequency resonance suppression mode.	0
H09.38	Frequency of low-frequency resonance suppression 1 at the mechanical end	Defines the frequency of the low-frequency resonance suppression filter.	100.0 Hz
H09.39	Low-frequency resonance suppression 1 at the mechanical end	Defines the setting of low-frequency resonance suppression filter.	2

Perform gain auto-tuning to get the initial values of the 1st gain set (or 2nd gain set) and the common gain set.

Fine-tune the following gains manually.

Parameter	Name	Function	Default
H07.05	Torque reference filter time constant 1	Defines the torque reference filter time constant.	0.50 ms
H08.00	Speed loop gain	Defines the speed loop proportional gain.	40.0 Hz
H08.01	Speed loop integral time constant	Defines the integral time constant of the speed loop.	19.89 ms
H08.02	Position loop gain	Defines the position loop proportional gain.	64.0 Hz
H08.19	Speed feedforward gain	Defines the speed feedforward gain.	0.0%

### 3.6.2 Parameter Adjustment in the Speed Control Mode

Parameter adjustment in the speed control mode is the same as that in the position control mode, except for the position loop gain (H08.02 and H08.05). For details, see ["3.6.1 Parameter Adjustment in the Position Control Mode" on page 118](#).


### 3.6.3 Parameter Adjustment in the Torque Control Mode

Parameter adjustment in the torque control mode are differentiated based on the following conditions:

- If the actual speed reaches the speed limit, the adjustment method is the same as that described in ["3.6.2 Parameter Adjustment in the Speed Control Mode" on page 120](#).
- If the actual speed does not reach the speed limit, the adjustment method is the same as that described in ["3.6.2 Parameter Adjustment in the Speed Control Mode" on page 120](#), except the position/speed loop gain and speed loop integral time constant.

## 3.7 Vibration suppression

The block diagram for vibration suppression is as follows.



Where:

- NTF1–4: 1st notch to 4th notch
- VIBSUP3: Suppression of medium- and low-frequency vibration reduction applied at a carrier frequency lower than 8 k under 300 Hz
- 1/s: Integral element

☆ Related parameters:

See ["H08\\_en.53" on page 212](#) for details.

See ["H08\\_en.54" on page 212](#) for details.

See ["H08\\_en.56" on page 213](#) for details.

---

## Note

- jitter suppression phase modulation coefficient: synchronous phase adjustment of the compensation value and vibration. It is recommended to use the default value. Adjustment is needed when the compensation value phase differs greatly from the vibration phase.
  - Jitter suppression frequency: Defines the jitter frequency that needs to be suppressed.
  - Jitter suppression compensation coefficient: Defines the compensation coefficient for jitter suppression.
- 

### 3.7.1 Low-Frequency Resonance Suppression at the Mechanical End




Figure 3-15 Low-frequency vibration at the mechanical end

If the mechanical load end is long and heavy, vibration may easily occur in this part during emergency stop, affecting the positioning effect. Such vibration is called low-frequency resonance as its frequency is generally within 100 Hz, which is lower than the mechanical resonance frequency mentioned in ["3.7.2 Mechanical Resonance Suppression" on page 124](#). Use the low-frequency resonance suppression function to reduce such vibration.




Figure 3-16 Procedure for setting low-frequency resonance suppression filter

First, use the oscilloscope function in the software tool to collect the position deviation waveform of the motor in the positioning state. Then calculate the position deviation fluctuation frequency, which is the low-frequency resonance frequency. Finally, input the value of H09.38 manually and use the default value of H09.39. Observe the resonance suppression effect after using the low-frequency resonance suppression filter.




Figure 3-17 Low-frequency resonance suppression effect

☆ Related parameters:

See "[H09\\_en.38](#)" on [page 227](#) for details.

See "[H09\\_en.39](#)" on [page 228](#) for details.

See "[H09\\_en.44](#)" on [page 228](#) for details.

See "[H09\\_en.45](#)" on [page 228](#) for details.



See "[H09\\_en.47" on page 229](#) for details.

See "[H09\\_en.49" on page 229](#) for details.

See "[H09\\_en.50" on page 229](#) for details.

See "[H09\\_en.52" on page 229](#) for details.

### 3.7.2 Mechanical Resonance Suppression

Resonance frequency is present in the mechanical system. When the gain of the drive increases, resonance may occur near the resonance frequency, disabling further increase of the gain.

Mechanical resonance can be suppressed in the following two methods:

#### Torque reference filter (H07.05, H07.06)

To suppress the mechanical resonance, set the filter time constant to enable the torque reference to be attenuated in the frequency range above the cutoff frequency.

Filter cutoff frequency  $f_c$  (Hz) =  $1/[2\pi \times H07.05 \text{ (ms)} \times 0.001]$

#### Notch

The notch reduces the gain at certain frequencies to suppress mechanical resonance. After the vibration is suppressed by the notch, you can continue to increase the gain. The operating principle of the notch is shown in the following figure.




Figure 3-18 Operating principle of the notch

A total of four notches can be used, and each notch is defined by three parameters: frequency, width level, and depth level. The 1st and 2nd notches are manual notches whose parameters need to be set by the user. Parameters of the 3rd and 4th notches can be either set by the user or set automatically after being configured as an adaptive notch (H09.02 = 1 or 2).

Table 3-9 Description of notch parameters

Item	Manual Notch		Manual/Adaptive Notch	
	1st Notch	2nd Notch	3rd Notch	4th Notch
Frequency	H09.12	H09.15	H09.18	H09.21
Width level	H09.13	H09.16	H09.19	H09.22
Depth level	H09.14	H09.17	H09.20	H09.23

## Note

- When the frequency is 8000 Hz (default), the notch is inactive.
- The adaptive notch is preferred for resonance suppression. The manual notch can be used in cases where the adaptive notch cannot deliver desired performance.




Figure 3-19 Using the notch

- Procedure for setting the adaptive notch:
  1. Set H09.02 (Adaptive notch mode selection) to 1 or 2 based on the number of resonance frequencies.
  2. When resonance occurs, set H09.02 to 1 first to enable one adaptive notch. If new resonance occurs after gain adjustment, set H09.02 to 2 to enable two adaptive notches.

- Parameters of the 3rd or 4th notches are updated automatically during operation, and parameter values are saved automatically to the corresponding parameters in group H09 every 30 min.
- If resonance is suppressed, the adaptive notch works. After the servo drive runs stably for a period of time, set H09.02 to 0 and the parameters of the adaptive notch are fixed to the last updated values.

This is to prevent notch parameters from being updated to wrong values due to misoperation. Wrong values will intensify resonance.

- If resonance persists after the notch is working for a period of time, switch off the S-ON signal.
- If there are more than two resonance frequencies, the problem cannot be solved by only using the adaptive notches. In this case, add a manual notch, Additionally use the manual notch, or use all the four notches as manual ones (H09.02 = 0).

---

## Note

- When adaptive notch is applied, if the S-OFF signal is activated within 30 min, the notch parameters will not be saved to the corresponding parameter
  - When the resonance frequency is below 300 Hz, the suppression effect of the adaptive notch may be degraded.
- 
- Procedure for setting the manual notch:
    - Analyze the resonance frequency.
    - When using the manual notch, set the notch frequency to same value as the actual resonance frequency obtained in the following ways: The resonance frequency can be obtained by using the following methods:
      - Use the "Mechanical characteristic analysis" function in Inovance software tool.
      - Calculate the resonance frequency based on the motor phase current displayed on the oscilloscope interface of the software tool.
      - Set H09.02 (Adaptive notch mode) to 3. The drive detects the resonance frequency and saves the detected value to H09.24 automatically during operation.
    - Input the resonance frequency obtained in step 1 to the parameter of the selected notch, and input the width level and depth level of this notch.
    - If resonance has been suppressed, it indicates the notch functions well and you can continue adjusting the gain. If resonance occurs again, repeat steps 1 and 2.
    - If resonance persists after the notch is working for a period of time, switch off the S-ON signal.

- Notch width level

The width level indicates the ratio of the notch width to the center frequency of the notch.

$$\text{Notch width level} = \frac{f_H - f_L}{f_T}$$

Where:

$f_T$ : center frequency of the notch, which is also the mechanical resonance frequency

$f_H - f_L$  is the notch width, that is, the frequency bandwidth with an amplitude attenuation rate of  $-3$  dB relative to the notch central frequency.

The following figure shows the correspondence. Use the default value 2 in normal cases.

- Depth level of the notch

The notch depth level indicates the ratio of the input to the output at the center frequency.

When the depth level is 0, the input is completely suppressed at the center frequency. When the depth level is 100, the input can be fully passed at the center frequency. Therefore, the lower the depth level is, the higher the notch depth is, and the stronger the suppression effect will be. Note that an excessively low depth level may lead to system oscillation.

---

## Note

If the amplitude frequency characteristic curve obtained through the mechanical analysis function does not have obvious peak, it indicates that vibration occurs actually. Such vibration may not be mechanical resonance, and cannot be suppressed by the notch. It occurs because the gain reaches the limit, and can be suppressed only by reducing the gain or the filter time of torque reference.

---

The following figure shows the frequency characteristics of the notch.




Figure 3-20 Notch frequency characteristics

☆ Related parameters:

See "[H09\\_en.02](#)" on [page 218](#) for details.

See "[H09\\_en.12](#)" on [page 221](#) for details.

See "[H09\\_en.13](#)" on [page 221](#) for details.

See "[H09\\_en.14](#)" on [page 221](#) for details.

See "[H09\\_en.15](#)" on [page 222](#) for details.

See "[H09\\_en.16](#)" on [page 222](#) for details.

See "[H09\\_en.17](#)" on [page 222](#) for details.

See "[H09\\_en.18](#)" on [page 223](#) for details.

See "[H09\\_en.19](#)" on [page 223](#) for details.

See "[H09\\_en.20](#)" on [page 223](#) for details.

See "[H09\\_en.21](#)" on [page 223](#) for details.

See "[H09\\_en.22](#)" on [page 224](#) for details.

See "[H09\\_en.23](#)" on [page 224](#) for details.

See "[H09\\_en.24](#)" on [page 224](#) for details.

### 3.8 Mechanical Characteristic Analysis

#### Overview

Mechanical characteristic analysis is used to determine the mechanical resonance point and system bandwidth. Up to 8 kHz response characteristic analysis is available and three modes including mechanical characteristics, speed open loop, and speed closed loop are supported.

#### Operating Procedure




Figure 3-21 Operating procedure for mechanical characteristic analysis

## Note

- To avoid large vibration during the test, set the current excitation to 10% during initial execution.
- The analysis waveform may be distorted if the current excitation is too low.
- If the vibration generated during test cannot be suppressed after reducing the current excitation, the possible causes and solutions may be: 1) The gain is too high, reduce the speed gain or set the notch based on the auto-tuned resonance point. 2) The set inertia is too high, set the correct inertia.
- After setting the notch, the waveform under mechanical characteristic test mode is the same with that before the setting, but the speed closed loop and speed open loop modes will be attenuated.




Figure 3-22 Example of the waveform obtained

An example of the waveform obtained with the mechanical characteristic analysis is shown in ["Figure 3-22 Example of the waveform obtained" on page 131](#).



## 4 Description of Parameters

### 4.1 H00 Servo Motor Parameters

#### H00.00 Motor SN

Address: 0x0000

Effective Upon the next power-on

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 14101

Change: At stop

##### **Value Range:**

0 to 65535

##### **Description**

Defines the code of the servo motor. Fixed to 14XXX. Setting the motor code to a wrong value will result in E120.0 (Unknown motor model).

#### H00.02 Customized No.

Address: 0x0002

Effective -

mode:

Min.: 0.00

Unit: -

Max.: 4294967295.00

Data Type: UInt32

Default: 0.00

Change: Unchangeable

##### **Value Range:**

0.00 to 4294967295.00

##### **Description**

Displays customized software code in hexadecimal.

The display format is: XXX.YY.

XXX: Fixed No. for customized software

YY: Upgrade record No. for customized software

#### H00.04 Encoder version

Address: 0x0004

Effective -

mode:

Min.: 0.0

Unit: -

Max.: 6553.5

Data type: UInt16

Default: 0.0

Change: Unchangeable

##### **Value Range:**

0.0 to 6553.5

##### **Description**

Displays the software version number of the encoder.

The display format is 2XXX.Y.

**H00.05 Serial-type motor code**

Address: 0x0005

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

Displays the code of the serial-type motor, which is determined by the motor model and changeable.

**H00.06 FPGA customized SN**

Address: 0x0006

Effective mode: -

Min.: 0.00

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 0.00

Change: Unchangeable

**Value Range:**

0.00 to 655.35

**Description**

-

**H00.07 STO version**

Address: 0x0007

Effective mode: -

Min.: 0.0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0 to 6553.5

**Description**

-

**H00.08 Bus encoder type**

Address: 0x0008

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 65535

**Description**

-

## 4.2 H01 Servo Drive Parameters

**H01.00 MCU software version**

Address: 0x0100

Effective -

mode:

Unit: -

Min.: 0.0

Max.: 6553.5

Data type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0 to 6553.5

**Description**

Displays the MCU software version.

The display format is XXXX.Y, with one decimal place.

**H01.01 FPGA software version**

Address: 0x0101

Effective -

mode:

Unit: -

Min.: 0.0

Max.: 6553.5

Data type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0 to 6553.5

**Description**

It displays the FPGA firmware version.

The display format is XXXX.Y, with one decimal place.

**H01.02 Servo drive series No.**

Address: 0x0102

Effective -

mode:

Unit: -

Min.: 0

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H01.08 Model parameter version 1**

Address: 0x0108

Min.: 0.0

Max.: 6553.5

Default: 0.0

**Value Range:**

0.0 to 6553.5

**Description**

-

Effective mode:

Unit: -

Data Type: UInt16

Change: Unchangeable

**H01.09 Model parameter version 2**

Address: 0x0109

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode:

Unit: -

Data Type: UInt16

Change: Unchangeable

**H01.10 Drive series No.**

Address: 0x010A

Min.: 0

Max.: 65535

Default: 3

**Value Range:**

Effective mode: Upon the next power-on

Unit: -

Data Type: UInt16

Change: At stop

2: S1R6  
3: S2R8  
5: S5R5  
60005: S6R6  
6: S7R6  
7: S012  
8: S018  
9: S022  
10: S027  
10001: T3R5  
10002: T5R4  
10003: T8R4  
10004: T012  
10005: T017  
10006: T021  
10007: T026

**Description**

Defines the servo drive model.

Drive models are listed in the following table. If the voltage input to the main circuit of the servo drive does not comply with the preceding specifications, E420.0 (Main circuit phase loss) occurs.

The main circuit of the servo drive supports single-phase 220 V power supplies without derating.

**H01.11 DC-AC voltage class**

Address: 0x010B

Effective mode: -  
Unit: V  
Data Type: UInt16  
Change: Unchangeable

Min.: 0  
Max.: 65535  
Default: 220

**Value Range:**

0V to 65535V

**Description**

-

**H01.12 Drive rated power**

Address: 0x010C

Effective mode: -  
Unit: kW  
Data type: UInt32  
Change: Unchangeable

Min.: 0.00  
Max.: 10737418.24  
Default: 0.40

**Value Range:**

0.00 kW–10737418.24 kW

**Description**

-

**H01.14 Max. output power of the drive**

Address: 0x010E

Effective  
mode: -

Min.: 0.00

Unit: kW

Max.: 10737418.24

Data type: UInt32

Default: 0.40

Change: Unchangeable

**Value Range:**

0.00 kW–10737418.24 kW

**Description**

-

**H01.16 Rated output current of the drive**

Address: 0x0110

Effective  
mode: -

Min.: 0.00

Unit: A

Max.: 10737418.24

Data Type: UInt32

Default: 2.80

Change: Unchangeable

**Value Range:**

0.00A to 10737418.24A

**Description**

-

**H01.18 Max. output current of the drive**

Address: 0x0112

Effective  
mode: -

Min.: 0.00

Unit: A

Max.: 10737418.24

Data Type: UInt32

Default: 10.10

Change: Unchangeable

**Value Range:**

0.00A to 10737418.24A

**Description**

-

**H01.40 DC bus overvoltage protection threshold**

Address: 0x0128

Effective  
mode: -

Min.: 0

Unit: V

Max.: 2000

Default: 420

**Value Range:**

0V to 2000V

**Description**

-

Data Type: UInt16

Change: Immediately

#### **H01.75 Current loop amplification factor**

Address: 0x014B

Effective mode: Real time

Min.: 0.00

Unit: -

Max.: 655.35

Data Type: UInt16

Default: 1.00

Change: Immediately

**Value Range:**

0.00 to 655.35

**Description**

-

#### **H01.88 Junction temperature parameter version 1**

Address: 0x0158

Effective mode: -

Min.: 0.0

Unit: -

Max.: 6553.5

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0 to 6553.5

**Description**

-

#### **H01.89 Junction temperature parameter version 2**

Address: 0x0159

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

### 4.3 H02 Basic Control Parameters

#### H02.00 Control mode

Address: 0x0200

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: At stop

Min.: 0

Max.: 11

Default: 11

##### Value Range:

0: Speed control mode

1: Position control mode

2: Torque control mode

3: Torque<->Speed control mode

4: Speed<->Position control mode

5: Torque<->Position control mode

6: Torque<->Speed<->Position compound mode

11: PN communication mode

##### Description

Defines the control mode of the servo drive.

#### H02.01 Absolute system selection

Address: 0x0201

Effective mode: Upon the next power-on  
Unit: -  
Data Type: UInt16  
Change: At stop

Min.: 0

Max.: 5

Default: 0

##### Value Range:

0: Incremental mode

1: Absolute position linear mode

2: Absolute position rotation mode

3: Absolute position linear mode (without encoder overflow warning)

4: Absolute position single-turn mode

5: Absolute position rotational mode, modal axis single modal revolution absolute command

##### Description

Defines the mode of the absolute system.

#### H02.02 Rotation direction selection

Address: 0x0202

Effective mode: Upon the next power-on  
Unit: -  
Data Type: UInt16

Min.: 0

Max.: 1



Default: 0

Change: At stop

**Value Range:**


0: Counterclockwise (CCW) as forward direction

1: Clockwise (CW) as forward direction

**Description**

Defines the forward direction of the motor when viewed from the motor shaft side.

Setpoint	Rotating direction	Remarks
0	Counterclockwise (CCW) as forward direction	Defines the CCW direction as the forward direction when a forward run command is received, indicating the motor rotates in the CCW direction when viewed from the motor shaft side.
1	Counterclockwise (CW) as forward direction	When a forward command is input, the motor rotates in CW direction viewed from the motor shaft side, that is, the motor rotates clockwise.



**H02.03 Output pulse phase**

Address: 0x0203

Effective mode: Upon the next power-on

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop



**Value Range:**

0: Phase A leads phase B

1: Phase A lags behind phase B

### Description

Defines the relationship between phase A and phase B on the condition that the motor direction of rotation remains unchanged when pulse output is enabled.

Setpoint	Output pulse phase	Remarks
0	Phase A leads phase B.	Phase A leads phase B by 90° in encoder frequency-division output pulses. 
1	Phase A lags phase B.	Phase A lags phase B by 90° in encoder frequency-division output pulses. 

### H02.05 Stop mode at S-ON OFF

Address: 0x0205

Effective mode: At stop

Min.: -5

Unit: -

Max.: 3

Data Type: Int16

Default: 3

Change: Real-time

#### Value Range:

-5: Stop in PN communication state (ramp-to-stop/quick stop/coast-to-stop), keeping dynamic braking state

-4: Stop based on ramp 2, keeping dynamic braking state

-3: Stop at zero speed, keeping dynamic braking state

-2: Stop based on ramp 1, keeping dynamic braking state

-1: Dynamic braking stop, keeping dynamic braking state

0: Coast to stop, keeping de-energized state

1: Stop based on ramp 1, keeping de-energized state

2: Dynamic braking stop, keeping de-energized state

3: Stop in PN communication state (ramp-to-stop/quick stop/coast-to-stop), keeping de-energized state

### Description

Defines the deceleration mode of the motor for stopping rotating upon S-ON OFF and the motor status after stop.

Set a proper stop mode according to the mechanical status and operation requirements.

**H02.06 Stop mode at No.2 fault**

Address: 0x0206	Effective mode:	At stop
Min.: -5	Unit:	-
Max.: 3	Data Type:	Int16
Default: 2	Change:	Real-time

**Value Range:**

- 5: Stop at zero speed, keeping dynamic braking state
- 4: Stop at emergency stop torque, keeping dynamic braking state
- 3: Stop based on ramp 2, keeping dynamic braking state
- 2: Stop based on ramp 1, keeping dynamic braking state
- 1: Dynamic braking stop, keeping dynamic braking state
- 0: Coast to stop, keeping de-energized state
- 1: Stop based on ramp 1, keeping de-energized state
- 2: Stop based on ramp 2, keeping de-energized state
- 3: Stop at emergency stop torque, keeping de-energized state
- 4: Dynamic braking stop, keeping de-energized state

**Description**

Defines the deceleration mode of the motor for stopping rotating upon occurrence of a No. 2 fault and the motor status after stop.  
After the brake (BK) output function is enabled, the stop mode at No. 2 fault is forcibly set to "Ramp to stop as defined by 6085h, keeping dynamic braking status".

**H02.07 Stop mode at overtravel**

Address: 0x0207	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 8	Data Type:	UInt16
Default: 8	Change:	Real-time

**Value Range:**

- 0: Coast to stop, keeping de-energized state
- 1: Stop at zero speed, keeping position lock state
- 2: Stop at zero speed, keeping de-energized state
- 3: Stop based on ramp 2, keeping de-energized state
- 4: Stop based on ramp 2, keeping position lock state
- 5: Dynamic braking stop, keeping de-energized state
- 6: Dynamic braking stop, keeping dynamic braking state
- 7: Not responding to overtravel

**Description**

Defines the deceleration mode of the motor for stopping rotating upon overtravel and the motor status after stop.

When the servo motor drives vertical axis, your setting must make the motor axis in position locking state after the limit switch signal is active to ensure safety.

**H02.08 Stop mode at No.1 fault**

Address:	0x0208	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	2	Change:	Real-time

**Value Range:**

0: Coast to stop, keeping de-energized state

1: Dynamic braking stop, keeping de-energized state

2: Dynamic braking stop, keeping dynamic braking state

**Description**

Defines the deceleration mode of the motor for stopping rotating when a No. 1 fault occurs and the motor status after stop.

For details on No. 1 faults, see the Troubleshooting Guide.

**H02.09 Delay from brake output ON to command received**

Address:	0x0209	Effective mode:	Real time
Min.:	0	Unit:	ms
Max.:	500	Data Type:	UInt16
Default:	250	Change:	Real-time

**Value Range:**

0 ms to 500 ms

**Description**

Defines the delay from the moment the brake (BK) output signal is ON to the moment the servo drive starts to receive commands after power-on.

**H02.10 Delay from brake output OFF to motor de-energized**

Address:	0x020A	Effective mode:	Real time
Min.:	50	Unit:	ms
Max.:	1000	Data Type:	UInt16
Default:	150	Change:	Real-time

**Value Range:**

50 ms to 1000 ms

**Description**

Defines the delay from the moment brake (BK) output is OFF to the moment when the motor at standstill enters the de-energized status.

**H02.11 Motor speed threshold at brake output OFF in rotation state**

Address:	0x020B	Effective mode:	Real time
Min.:	20	Unit:	RPM
Max.:	3000	Data Type:	UInt16
Default:	30	Change:	Real-time

**Value Range:**

20 rpm to 3000 rpm

**Description**

Defines the motor speed threshold when brake (BK) output is OFF in the rotation state.

**H02.12 Delay from S-ON OFF to brake output OFF in rotation state**

Address:	0x020C	Effective mode:	Real time
Min.:	1	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	500	Change:	Real-time

**Value Range:**

1 ms to 65535 ms

**Description**

Defines the delay from the moment the S-ON signal is OFF to the moment the brake (BK) output is OFF in the rotation state.

**H02.15 LED warning display**

Address:	0x020F	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

0: Output warning information immediately

1: Not output warning information

**Description**

Defines whether to switch the keypad to the fault display mode when a No. 3 fault occurs.

For details on No. 3 Warnings, see the Troubleshooting Guide.

**H02.17 Stop mode upon main circuit power failure**

Address: 0x0211	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 3	Data Type:	UInt16
Default: 2	Change:	Real-time

**Value Range:**

- 0: Keep current action
- 1: Stop upon fault as defined by H0206
- 2: Stop at S-ON OFF as defined by H0205
- 3: Stop quickly as defined by H0218

**Description**

-

**H02.18 DI emergency stop mode selection**

Address: 0x0212	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 3	Data Type:	UInt16
Default: 2	Change:	Real-time

**Value Range:**

- 0: Coast to stop, keeping de-energized state
- 1: Ramp 1 stop, keeping de-energized state
- 2: Ramp 2 stop, keeping de-energized stat
- 3: Stop at emergency stop torque, keeping de-energized state

**Description**

-

**H02.21 Permissible minimum resistance of regenerative resistor**

Address: 0x0215	Effective mode:	-
Min.: 1	Unit:	Ω
Max.: 1000	Data Type:	UInt16
Default: 40	Change:	Unchangeable

**Value Range:**

1Ω to 1000 Ω

**Description**

The permissible minimum resistance of the regenerative resistor is only related to the servo drive model.

**H02.22    Power of built-in regenerative resistor**

Address:	0x0216	Effective	-
		mode:	
Min.:	0	Unit:	W
Max.:	65535	Data Type:	UInt16
Default:	50	Change:	Unchangeable

**Value Range:**

0 W–65535 W

**Description**

The power of the built-in regenerative resistor is only related to the servo drive model, which is unmodifiable.

**H02.23    Resistance of built-in regenerative resistor**

Address:	0x0217	Effective	-
		mode:	
Min.:	0	Unit:	Ω
Max.:	65535	Data Type:	UInt16
Default:	50	Change:	Unchangeable

**Value Range:**

0Ω to 65535Ω

### Description

The resistance of the built-in braking resistor is only related to the servo drive model, which is unmodifiable.

The built-in braking resistor comes into rescue when the maximum braking energy calculated exceeds the absorption capacity of the capacitor.

When using the built-in braking resistor, connect a jumper bar between terminals P and D. When H01-02 (servo drive No.) = 2 or 3, there is no built-in braking resistor.

Table 4-1 Specifications of the regenerative resistor

Servo Drive Model	Specifications of Built-in Regenerative Resistor		External regenerative resistor Min. Allowable Resistance ( $\Omega$ ) (H02.21)
	Resistance ( $\Omega$ )	Power (Pr) (W)	
SV660FS1R6I	-	-	50
SV660FS2R8I	-	-	45
SV660FS5R5I	50	50	40
SV660FS7R6I	25	80	20
SV660FS012I			15
SV660FT3R5I	100	80	80
SV660FT5R4I	100	80	60
SV660FT8R4I	50	80	45
SV660FT012I			40
SV660FT017I	35	100	35
SV660FT021I			25
SV660FT026I			

### H02.24 Resistor heat dissipation coefficient

Address: 0x0218

Effective mode:

Real time

Min.: 10

Unit: %

Max.: 100

Data Type: UInt16

Default: 30

Change: Real-time

#### Value Range:

10%–100%

#### Description

Defines the heat dissipation coefficient of the regenerative resistor, which is applicable to both external and built-in regenerative resistors.

Set this parameter properly according to actual heat dissipation conditions of the resistor (heat dissipation coefficient).

Recommendations:

- Generally, the coefficient cannot exceed 30% for natural cooling.
- It cannot exceed 50% for forced air cooling.



**H02.25 Regenerative resistor type**

Address: 0x0219

Effective mode: Real time

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 3

Change: Real-time

**Value Range:**

0: Built-in

1: External, natural cooling

2: External, forced air cooling

3: No resistor needed

**Description**

Defines the regenerative resistor type and the mode of absorbing and releasing the braking energy.

**H02.26 Power of external regenerative resistor**

Address: 0x021A

Effective mode: Real time

Min.: 1

Unit: W

Max.: 65535

Data Type: UInt16

Default: 40

Change: Real-time

**Value Range:**

1 W–65535 W

**Description**

Defines the power of the external braking resistor.

Note: The value of this parameter cannot be lower than the calculated braking power.

**H02.27 Resistance of external regenerative resistor**

Address: 0x021B

Effective mode: Real time

Min.: 15

Unit:  $\Omega$ 

Max.: 1000

Data Type: UInt16

Default: 50

Change: Real-time

**Value Range:**15  $\Omega$  to 1000  $\Omega$ **Description**

Defines the power of the external braking resistor.

Note: The value of this parameter cannot be lower than the calculated braking power.

**H02.30 User password**

Address: 0x021E

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H02.31 System parameter initialization**

Address: 0x021F

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Restore default settings

2: Clear fault records

**Description**

Used to restore default values or clear fault records.

If necessary, use Inovance software tool to back up parameters except those in groups 2000h and 2001h.

**H02.32 Selection of parameters in group H0b**

Address: 0x0220

Effective mode: Real time

Min.: 0

Unit: -

Max.: 99

Data Type: UInt16

Default: 50

Change: Immediately

**Value Range:**

0 to 99

**Description**

-

**H02.33 200P software version**

Address: 0x0221

Effective mode: -

Min.: 0.0

Unit: -

Max.: 65535.0

Data Type: UInt16

Default: 0.0

**Value Range:**  
0.0 to 65535.0

**Description**  
-

Change:

Unchangeable

**H02.35 Keypad data update frequency**

Address: 0x0223

Min.: 0

Max.: 20

Default: 0

**Value Range:**  
0 Hz to 20 Hz

**Description**  
-

Effective mode:

Real time

Unit:

Hz

Data Type:

UInt16

Change:

Immediately

**H02.41 Manufacturer password**

Address: 0x0229

Min.: 0

Max.: 65535

Default: 0

**Value Range:**  
0 to 65535

**Description**  
-

Effective mode:

Real time

Unit:

-

Data Type:

UInt16

Change:

Immediately

**4.4 H03 Terminal Input Parameters**

**H03.00 DI function allocation 1 (activated upon power-on)**

Address: 0x0300

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

Effective mode:

Upon the next power-on

Unit:

-

Data Type:

UInt16

Change:

Real-time

0: Corresponding to null  
1: Corresponding to FunIN.1  
2: Corresponding to FunIN.2  
4: Corresponding to FunIN.3  
8: Corresponding to FunIN.4  
16: Corresponding to FunIN.5  
32: Corresponding to FunIN.6  
64: Corresponding to FunIN.7  
128: Corresponding to FunIN.8  
256: Corresponding to FunIN.9  
512: Corresponding to FunIN.10  
1024: Corresponding to FunIN.11  
2048: Corresponding to FunIN.12  
4096: Corresponding to FunIN.13  
8192: Corresponding to FunIN.14  
16384: Corresponding to FunIN.15  
32768: Corresponding to FunIN.16

**Description**

-

**H03.01 DI function allocation 2 (activated upon power-on)**

Address: 0x0301

Effective      Upon the next power-on  
mode:

Min.:      0

Unit:      -

Max.:      65535

Data Type:    UInt16

Default:    0

Change:      Real-time

**Value Range:**

- 0: Corresponding to null
- 1: Corresponding to FunIN.17
- 2: Corresponding to FunIN.18
- 4: Corresponding to FunIN.19
- 8: Corresponding to FunIN.20
- 16: Corresponding to FunIN.21
- 32: Corresponding to FunIN.22
- 64: Corresponding to FunIN.23
- 128: Corresponding to FunIN.24
- 256: Corresponding to FunIN.25
- 512: Corresponding to FunIN.26
- 1024: Corresponding to FunIN.27
- 2048: Corresponding to FunIN.28
- 4096: Corresponding to FunIN.29
- 16384: Corresponding to FunIN.31
- 32768: Corresponding to FunIN.32

**Description**

-

**H03.02 D11 function**

Address:	0x0302	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	56	Data Type:	UInt16
Default:	14	Change:	Real-time

**Value Range:**

- 0: Undefined
- 1: S-ON
- 3: Gain switchover
- 14: Forward overtravel switch
- 15: Reverse overtravel switch
- 16: Positive external torque limit
- 17: Negative external torque limit
- 18: Forward jog
- 19: Reverse jog
- 31: Home switch
- 32: Homing enabled
- 34: Emergency stop
- 36: Internal speed limit source
- 38: Probe 1
- 39: Probe 2
- 41: Current position as home
- 56: EPOS program block external toggle switch

**Description**

Defines the function of DI1.

**H03.03 DI1 logic selection**

Address:	0x0303	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

- 0: Active low
- 1: Active high

**Description**

Used to set the level logic of DI1 when the function assigned to DI1 is active. DI1 to DI4 are normal DIs, requiring the input signal width to be larger than 1 ms. Set active level logic correctly according to the host controller and peripheral circuits. The width of the input signal is shown in the following table for your reference.

**H03.04 DI2 function selection**

Address:	0x0304	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	56	Data Type:	UInt16
Default:	15	Change:	Immediately

**Value Range:**

Same as H03.02.

**Description**

-

**H03.05 D12 logic selection**

Address: 0x0305

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active low

1: Active high

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H03.06 D13 function**

Address: 0x0306

Min.: 0

Max.: 56

Default: 31

**Value Range:**

Same as H03.02.

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H03.07 D13 logic selection**

Address: 0x0307

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active low

1: Active high

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H03.08 D14 function**

Address: 0x0308

Min.: 0

Max.: 56

Default: 34

**Value Range:**

Same as H03.02.

**Description**

-

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H03.09 D14 logic selection**

Address: 0x0309

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active low

1: Active high

**Description**

-

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H03.10 D15 function**

Address: 0x030A

Min.: 0

Max.: 56

Default: 38

**Value Range:**

Same as H03.02.

**Description**

-

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H03.11 D15 logic selection**

Address: 0x030B

Min.: 0

Max.: 1

Default: 0

**Value Range:**

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately



0: Active low  
1: Active high

**Description**

-

**H03.12 DI6 function**

Address: 0x030C

Min.: 0  
Max.: 45  
Default: 0

**Value Range:**

Same as H03.02

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H03.13 DI6 logic selection**

Address: 0x030D

Min.: 0  
Max.: 1  
Default: 0

**Value Range:**

0: Active low  
1: Active high

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H03.14 DI7 function**

Address: 0x030E

Min.: 0  
Max.: 45  
Default: 45

**Value Range:**

Same as H03.02

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H03.15 DI7 logic selection**

Address: 0x030F

Effective mode: Real time

Min.: 0	Unit: -
Max.: 1	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0: Active low

1: Active high

**Description**

-

**H03.16 D18 function**

Address: 0x0310

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

Min.: 0

Max.: 45

Default: 31

**Value Range:**

Same as H03.02

**Description**

-

**H03.17 D18 logic selection**

Address: 0x0311

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active low

1: Active high

**Description**

-

**H03.34 DI function allocation 3 (activated upon power-on)**

Address: 0x0322

Effective mode: Upon the next power-on

Unit: -

Data Type: UInt16

Change: Real-time

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

- 0: Corresponding to null
- 1: Corresponding to FunIN.33
- 2: Corresponding to FunIN.34
- 4: Corresponding to FunIN.35
- 8: Corresponding to FunIN.36
- 16: Corresponding to FunIN.37
- 32: Corresponding to FunIN.38
- 64: Corresponding to FunIN.39
- 128: Corresponding to FunIN.40
- 256: Corresponding to FunIN.41
- 512: Corresponding to FunIN.42
- 1024: Corresponding to FunIN.43
- 2048: Corresponding to FunIN.44
- 4096: Corresponding to FunIN.45
- 8192: Corresponding to FunIN.46
- 16384: Corresponding to FunIN.47
- 32768: Corresponding to FunIN.48

**Description**

-

**H03.35    DI function allocation 4 (activated upon power-on)**

Address:	0x0323	Effective mode:	Upon the next power-on
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

0: Corresponding to null  
 1: Corresponding to FunIN.49  
 2: Corresponding to FunIN.50  
 4: Corresponding to FunIN.51  
 8: Corresponding to FunIN.52  
 16: Corresponding to FunIN.53  
 32: Corresponding to FunIN.54  
 64: Corresponding to FunIN.55  
 128: Corresponding to FunIN.56  
 256: Corresponding to FunIN.57  
 512: Corresponding to FunIN.58  
 1024: Corresponding to FunIN.59  
 2048: Corresponding to FunIN.60  
 4096: Corresponding to FunIN.61  
 8192: Corresponding to FunIN.62  
 16384: Corresponding to FunIN.63

#### Description

-

### H03.51 Current-type AI1 input filter time constant

Address:	0x0333	Effective mode:	Real time
Min.:	0.00	Unit:	ms
Max.:	655.35	Data Type:	UInt16
Default:	2.00	Change:	Immediately

#### Value Range:

0.00ms to 655.35ms

#### Description

-

### H03.55 Voltage-type AI2 offset

Address:	0x0337	Effective mode:	Real time
Min.:	-5000	Unit:	mV
Max.:	5000	Data Type:	Int16
Default:	0	Change:	Immediately

#### Value Range:

-5000mV to 5000mV

#### Description

-

**H03.56 Voltage-type AI2 input filter time constant**

Address: 0x0338

Effective mode: Real time

Min.: 0.00

Unit: ms

Max.: 655.35

Data Type: UInt16

Default: 2.00

Change: Immediately

**Value Range:**

0.00ms to 655.35ms

**Description**

-

**H03.58 Voltage-type AI2 dead zone**

Address: 0x033A

Effective mode: Real time

Min.: 0.0

Unit: mV

Max.: 1000.0

Data Type: UInt16

Default: 10.0

Change: Immediately

**Value Range:**

0.0mV to 1000.0mV

**Description**

-

**H03.59 Voltage-type AI2 zero drift**

Address: 0x033B

Effective mode: Real time

Min.: -500

Unit: mV

Max.: 500.0

Data Type: Int16

Default: 0.0

Change: Immediately

**Value Range:**

-500mV to 500.0mV

**Description**

-

**H03.60 DI1 filter time**

Address: 0x033C

Effective mode: Real time

Min.: 0.00

Unit: ms

Max.: 500.00

Data Type: UInt16

Default: 3.00

Change: Immediately

**Value Range:**

0.00ms to 500.00ms

**Description**

-

**H03.61 D12 fitter time**

Address: 0x033D

Min.: 0.00

Max.: 500.00

Default: 3.00

**Value Range:**

0.00ms to 500.00ms

**Description**

-

Effective mode: Real time  
 Unit: ms  
 Data type: UInt16  
 Change: Immediately

**H03.62 D13 fitter time**

Address: 0x033E

Min.: 0.00

Max.: 500.00

Default: 3.00

**Value Range:**

0.00ms to 500.00ms

**Description**

-

Effective mode: Real time  
 Unit: ms  
 Data type: UInt16  
 Change: Immediately

**H03.63 D14 fitter time**

Address: 0x033F

Min.: 0.00

Max.: 500.00

Default: 3.00

**Value Range:**

0.00ms to 500.00ms

**Description**

-

Effective mode: Real time  
 Unit: ms  
 Data type: UInt16  
 Change: Immediately

**H03.64 D15 fitter time**

Address: 0x0340

Min.: 0.00

Max.: 500.00

Default: 3.00

Effective mode: Real time  
 Unit: ms  
 Data type: UInt16  
 Change: Immediately

**Value Range:**

0.00ms to 500.00ms

**Description**

-

**H03.65 D16 fitter time**

Address: 0x0341

Effective mode: Real time

Min.: 0.00

Unit: ms

Max.: 500.00

Data type: UInt16

Default: 0.50

Change: Immediately

**Value Range:**

0.00ms to 500.00ms

**Description**

-

**H03.66 D17 fitter time**

Address: 0x0342

Effective mode: Real time

Min.: 0.00

Unit: ms

Max.: 500.00

Data type: UInt16

Default: 0.50

Change: Immediately

**Value Range:**

0.00ms to 500.00ms

**Description**

-

**H03.67 D18 fitter time**

Address: 0x0343

Effective mode: Real time

Min.: 0.00

Unit: ms

Max.: 500.00

Data type: UInt16

Default: 0.50

Change: Immediately

**Value Range:**

0.00ms to 500.00ms

**Description**

-

**H03.80 Speed corresponding to analog 10 V**

Address: 0x0350

Effective mode: Real time

Min.: 0

Unit: 1 RPM

Max.: 6000

Data type: UInt16

Default: 3000

Change: At stop

**Value Range:**

01 RPM–60001 RPM

**Description**

-

**H03.81 Torque corresponding to analog 10 V**

Address: 0x0351

Effective mode: Real time

Min.: 1.00

Unit: Multiplier

Max.: 8.00

Data type: UInt16

Default: 1.00

Change: At stop

**Value Range:**

1.00 to 8.00

**Description**

-

## 4.5 H04 Terminal Output Parameters

**H04.00 DO1 function**

Address: 0x0400

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1

Change: Real-time

**Value Range:**



- 0: No function
- 1: Servo ready
- 2: Motor rotation signal
- 3: Zero speed signal
- 4: Speed matching signal
- 5: Positioning completed
- 6: Positioning near
- 7: Torque limited signal
- 8: Speed limited signal
- 9: Braking
- 10: Warning
- 11: Fault
- 16: Homing completed
- 18: Torque reached signal
- 19: Speed reached signal
- 21: Enable completed
- 25: Comparison output
- 30: Warning or fault output
- 32: EDM output

**Description**

Defines the function of DO1.  
Different VDOs can be assigned with the same function.  
Descriptions for the setpoints are shown in the following table.

**H04.01 DO1 logic selection**

Address:	0x0401	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

- 0: Normally open
- 1: Closed

**Description**

Defines the level logic of DO1 when the function assigned to DO1 is active.  
DO1 to DO3 are normal DOs, requiring the minimum output signal width to be 1 ms.  
The host controller must be able to receive valid DO logic changes.  
Before receiving DO logic changes, check the setting of forced DI/DO selection to see whether the DO level is determined by the actual operating status of the drive or by forced DO.

**H04.02 DO2 function**

Address: 0x0402

Min.: 0

Max.: 65535

Default: 11

**Value Range:**

See H04.00.

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H04.03 DO2 logic selection**

Address: 0x0403

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Normally open

1: Closed

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H04.04 DO3 function**

Address: 0x0404

Min.: 0

Max.: 65535

Default: 9

**Value Range:**

See H04.00.

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H04.05 DO3 logic selection**

Address: 0x0405

Min.: 0

Max.: 1

Default: 0

**Value Range:**

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

0: Normally open  
1: Closed

**Description**

-

**H04.06 DO4 function**

Address: 0x0406

Min.: 0

Max.: 65535

Default: 11

**Value Range:**

Same as H04.00

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H04.07 DO4 logic selection**

Address: 0x0407

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Normally open

1: Closed

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H04.08 DO5 function**

Address: 0x0408

Min.: 0

Max.: 65535

Default: 16

**Value Range:**

Same as H04.00

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H04.09 DO5 logic selection**

Address: 0x0409

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Normally open

1: Closed

**Description**

-

**H04.22 DO source selection**

Address: 0x0416

Effective mode: Real time

Min.: 0

Unit: -

Max.: 31

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

bit	Name	Description
0	DO1	0: DO1 function output
		1: Bit 0 of H31.04 set through communication
1	DO2	0: DO2 function output
		1: Bit 1 of H31.04 set through communication
2	DO3	0: DO3 function output
		1: Bit 2 of H31.04 set through communication
3	DO4	0: DO4 function output
		1: Bit 3 of H31.04 set through communication
4	DO5	0: DO5 function output
		1: Bit 4 of H31.04 set through communication

**Description**


Defines whether the logic of a physical DO terminal is defined by the actual state of the drive or by communication.

The value of H04.22 is displayed in decimal on the keypad. When the value is converted to a binary equivalent: If bit(n) is 0, it indicates the logic of DO(n+1) is defined by the actual state of the drive. If bit(n) is 1, it indicates the logic of DO(n+1) is defined by communication (H31.04).

Setpoint (decimal)	Setpoint (binary)					DO logic	
	bit4	bit3	bit2	bit1	bit0	Defined by the Drive State	Defined by Communica tion (H31.04)
	DO5	DO4	DO3	DO2	DO1		
0	0	0	0	0	0	DO1–DO5	N/A
1	0	0	0	0	1	DO2–DO5	DO1
...	...	...	...	...	...	...	...
31	1	1	1	1	1	N/A	DO1–DO5

Set H04.22 to a value listed in the preceding table.

H31.04 is not displayed on the keypad and can only be modified through communication. For H31.04, "bit(n) = 1" indicates the logic of DO(n+1) is active. "bit(n) = 0" indicates the logic of DO(n+1) is inactive.



### H04.50 AO1 signal selection

Address: 0x0432

Min.: 0

Max.: 10

Default: 0

**Value Range:**

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Real-time

- 0: Motor speed (1 V/1000 rpm)
- 1: Speed reference (1 V/1000 rpm)
- 2: Torque reference (1 V/100 x rated torque)
- 3: Position deviation (0.5 mV/1 reference unit)
- 4: Position deviation (0.5 mV/1 encoder unit)
- 5: Position reference speed (1 V/1000 rpm)
- 6: Positioning completed
- 9: AI2 voltage
- 10: Defined by H31.05

**Description**

-

**H04.51 AO1 offset voltage**

Address: 0x0433

Effective mode: Real time

Min.: -10000

Unit: mV

Max.: 10000

Data Type: Int16

Default: 5000

Change: Immediately

**Value Range:**

-10000mV to 10000mV

**Description**

-

**H04.52 AO1 ratio**

Address: 0x0434

Effective mode: Real time

Min.: -99.99

Unit: -

Max.: 99.99

Data Type: Int16

Default: 1.00

Change: Immediately

**Value Range:**

-99.99 to 99.99

**Description**

-

**4.6 H05 Position Control Parameters****H05.00 Primary position reference source**

Address: 0x0500

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16



**H05.05 Step amount**

Address: 0x0505

Effective mode: Real time

Min.: -9999

Unit: Reference unit

Max.: 9999

Data Type: Int16

Default: 50

Change: At stop

**Value Range:**

-9999 to +9999

**Description**

-

**H05.06 Moving average filter time constant 1**

Address: 0x0506

Effective mode: Real time

Min.: 0.0

Unit: ms

Max.: 128.0

Data Type: UInt16

Default: 0.0

Change: At stop

**Value Range:**

0.0 ms to 128.0ms

**Description**

-

**H05.07 Electronic gear ratio 1 (numerator)**

Address: 0x0507

Effective mode: Real time

Min.: 1

Unit: -

Max.: 1073741824

Data type: UInt32

Default: 8388608

Change: Immediately

**Value Range:**

1 to 1073741824

**Description**

-

**H05.09 Electronic gear ratio 1 (denominator)**

Address: 0x0509

Effective mode: Real time

Min.: 1

Unit: -

Max.: 1073741824

Data type: UInt32

Default: 10000

Change: Immediately

**Value Range:**

1 to 1073741824



**Description**

-

**H05.11 Electronic gear ratio 2 (numerator)**

Address: 0x050B	Effective mode:	Real time
Min.: 1	Unit:	-
Max.: 1073741824	Data type:	UInt32
Default: 8388608	Change:	Immediately

**Value Range:**

1 to 1073741824

**Description**

-

**H05.13 Electronic gear ratio 2 (denominator)**

Address: 0x050D	Effective mode:	Real time
Min.: 1	Unit:	-
Max.: 1073741824	Data type:	UInt32
Default: 10000	Change:	Immediately

**Value Range:**

1 to 1073741824

**Description**

-

**H05.15 Pulse reference form**

Address: 0x050F	Effective mode:	Upon the next power-on
Min.: 0	Unit:	-
Max.: 3	Data type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0: Direction + Pulse, positive logic

1: Direction + Pulse, negative logic

2: Phase A + phase B quadrature pulse, quadrupled frequency

3: CW + CCW

**Description**

-

**H05.16 Clear action**

Address: 0x0510	Effective mode:	Real time
-----------------	-----------------	-----------

Min.: 0	Unit: -
Max.: 2	Data Type: UInt16
Default: 0	Change: At stop

**Value Range:**

0: Position deviation cleared upon S-OFF or non-operational state

1: Position deviation cleared upon S-OFF or fault

2: Position deviation cleared upon S-OFF or active DI function 35

**Description**

-

**H05.17 Number of encoder frequency-division pulses**

Address: 0x0511	Effective mode:	Upon the next power-on
Min.: 35	Unit:	PPR
Max.: 4194303	Data type:	UInt32
Default: 2500	Change:	At stop

**Value Range:**

35P/Rev–4194303P/Rev

**Description**

-

**H05.19 Speed feedforward control**

Address: 0x0513	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 3	Data Type:	UInt16
Default: 1	Change:	At stop

**Value Range:**

0: No speed feedforward

1: Internal speed feedforward

2: PLC speed feedforward

**Description**

Defines the source of the speed loop feedforward signal.

In the position control mode, speed feedforward can be used to improve the position reference response speed.

Speed feedforward control parameters include speed feedforward filter time constant and speed feedforward gain. See section "Feedforward Gain" for details.

**H05.20 Condition for positioning completed signal output**

Address: 0x0514	Effective mode:	Real time
-----------------	-----------------	-----------

Min.:	0	Unit:	-
Max.:	10	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

- 0: Absolute position deviation lower than the setpoint of H05.21
- 1: Absolute position deviation lower than the setpoint of H05.21 and the filtered position reference is 0
- 2: Absolute position deviation lower than the setpoint of H05.21 and the unfiltered position reference is 0
- 3: Absolute position deviation kept lower than the setpoint of H05.21 within the time defined by H05.60 and the unfiltered position reference is 0
- 4: Absolute value of position deviation lower than threshold, window time being active and filtered position reference being 0
- 5: Absolute value of position deviation lower than threshold, with zero speed signal being active and filtered position reference being 0
- 6: Absolute value of position deviation lower than threshold, with zero speed signal being active and filtered position reference being 0
- 7: COIN signal judged after the change (available→unavailable) of the position reference kept active for the defined window time, with filtered position reference being 0 and position deviation lower than threshold
- 8: COIN signal judged after the change (available→unavailable) of the filtered position reference kept active for the defined window time, with filtered position reference being 0 and position deviation lower than the threshold
- 9: COIN signal judged after the change (available→unavailable) of the position reference kept active for the defined window time, with filtered position reference being 0 and position deviation lower than the threshold
- 10: COIN signal judged after the change (available→unavailable) of the filtered position reference kept active for the defined window time, with filtered position reference being 0 and position deviation lower than threshold

**Description**

-

**H05.21 Threshold of positioning completed**

Address:	0x0515	Effective mode:	Real time
Min.:	1	Unit:	Encoder unit
Max.:	65535	Data Type:	UInt16
Default:	7	Change:	Immediately

**Value Range:**

1 to 65535

**Description**

-

**H05.22 Proximity threshold**

Address: 0x0516

Effective mode: Real time

Min.: 1

Unit: Encoder unit

Max.: 65535

Data type: UInt16

Default: 65535

Change: Immediately

**Value Range:**

1 to 65535

**Description**

-

**H05.24 Interrupt positioning displacement**

Address: 0x0518

Effective mode: Real time

Min.: 0

Unit: Reference unit

Max.: 1073741824

Data type: UInt32

Default: 10000

Change: Immediately

**Value Range:**

0 to 1073741824

**Description**

-

**H05.26 Constant operating speed in interrupt positioning**

Address: 0x051A

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 6000

Data Type: UInt16

Default: 200

Change: Immediately

**Value Range:**

0rpm–6000rpm

**Description**

-

**H05.27 Acc./Dec. time of interrupt positioning**

Address: 0x051B

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10

Change: Immediately

**Value Range:**

0ms to 65535ms

**Description**

-

**H05.29 Interruption fixed length unlock**

Address: 0x051D

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

Min.: 0  
Max.: 1  
Default: 1

**Value Range:**

0: Disabled  
1: Enabled

**Description**

-

**H05.32 Speed of high-speed search for home switch signal**

Address: 0x0520

Effective mode: Real time  
Unit: RPM  
Data type: UInt16  
Change: Immediately

Min.: 0  
Max.: 3000  
Default: 100

**Value Range:**

0 RPM–3000 RPM

**Description**

-

**H05.33 Speed of low-speed search for home switch signal**

Address: 0x0521

Effective mode: Real time  
Unit: RPM  
Data type: UInt16  
Change: Immediately

Min.: 0  
Max.: 1000  
Default: 10

**Value Range:**

0rpm–1000rpm

**Description**

-

**H05.34 Acceleration/Deceleration time during homing**

Address: 0x0522

Effective mode: Real time  
Unit: ms

Min.: 0

Max.: 1000

Default: 1000

**Value Range:**

0ms to 1000ms

**Description**

-

Data Type: UInt16

Change: Immediately

**H05.35 Home search time limit**

Address: 0x0523

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10000

Change: Immediately

**Value Range:**

0ms to 65535ms

**Description**

-

**H05.36 Mechanical home offset**

Address: 0x0524

Effective mode: Real time

Min.: -2147483648

Unit: Reference unit

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Real-time

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H05.38 Frequency-division output source**

Address: 0x0526

Effective mode: Upon the next power-on

Min.: 0

Unit: -

Max.: 2

Data type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Encoder frequency-division output

1: Pulse reference synchronous output

2: Frequency-division output inhibited

3: Second encoder frequency-division output

**Description**

-

**H05.39 Electronic gear ratio switchover condition**

Address: 0x0527	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0: Switchover after position reference is kept 0 for 2.5 ms

1: Switched in real time

**Description**

-

**H05.40 Mechanical home offset and action upon overtravel**

Address: 0x0528	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 3	Data Type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0: H05.36 as the coordinate after homing, reverse homing applied after homing triggered again on overtravel

1: H05.36 as the relative offset after homing, reverse homing applied after homing triggered again on overtravel

2: H05.36 as the coordinate after homing, reverse homing auto-applied on overtravel

3: H05.36 as the relative offset after homing, reverse homing auto-applied on overtravel

**Description**

-

**H05.41 Z pulse output polarity**

Address: 0x0529	Effective mode:	Upon the next power-on
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 1	Change:	At stop

**Value Range:**

bit0: Frequency-division Z output polarity  
 0: Positive (high level upon active Z pulse)  
 1: Negative (low level upon active Z pulse)  
 bit1: OCZ output polarity  
 0: Positive (high level upon active Z pulse)  
 1: Negative (low level upon active Z pulse)  
 bit2: Inner loop probe Z signal source  
 0: Motor Z signal  
 1: Frequency-division output Z signal

**Description**

-

**H05.43 Position pulse edge**

Address: 0x052B

Effective mode: Upon the next power-on

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Rising edge-triggered

1: Falling edge-triggered

**Description**

-

**H05.44 Numerator of frequency-division output reduction ratio**

Address: 0x052C

Effective mode: Real time

Min.: 1

Unit: -

Max.: 16383

Data Type: UInt16

Default: 1

Change: At stop

**Value Range:**

1 to 16383

**Description**

-

**H05.45 Denominator of frequency-division output reduction ratio**

Address: 0x052D

Effective mode: Real time

Min.: 1

Unit: -

Max.: 8191

Data Type: UInt16

Default: 1

Change: At stop



**Value Range:**

1 to 8191

**Description**

-

**H05.46 DI selection of multi-turn frequency-division Z starting point**

Address: 0x052E

Effective mode: Upon the next power-on

Min.: 0

Unit: -

Max.: 8

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: No selection

1: DI1

2: DI2

3: DI3

4: DI4

5: DI5

6: DI6

7: DI7

8: DI8

**Description**

-

**H05.47 Frequency-division Z pulse width**

Address: 0x052F

Effective mode: Real time

Min.: 0

Unit: us

Max.: 400

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0us–400us

**Description**

-

**H05.50 Mechanical gear ratio in absolute position rotation mode (numerator)**

Address: 0x0532

Effective mode: Upon the next power-on

Min.: 1

Unit: -

Max.: 65535

Data type: UInt16

Default: 1

Change: At stop

**Value Range:**

1 to 65535

**Description**

-

**H05.51 Mechanical gear ratio in absolute position rotation mode (denominator)**

Address: 0x0533

Effective mode: Upon the next power-on

Min.: 1

Unit: -

Max.: 65535

Data type: UInt16

Default: 1

Change: At stop

**Value Range:**

1 to 65535

**Description**

-

**H05.52 Pulses per revolution of the load in absolute position rotation mode (low 32 bits)**

Address: 0x0534

Effective mode: Upon the next power-on

Min.: 0

Unit: Encoder unit

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At stop

**Value Range:**

0 to 2147483647

**Description**

-

**H05.54 Pulses per revolution of the load in absolute position rotation mode (high 32 bits)**

Address: 0x0536

Effective mode: Upon the next power-on

Min.: 0

Unit: Encoder unit

Max.: 2147483647

Data Type: UInt32

Default: 0

Change: At stop

**Value Range:**

0 to 2147483647

**Description**

-

**H05.56 Speed threshold in homing upon hit-and-stop**

Address: 0x0538

Effective mode: Real time

Min.: 0  
Max.: 1000  
Default: 2

Unit: RPM  
Data Type: UInt16  
Change: Immediately

**Value Range:**

0rpm–1000rpm

**Description**

-

**H05.58 Torque threshold in homing upon hit-and-stop**

Address: 0x053A

Effective mode: Real time

Min.: 0.0  
Max.: 300.0  
Default: 100.0

Unit: %  
Data type: UInt16  
Change: Immediately

**Value Range:**

0.0% to 300.0%

**Description**

-

**H05.59 Positioning window time**

Address: 0x053B

Effective mode: Real time

Min.: 0  
Max.: 30000  
Default: 0

Unit: ms  
Data Type: UInt16  
Change: Immediately

**Value Range:**

0ms to 30000ms

**Description**

-

**H05.60 Hold time of positioning completed**

Address: 0x053C

Effective mode: Real time

Min.: 0  
Max.: 30000  
Default: 0

Unit: ms  
Data Type: UInt16  
Change: Immediately

**Value Range:**

0ms to 30000ms

**Description**

-

**H05.66 Homing time unit**

Address: 0x0542

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: At stop

Min.: 0

Max.: 2

Default: 2

**Value Range:**

0: 1 ms

1: 10 ms

2: 100 ms

**Description**

-

**H05.67 Offset between zero point and single-turn absolute position**

Address: 0x0543

Effective mode: Real time  
 Unit: 1 encoder unit  
 Data Type: Int32  
 Change: At stop

Min.: -2147483648

Max.: 2147483647

Default: 0

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H05.69 Auxiliary homing function**

Address: 0x0545

Effective mode: Upon the next power-on  
 Unit: -  
 Data Type: UInt16  
 Change: At stop

Min.: 0

Max.: 2

Default: 0

**Value Range:**

0: Inhibited

1: Record offset position

2: Clear offset position

**Description**

-

**H05.70 Moving average filter time constant 2**

Address: 0x0546

Effective mode: Real time  
 Unit: ms  
 Data Type: UInt16

Min.: 0.0

Max.: 1000.0

Default: 0.0

Change: At stop

**Value Range:**

0.0 ms to 1000.0ms

**Description**

-

**H05.71 Motor Z signal width**

Address: 0x0547

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 100

Data Type: UInt16

Default: 4

Change: Immediately

**Value Range:**

0ms to 100ms

**Description**

-

**H05.72 Positioning completed window in fully closed-loop mode**

Address: 0x0548

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Use inner loop unit

1: Inner loop uses inner loop unit, and outer loop uses outer loop unit

**Description**

-

**H05.80 Reference operation mode in rotation mode**

Address: 0x0550

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 4

**Description**

-

## 4.7 H06 Speed Control Parameters

### H06.00 Source of main speed reference A

Address: 0x0600

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: Digital setting (H06.03)

#### Description

-

### H06.01 Source of auxiliary speed reference B

Address: 0x0601

Effective mode: Real time

Min.: 0

Unit: -

Max.: 5

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: Digital setting (H06.03)

5: Multi-speed reference

#### Description

-

### H06.02 Speed reference source

Address: 0x0602

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4

Data type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: Source of main speed reference A

1: Source of auxiliary speed reference B

2: A+B

3: Switched between A and B

4: Communication

#### Description

-

<b>H06.03</b>	<b>Speed reference value set through keypad</b>		
Address:	0x0603	Effective mode:	Real time
Min.:	-10000	Unit:	RPM
Max.:	10000	Data type:	Int16
Default:	200	Change:	Immediately
<b>Value Range:</b> -10000 RPM to +10000 RPM			
<b>Description</b> -			

<b>H06.04</b>	<b>DI speed reference</b>		
Address:	0x0604	Effective mode:	Real time
Min.:	0	Unit:	RPM
Max.:	10000	Data Type:	Int16
Default:	150	Change:	Immediately
<b>Value Range:</b> 0rpm-10000rpm			
<b>Description</b> -			

<b>H06.05</b>	<b>Acc. ramp time of speed reference</b>		
Address:	0x0605	Effective mode:	Real time
Min.:	0	Unit:	ms
Max.:	65535	Data type:	UInt16
Default:	0	Change:	Immediately
<b>Value Range:</b> 0ms to 65535ms			
<b>Description</b> Acc. ramp time of speed reference in the local speed mode.			

<b>H06.06</b>	<b>Dec. ramp time of speed reference</b>		
Address:	0x0606	Effective mode:	Real time
Min.:	0	Unit:	ms
Max.:	65535	Data type:	UInt16
Default:	0	Change:	Immediately
<b>Value Range:</b> 0ms to 65535ms			

**Description**

Dec. ramp time of speed reference in the local speed mode.

**H06.07 Max. speed limit**

Address: 0x0607

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 7000

Change: Immediately

**Value Range:**

0rpm–10000rpm

**Description**

-

**H06.08 Forward speed limit**

Address: 0x0608

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 7000

Change: Immediately

**Value Range:**

0rpm–10000rpm

**Description**

-

**H06.09 Reverse speed limit**

Address: 0x0609

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 7000

Change: Immediately

**Value Range:**

0rpm–10000rpm

**Description**

-

**H06.10 Deceleration unit in emergency stop**

Address: 0x060A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16



Default: 0

Change: At stop

**Value Range:**

0: Multiplied by 1

1: Multiplied by 10

2: Multiplied by 100

**Description**

The default value is 0. When ramp stop is set to the maximum value but the ramp time still exceeds the expected value, you can use this parameter to reduce the stop time.

**H06.11 Torque feedforward control**

Address: 0x060B

Effective Real time

mode:

Min.: 0

Unit:

-

Max.: 1

Data Type: UInt16

Default: 1

Change: Real-time

**Value Range:**

0: No torque feedforward

1: Internal torque feedforward

**Description**

Defines whether to enable internal torque feedforward in the control modes other than torque control.

Torque feedforward can be used to improve the torque reference response speed and reduce the position deviation during acceleration/deceleration at constant speed.

Parameters of the torque feedforward function include torque feedforward filter time constant and torque feedforward gain. For details, see section Feedforward Gain.

In non-torque control, the control block diagram of torque feedforward is shown in the following figure.

**H06.12 Acceleration ramp time of jog speed**

Address: 0x060C

Effective Real time

mode:

Min.: 0

Unit: ms

Max.: 65535

Data Type: UInt16

Default: 10

Change: Real-time

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the acceleration/deceleration time of jog speed references in the jog mode set through H0d.11 or the software tool.

**H06.13 Speed feedforward smoothing filter**

Address: 0x060D

Effective mode: Real time

Min.: 0

Unit: us

Max.: 65535

Data type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0us–65535us

**Description**

Defines the speed feedforward filter time constant.

**H06.15 Zero clamp speed threshold**

Address: 0x060F

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 10

Change: Immediately

**Value Range:**

0rpm–10000rpm

**Description**

-

**H06.16 Threshold of TGON (motor rotation) signal**

Address: 0x0610

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 1000

Data Type: UInt16

Default: 20

Change: Immediately

**Value Range:**

0rpm–1000rpm

**Description**

-

**H06.17 Threshold of V-Cmp (speed matching) signal**

Address: 0x0611

Effective mode: Real time

Min.: 0

Unit: RPM

Max.: 100

Data Type: UInt16

Default: 10

Change: Immediately

**Value Range:**

0 RPM –100 RPM

**Description**

-

**H06.18 Threshold of speed reach signal**

Address: 0x0612

Effective mode: Real time

Min.: 20

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 1000

Change: Immediately

**Value Range:**

20rpm–10000rpm

**Description**

-

**H06.19 Threshold of zero speed output signal**

Address: 0x0613

Effective mode: Real time

Min.: 1

Unit: RPM

Max.: 10000

Data Type: UInt16

Default: 10

Change: Immediately

**Value Range:**

1rpm–10000rpm

**Description**

-

**H06.36 Deceleration time of ramp 1/PN ramp stop**

Address: 0x0624

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 32

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0ms to 32ms

**Description**

-

**H06.40 Deceleration time of ramp 1/PN ramp stop**

Address: 0x0628

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 65535

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0ms to 65535ms

**Description**

-

**H06.41 Dec. time of ramp 2/PN quick stop**

Address: 0x0629

Effective mode: Real time

Min.: 0

Unit: ms

Max.: 65535

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0ms to 65535ms

**Description**

-

**H06.50 Speed S-curve enable switch**

Address: 0x0632

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 1

**Description**

-

**H06.51 Increasing acceleration of speed S-curve acceleration segment**

Address: 0x0633

Effective mode: Real time

Min.: 0.0

Unit: %

Max.: 100.0

Data type: UInt16

Default: 50.0

Change: At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.52 Decreasing acceleration of speed S-curve acceleration segment**

Address: 0x0634

Effective mode: Real time

Min.:	0.0	Unit:	%
Max.:	100.0	Data type:	UInt16
Default:	50.0	Change:	At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.53 Increasing acceleration of speed S-curve deceleration segment**

Address:	0x0635	Effective mode:	Real time
Min.:	0.0	Unit:	%
Max.:	100.0	Data type:	UInt16
Default:	50.0	Change:	At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

**H06.54 Decreasing acceleration of speed S-curve deceleration segment**

Address:	0x0636	Effective mode:	Real time
Min.:	0.0	Unit:	%
Max.:	100.0	Data type:	UInt16
Default:	50.0	Change:	At stop

**Value Range:**

0.0% to 100.0%

**Description**

-

## 4.8 H07 Torque Control Parameters

**H07.00 Source of main torque reference A**

Address:	0x0700	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	2	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Keypad (H7.03)

**Description**

-

**H07.01 Source of auxiliary torque reference B**

Address: 0x0701

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Keypad (H7.03)

**Description**

-

**H07.02 Torque reference source**

Address: 0x0702

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Source of main torque reference A

1: Source of auxiliary torque reference B

2: Source of A+B

3: Switched between A and B

4: Communication

**Description**

-

**H07.03 Torque reference set through keypad**

Address: 0x0703

Effective mode: Real time

Min.: -400

Unit: %

Max.: 400.0

Data type: Int16

Default: 0.0

Change: Immediately

**Value Range:**

-400.0% to 400.0%

**Description**

-

**H07.05 Torque reference filter time constant 1**

Address: 0x0705	Effective mode:	Real time
Min.: 0.00	Unit:	ms
Max.: 30.00	Data Type:	UInt16
Default: 0.50	Change:	Immediately

**Value Range:**

0.00ms to 30.00ms

**Description**

-

**H07.06 Torque reference filter time constant 2**

Address: 0x0706	Effective mode:	Real time
Min.: 0.00	Unit:	ms
Max.: 30.00	Data Type:	UInt16
Default: 0.27	Change:	Real-time

**Value Range:**

0.00 ms to 30.00 ms

**Description**

Defines the torque reference filter time constant.

Low-pass filtering of torque references helps smoothen torque references and reduce vibration.

Pay attention to the responsiveness during setting as an excessively high setpoint lowers down the responsiveness.

**H07.07 Torque limit source**

Address: 0x0707	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 5	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0: Positive/Negative internal torque limit

5: PN torque limit

**Description**

-

**H07.09 Positive internal torque limit**

Address: 0x0709	Effective mode:	Real time
-----------------	-----------------	-----------

Min.: 0.0  
 Max.: 400.0  
 Default: 350.0

Unit: %  
 Data Type: UInt16  
 Change: Immediately

**Value Range:**

0.0% to 400.0%

**Description**

-

**H07.10 Negative internal torque limit**

Address: 0x070A

Effective mode: Real time

Min.: 0.0  
 Max.: 400.0  
 Default: 350.0

Unit: %  
 Data Type: UInt16  
 Change: Immediately

**Value Range:**

0.0% to 400.0%

**Description**

-

**H07.11 Positive external torque limit**

Address: 0x070B

Effective mode: Real time

Min.: 0.0  
 Max.: 400.0  
 Default: 350.0

Unit: %  
 Data Type: UInt16  
 Change: Immediately

**Value Range:**

0.0% to 400.0%

**Description**

-

**H07.12 Negative external torque limit**

Address: 0x070C

Effective mode: Real time

Min.: 0.0  
 Max.: 400.0  
 Default: 350.0

Unit: %  
 Data Type: UInt16  
 Change: Immediately

**Value Range:**

0.0% to 400.0%

**Description**

-



**H07.15 Emergency-stop torque**

Address: 0x070F	Effective mode:	At stop
Min.: 0.0	Unit:	%
Max.: 400.0	Data Type:	UInt16
Default: 100.0	Change:	Immediately
<b>Value Range:</b>		
0.0% to 400.0%		
<b>Description</b>		
-		

**H07.17 Speed limit source**

Address: 0x0711	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 2	Data type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
0: Internal speed limit		
2: H07.19 or H07.20 as defined by DI		
<b>Description</b>		
-		

**H07.19 Positive speed limit/Speed limit 1 in torque control**

Address: 0x0713	Effective mode:	Real time
Min.: 0	Unit:	RPM
Max.: 10000	Data type:	UInt16
Default: 3000	Change:	Immediately
<b>Value Range:</b>		
0 RPM–10000 RPM		
<b>Description</b>		
-		

**H07.20 Negative speed limit/Speed limit 2 in torque control**

Address: 0x0714	Effective mode:	Real time
Min.: 0	Unit:	RPM
Max.: 10000	Data type:	UInt16
Default: 3000	Change:	Immediately
<b>Value Range:</b>		
0 RPM–10000 RPM		

**Description**

-

**H07.21 Torque reach base value**

Address: 0x0715

Min.: 0.0

Max.: 300.0

Default: 0.0

**Value Range:**

0.0% to 300.0%

**Description**

-

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

**H07.22 Torque reach valid value**

Address: 0x0716

Min.: 0.0

Max.: 400.0

Default: 20.0

**Value Range:**

0.0% to 400.0%

**Description**

-

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

**H07.23 Torque reach invalid value**

Address: 0x0717

Min.: 0.0

Max.: 400.0

Default: 10.0

**Value Range:**

0.0% to 400.0%

**Description**

-

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

**H07.24 Field weakening depth**

Address: 0x0718

Min.: 60

Max.: 115

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16

Default: 115

Change: Real-time

**Value Range:**

60%–115%

**Description**

Use the default value in general cases. Reducing the flux weakening depth improves the dynamic performance of flux-weakening area and reduces current ripple, but also leads to load rate rise.

**H07.25 Max. permissible demagnetizing current**

Address: 0x0719

Effective mode: Real time

Min.: 0

Unit: %

Max.: 200

Data Type: UInt16

Default: 100

Change: Real-time

**Value Range:**

0%–200%

**Description**

Use the default value in general cases. Increasing the demagnetizing current extends the motor speed range, but also poses a greater challenge on the bearing capacity of the motor. If you need to increase the setpoint of 2007-1Ah, contact Inovance first.

**H07.26 Field weakening selection**

Address: 0x071A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disabled

1: Enabled

**Description**

0: Disabled; 1: Enabled

**H07.27 Flux weakening gain**

Address: 0x071B

Effective mode: Real time

Min.: 0.001

Unit: Hz

Max.: 1.000

Data Type: UInt16

Default: 0.030

Change: Immediately

**Value Range:**

0.001 Hz to 1.000 Hz

**Description**

-

**H07.28 Speed of flux weakening point**

Address: 0x071C

Effective mode: Real time

Unit: -

Min.: 0

Data Type: UInt16

Max.: 65535

Change: Unchangeable

Default: 0

**Value Range:**

0 to 65535

**Description**

-

**H07.36 Time constant of low-pass filter 2**

Address: 0x0724

Effective mode: Real time

Unit: ms

Min.: 0.00

Data Type: UInt16

Max.: 10.00

Change: Immediately

Default: 0.00

**Value Range:**

0.00ms to 10.00ms

**Description**

-

**H07.37 Torque reference filter selection**

Address: 0x0725

Effective mode: Real time

Unit: -

Min.: 0

Data type: UInt16

Max.: 1

Change: Immediately

Default: 0

**Value Range:**

0: First-order filter

1: Biquad filter

**Description**

0: First-order filter

1: Biquad filter

**H07.38 Biquad filter attenuation ratio**

Address: 0x0726

Effective mode: Real time

Min.:	0	Unit:	-
Max.:	50	Data Type:	UInt16
Default:	16	Change:	At stop

**Value Range:**

0 to 50

**Description**

-

**H07.40 Speed limit window in torque control mode**

Address:	0x0728	Effective mode:	Real time
Min.:	0.0	Unit:	ms
Max.:	30.0	Data type:	UInt16
Default:	1.0	Change:	Immediately

**Value Range:**

0.0 ms to 30.0ms

**Description**

-

## 4.9 H08 Gain Parameters

**H08.00 Speed loop gain**

Address:	0x0800	Effective mode:	Real time
Min.:	0.1	Unit:	Hz
Max.:	2000.0	Data Type:	UInt16
Default:	40.0	Change:	Real-time

**Value Range:**

0.1Hz to 2000.0Hz

**Description**

Defines the proportional gain of the speed loop.

2008-01h determines the responsiveness of the speed loop. The higher the setpoint, the higher the responsiveness. Note that an excessively high setpoint may cause vibration. In the position control mode, the position loop gain must be increased together with the speed loop gain.

**H08.01 Speed loop integral time constant**

Address:	0x0801	Effective mode:	Real time
Min.:	0.15	Unit:	ms
Max.:	512.00	Data Type:	UInt16

Default: 19.89

Change: Real-time

**Value Range:**

0.15 ms to 512.00 ms

**Description**

Defines the integral time constant of the speed loop.

The lower the setpoint, the better the integral action, and the quicker will the deviation value be close to 0.

Note: There is no integral action when H08.01 is set to 512.00.

**H08.02 Position loop gain**

Address: 0x0802

Effective mode: Real time

Min.: 0.1

Unit: Hz

Max.: 2000.0

Data Type: UInt16

Default: 64.0

Change: Real-time

**Value Range:**

0.1Hz to 2000.0Hz

**Description**

Defines the proportional gain of the position loop.

Defines the responsiveness of the position loop. A high setpoint shortens the positioning time.

Note that an excessively high setpoint may cause vibration. The torque reference filter time constant is called the 1st gain.

**H08.03 2nd speed loop gain**

Address: 0x0803

Effective mode: Real time

Min.: 0.1

Unit: Hz

Max.: 2000.0

Data Type: UInt16

Default: 75.0

Change: Immediately

**Value Range:**

0.1 Hz to 2000.0 Hz

**Description**

-

**H08.04 2nd speed loop integral time constant**

Address: 0x0804

Effective mode: Real time

Min.: 0.15

Unit: ms

Max.: 512.00

Data type: UInt16

Default: 10.61

Change: Immediately

**Value Range:**

0.15ms to 512.00ms

**Description**

-

**H08.05 2nd position loop gain**

Address: 0x0805

Effective mode: Real time

Min.: 0.1

Unit: Hz

Max.: 2000.0

Data Type: UInt16

Default: 120.0

Change: Real-time

**Value Range:**

0.1Hz to 2000.0Hz

**Description**

Defines the second gain set of the position loop and speed loop.  
The 2nd torque reference filter time constant is called 2nd gain.  
For details on gain switchover, see section "Gain Switchover".

**H08.08 2nd gain mode setting**

Address: 0x0808

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 1

Change: Real-time

**Value Range:**

0: Fixed to the 1st group of gains, P/PI switched through external  
DI1: Switched between the 1st and 2nd group of gains as defined by H08.09

**Description**

Defines the mode for switching to the 2nd gain set.

**H08.09 Gain switchover condition**

Address: 0x0809

Effective mode: Real time

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

- 0: Fixed to the 1st gain set (PS)
- 1: Switched as defined by Func3 of 60FEh
- 2: Torque reference too large (PS)
- 3: Speed reference too large (PS)
- 4: Speed reference change rate too large (PS)
- 5: Speed reference low/high speed threshold (PS)
- 6: Position deviation too large (P)
- 7: Position reference available (P)
- 8: Positioning unfinished (P)
- 9: Actual speed (P)
- 10: Position reference + Actual speed (P)

### Description

See the following table for gain switchover conditions.

Set point	Gain switchover condition	Remarks
0	Fixed to the 1st gain set	The 1st gain set applies.
1	DI (Func3) switchover	-
2	Torque reference too large	If the torque reference absolute value exceeds (Level + Dead time) [%] in the last 1st gain set, the drive switches to the 2nd gain set. If the absolute value of the torque reference is lower than (level – Dead time) [%] and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain, the drive returns to the 1st gain set.
3	Speed reference too large	If the speed reference absolute value exceeds (Level + Dead time) [rpm] in the last 1st gain set, the drive switches to the 2nd gain set. If the absolute value of the speed reference is lower than (level - Dead time) [rpm] and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain, the drive returns to the 1st gain set.
4	Speed reference too large	Active in the control modes other than speed control If the absolute value of the change rate of the speed reference exceeds (Level + Dead time) [10 rpm/s] in the last 1st gain set, the drive switches to the 2nd gain set. If the absolute value of the speed reference change rate is lower than (level – hysteresis) [10 rpm/s] and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain, the drive returns to the 1st gain set. In the speed control mode, the 1st gain set always applies.
5	Speed reference high/low-speed threshold	If the speed reference absolute value exceeds (Level - Dead time) [rpm] in the last 1st gain set, the drive starts to switch to the 2nd gain set, with gains changed gradually. When the speed reference absolute value reaches (Level + Dead time) [rpm], the 2nd gain set applies. If the speed reference absolute value is lower than (Level + Dead time) [rpm] in the last 2nd gain set, the drive starts to return to the 1st gain set, with gains changed gradually. When the speed reference absolute value reaches (Level - Dead time) [rpm], the 1st gain set applies.



Set point	Gain switchover condition	Remarks
6	Position deviation too large	Active only in position control and full closed-loop control. If the position deviation absolute value exceeds (Level + Dead time) [encoder unit] in the last 1st gain set, the drive switches to the 2nd gain set. When the absolute value of the position deviation is lower than (Level - Dead time) [encoder unit] and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain, the drive returns to the 1st gain set. If the drive is not in position control or full closed-loop control, the 1st gain set always applies.
7	Position reference available	Active only in position control and full closed-loop control. If the position reference is not 0 in the last 1st gain set, the drive switches to the 2nd gain set. When the position reference is 0 and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain, the drive returns to the 1st gain set. If the drive is not in position control or full closed-loop control, the 1st gain set always applies.
8	Positioning uncompleted	Active only in position control and full closed-loop control. If positioning has not been completed in the last 1st gain set, the drive switches to the 2nd gain set. If positioning is not completed and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain set, the servo drive returns to the 1st gain set. If the drive is not in position control or full closed-loop control, the 1st gain set always applies.
9	Actual speed	Active only in position control and full closed-loop control. If the absolute value of actual speed exceeds (Level + Dead time) [rpm] in the last 1st gain set, the drive switches to the 2nd gain set. If the absolute value of actual speed is lower than (Level - Dead time) [rpm] and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain set, the drive returns to the 1st gain set. If the drive is not in position control or full closed-loop control, the 1st gain set always applies.
10	Position reference + Actual speed	Active only in position control and full closed-loop control. If the position reference is not 0 in the last 1st gain set, the drive switches to the 2nd gain set. If the position reference is 0 and such status lasts within the delay defined by H08.10 (Gain switchover delay) in the 2nd gain set, the 2nd gain set applies. When the position reference is 0 and the delay defined by (H08.10) is reached, if the absolute value of actual speed is lower than (Level) [rpm], the speed loop integral time constant is fixed to the setpoint of H08.04 (2nd speed loop integral time constant), and others return to the 1st gain set; if the absolute value of actual speed does not reach (Level - Dead time) [rpm], the speed integral also returns to the setpoint of H08.01 (Speed loop integral time constant). If the drive is not in position control or full closed-loop control, the 1st gain set always applies.

## H08.10 Gain switchover delay

Address: 0x080A

Min.: 0.0

Max.: 1000.0

Default: 5.0

### Value Range:

0.0 ms to 1000.0 ms

Effective mode:

Unit: ms

Data Type: UInt16

Change: Real-time

**Description**

Defines the delay when the drive switches from the 2nd gain set to the 1st gain set.

**H08.11 Gain switchover level**

Address: 0x080B

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Real-time

Min.: 0  
Max.: 20000  
Default: 50

**Value Range:**

0 to 20000

**Description**

Defines the gain switchover level.

Defines the gain switchover level.

The unit of gain switchover level varies with the switchover condition.

**H08.12 Gain switchover hysteresis**

Address: 0x080C

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Real-time

Min.: 0  
Max.: 20000  
Default: 30

**Value Range:**

0 to 20000

**Description**

Defines the dead time for gain switchover.

Gain switchover is affected by both the level and the dead time.

The unit of gain switchover hysteresis varies with the switchover condition.

**H08.13 Position gain switchover time**

Address: 0x080D

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Real-time

Min.: 0.0  
Max.: 1000.0  
Default: 3.0

**Value Range:**

0.0 ms to 1000.0 ms

**Description**

In position control, if 2nd position loop gain is much higher than position loop gain, set the time for switching from the latter to the former.

This parameter can be used to reduce the impact caused by an increase in the position loop gain.

**H08.15 Load moment of inertia ratio**

Address: 0x080F

Effective      Real time  
mode:

Min.: 0.00

Unit: -

Max.: 120.00

Data Type: UInt16

Default: 1.00

Change: Real-time

**Value Range:**

0.00 to 120.00

**Description**

Defines the mechanical load inertia ratio relative to the motor moment of inertia. In online inertia auto-tuning, the servo drive sets the parameter automatically and manual setting is not allowed. Manual setting is allowed after online inertia auto-tuning is off.

**H08.17 Zero phase delay**

Address: 0x0811

Effective      Real time  
mode:

Min.: 0.0

Unit: ms

Max.: 4.0

Data Type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0 ms to 4.0ms

**Description**

-

**H08.18 Time constant of speed feedforward filter**

Address: 0x0812

Effective      Real time  
mode:

Min.: 0.00

Unit: ms

Max.: 64.00

Data Type: UInt16

Default: 0.50

Change: Immediately

**Value Range:**

0.00ms to 64.00ms

**Description**

Defines the filter time constant of speed feedforward.

**H08.19 Speed feedforward gain**

Address: 0x0813

Effective mode: Real time  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

Min.: 0.0  
 Max.: 100.0  
 Default: 0.0

**Value Range:**

0.0% to 100.0%

**Description**

Increasing the setpoint improves the responsiveness to position references and reduces the position deviation during operation at a constant speed.

**H08.20 Torque feedforward filter time constant**

Address: 0x0814

Effective mode: Real time  
 Unit: ms  
 Data type: UInt16  
 Change: Immediately

Min.: 0.00  
 Max.: 64.00  
 Default: 0.50

**Value Range:**

0.00ms to 64.00ms

**Description**

Defines the filter time constant of torque feedforward.

**H08.21 Torque feedforward gain**

Address: 0x0815

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Real-time

Min.: 0.0  
 Max.: 300.0  
 Default: 0.0

**Value Range:**

0.0%–300.0%

**Description**

Increasing the setpoint improves the responsiveness to variable speed references. Increasing the setpoint improves the responsiveness to position references and reduces the position deviation during operation at a constant speed.

**H08.22 Speed feedback filtering option**

Address: 0x0816

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16

Min.: 0  
 Max.: 4

Default: 0

Change: At stop

**Value Range:**

0: Inhibited

1: 2 times

2: 4 times

3: 8 times

4: 16 times

**Description**

Defines the moving average filtering times for speed feedback.

The higher the setpoint, the weaker the speed feedback fluctuation, but the longer the feedback delay will be.

**H08.23 Cutoff frequency of speed feedback low-pass filter**

Address: 0x0817

Effective      Real time  
mode:

Min.: 100

Unit: Hz

Max.: 8000

Data Type: UInt16

Default: 8000

Change: Real-time

**Value Range:**

100Hz to 8000Hz

**Description**

Defines the cutoff frequency for first-order low-pass filtering on the speed feedback.

**H08.24 PDFF control coefficient**

Address: 0x0818

Effective      Real time  
mode:

Min.: 0.0

Unit: %

Max.: 200.0

Data Type: UInt16

Default: 100.0

Change: Real-time

**Value Range:**

0.0%–200.0%

**Description**

Defines the control mode of the speed loop.

When the parameter is set to 200.0, PI control (default control mode of the speed loop) is applied to the speed loop, which features fast dynamic response. When this parameter is set to 0.0, speed loop integral action is enhanced, which filters out low-frequency interference but also slows down the dynamic response.

**H08.27 Speed observer cutoff frequency**

Address: 0x081B

Effective      Real time  
mode:

Min.:	50	Unit:	Hz
Max.:	600	Data Type:	UInt16
Default:	170	Change:	Immediately

**Value Range:**

50 Hz to 600 Hz

**Description**

-

**H08.28 Speed observer inertia correction coefficient**

Address:	0x081C	Effective mode:	Real time
Min.:	1	Unit:	%
Max.:	1600	Data Type:	UInt16
Default:	100	Change:	Immediately

**Value Range:**

1% to 1600%

**Description**

-

**H08.29 Speed observer filter time**

Address:	0x081D	Effective mode:	Real time
Min.:	0.00	Unit:	ms
Max.:	10.00	Data Type:	UInt16
Default:	0.80	Change:	Immediately

**Value Range:**

0.00ms to 10.00ms

**Description**

-

**H08.31 Disturbance cutoff frequency**

Address:	0x081F	Effective mode:	Real time
Min.:	10	Unit:	Hz
Max.:	4000	Data Type:	UInt16
Default:	600	Change:	Immediately

**Value Range:**

10 Hz to 4000 Hz

**Description**

-

**H08.32 Disturbance compensation gain**

Address: 0x0820

Effective mode: Real time  
Unit: %  
Data Type: UInt16  
Change: Immediately

Min.: 0  
Max.: 100  
Default: 0

**Value Range:**

0% to 100%

**Description**

-

**H08.33 Disturbance observer inertia correction coefficient**

Address: 0x0821

Effective mode: Real time  
Unit: %  
Data Type: UInt16  
Change: Immediately

Min.: 0  
Max.: 1600  
Default: 100

**Value Range:**

0% to 1600%

**Description**

-

**H08.37 Phase modulation for medium-frequency jitter suppression 2**

Address: 0x0825

Effective mode: Real time  
Unit: °  
Data Type: Int16  
Change: Immediately

Min.: -90  
Max.: 90  
Default: 0

**Value Range:**

-90° to 90°

**Description**

-

**H08.38 Medium-frequency suppression 2 frequency**

Address: 0x0826

Effective mode: Real time  
Unit: Hz  
Data Type: UInt16  
Change: Immediately

Min.: 0  
Max.: 1000  
Default: 0

**Value Range:**

0 Hz to 1000 Hz

**Description**

-

**H08.39 Compensation gain of medium-frequency jitter suppression 2**

Address: 0x0827

Effective mode: Real time

Min.: 0

Unit: %

Max.: 300

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0% to 300%

**Description**

-

**H08.40 Speed observer selection**

Address: 0x0828

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Disabled

1: Enabled

**Description**

-

**H08.42 Model control selection**

Address: 0x082A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Disable

1: Enable

2: Dual-inertia model

**Description**

-

**H08.43 Model gain**

Address: 0x082B

Effective mode: Real time



Min.:	0.1	Unit:	-
Max.:	2000.0	Data Type:	UInt16
Default:	40.0	Change:	Immediately
<b>Value Range:</b>			
0.1 to 2000.0			
<b>Description</b>			
-			

**H08.46 Feedforward value**

Address:	0x082E	Effective mode:	Real time
Min.:	0.0	Unit:	-
Max.:	102.4	Data Type:	UInt16
Default:	95.0	Change:	Immediately
<b>Value Range:</b>			
0.0 to 102.4			
<b>Description</b>			
-			

**H08.53 Medium- and low-frequency jitter suppression frequency 3**

Address:	0x0835	Effective mode:	Real time
Min.:	0.0	Unit:	Hz
Max.:	300.0	Data type:	UInt16
Default:	0.0	Change:	Immediately
<b>Value Range:</b>			
0.0 Hz to 300.0 Hz			
<b>Description</b>			
-			

**H08.54 Medium- and low-frequency jitter suppression compensation 3**

Address:	0x0836	Effective mode:	Real time
Min.:	0	Unit:	%
Max.:	200	Data Type:	UInt16
Default:	0	Change:	Immediately
<b>Value Range:</b>			
0% to 200%			
<b>Description</b>			
-			

**H08.56 Medium- and low-frequency jitter suppression phase modulation 3**

Address: 0x0838

Effective Real time

mode:

Min.: 0

Unit: %

Max.: 600

Data Type: UInt16

Default: 100

Change: Immediately

**Value Range:**

0% to 600%

**Description**

-

**H08.59 Medium- and low-frequency jitter suppression frequency 4**

Address: 0x083B

Effective Real time

mode:

Min.: 0.0

Unit: Hz

Max.: 300.0

Data type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0 Hz to 300.0 Hz

**Description**

-

**H08.60 Medium- and low-frequency jitter suppression compensation 4**

Address: 0x083C

Effective Real time

mode:

Min.: 0

Unit: %

Max.: 200

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0% to 200%

**Description**

-

**H08.61 Medium- and low-frequency jitter suppression phase modulation 4**

Address: 0x083D

Effective Real time

mode:

Min.: 0

Unit: %

Max.: 600

Data Type: UInt16

Default: 100

Change: Immediately

**Value Range:**

0% to 600%

**Description**

-

**H08.62 Position loop integral time constant**

Address: 0x083E	Effective mode:	Real time
Min.: 0.15	Unit:	-
Max.: 512.00	Data type:	UInt16
Default: 512.00	Change:	Immediately

**Value Range:**

0.15 to 512.00

**Description**

-

**H08.63 2nd position loop integral time constant**

Address: 0x083F	Effective mode:	Real time
Min.: 0.15	Unit:	-
Max.: 512.00	Data type:	UInt16
Default: 512.00	Change:	Immediately

**Value Range:**

0.15 to 512.00

**Description**

-

**H08.64 Speed observer feedback source**

Address: 0x0840	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0: Disabled

1: Enabled

**Description**

-

**H08.65 Zero deviation control selection**

Address: 0x0841	Effective mode:	Real time
Min.: 0	Unit:	-

Data Type: UInt16

Change: Immediately

0: Disabled

0: Disabled

1: Enabled

### Description

1

### H08.66 Zero deviation control position average filter

Effective	Real time
-----------	-----------

mode:

Unit: ms

Data Type: UInt16

Change: Immediately

**Value Range:**

0.0 ms to 320.0ms

### Description

### H08.68 Speed feedforward of zero deviation control

Effective	Real time
-----------	-----------

mode:

Unit: %

Data Type: UInt16

Change: Immediately

**Value Range:**

0.0% to 100.0%

### Description

1

### H08.69 Torque feedforward of zero deviation control

Effective      Real time

mode:

Unit: %

Data Type: UInt16

Change: Immediately

**Value Range:**

0.0% to 100.0%

### Description

**H08.81     Anti-resonance frequency of dual-inertia model**

Address: 0x0851	Effective mode:	Real time
Min.: 0.0	Unit:	Hz
Max.: 300.0	Data type:	UInt16
Default: 0.0	Change:	Immediately
<b>Value Range:</b> 0.0 Hz to 300.0 Hz		
<b>Description</b> -		

**H08.82     Resonance frequency of dual-inertia model**

Address: 0x0852	Effective mode:	Real time
Min.: 0.0	Unit:	Hz
Max.: 300.0	Data Type:	UInt16
Default: 0.0	Change:	Immediately
<b>Value Range:</b> 0.0 Hz to 300.0 Hz		
<b>Description</b> -		

**H08.83     Dual-inertia model gain**

Address: 0x0853	Effective mode:	Real time
Min.: 0.1	Unit:	Hz
Max.: 2000.0	Data Type:	UInt16
Default: 40.0	Change:	Immediately
<b>Value Range:</b> 0.1 Hz to 2000.0 Hz		
<b>Description</b> -		

**H08.84     Inertia ratio of dual-inertia model**

Address: 0x0854	Effective mode:	Real time
Min.: 0.00	Unit:	-
Max.: 120.00	Data Type:	UInt16
Default: 1.00	Change:	Immediately
<b>Value Range:</b> 0.00 to 120.00		

**Description**

-

**H08.88 Speed feedforward value of dual-inertia model**

Address: 0x0858

Effective mode: Real time

Min.: 0.0

Unit: -

Max.: 100.0

Data Type: UInt16

Default: 100.0

Change: Immediately

**Value Range:**

0.0 to 100.0

**Description**

-

**H08.89 Torque feedforward value of dual-inertia model**

Address: 0x0859

Effective mode: Real time

Min.: 0.0

Unit: -

Max.: 100.0

Data Type: UInt16

Default: 100.0

Change: Immediately

**Value Range:**

0.0 to 100.0

**Description**

-

**4.10 H09 Auto-tuning Parameters****H09.00 Auto-adjustment mode**

Address: 0x0900

Effective mode: Real time

Min.: 0

Unit: -

Max.: 6

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: Disabled, manual gain tuning required

1: Enabled, gain parameters generated automatically based on the stiffness level

2: Positioning mode, gain parameters generated automatically based on the stiffness level

4: Normal mode+Inertia auto-tuning

6: Quick positioning mode+Inertia auto-tuning

**Description**

2009-01h is set to 4 by default.

**H09.01 Stiffness level selection**

Address: 0x0901

Effective      Real time  
mode:  
Unit:          -  
Data Type:    UInt16  
Change:       Real-time

Min.:      0  
Max.:      41  
Default:   15

**Value Range:**

0 to 41

**Description**

Defines the stiffness level of the servo system. The higher the stiffness level, the stronger the gains and the quicker the response will be. But an excessively high stiffness level will cause vibration.

The setpoint 0 indicates the weakest stiffness and 41 indicates the strongest stiffness.

**H09.02 Adaptive notch mode**

Address: 0x0902

Effective      Real time  
mode:  
Unit:          -  
Data Type:    UInt16  
Change:       Real-time

Min.:      0  
Max.:      4  
Default:   3

**Value Range:**

- 0: Adaptive notch no longer updated;
- 1: One adaptive notch activated (3rd notch)
- 2: Two adaptive notches activated (3rd and 4th notches)
- 3: Resonance point tested only (displayed in H09.24)
- 4: Adaptive notch cleared, values of 3rd and 4th notches restored to default

**Description**

Defines the operation mode of the adaptive notch.

**H09.03 Online inertia auto-tuning mode**

Address: 0x0903

Effective      Real time  
mode:  
Unit:          -  
Data Type:    UInt16  
Change:       Real-time

Min.:      0  
Max.:      3  
Default:   2

**Value Range:**

- 0: Disabled
- 1: Enabled, changing slowly
- 2: Enabled, changing normally
- 3: Enabled, changing quickly

**Description**

Sets the offline inertia auto-tuning mode. For details on offline inertia auto-tuning, see section Offline Inertia Auto-tuning.

**H09.05 Offline inertia auto-tuning mode**

Address:	0x0905	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	1	Data type:	UInt16
Default:	1	Change:	At stop

**Value Range:**

- 0: Bi-directional
- 1: Unidirectional

**Description**

Sets the offline inertia auto-tuning mode. For details on offline inertia auto-tuning, see section Offline Inertia Auto-tuning.

**H09.06 Max. speed of inertia auto-tuning**

Address:	0x0906	Effective mode:	Real time
Min.:	100	Unit:	RPM
Max.:	1000	Data Type:	UInt16
Default:	500	Change:	At stop

**Value Range:**

100rpm–1000rpm

**Description**

Defines the maximum permissible speed reference in offline inertia auto-tuning mode.

During inertia auto-tuning, the higher the speed, the more accurate the auto-tuned values. Use the default setpoint in general cases.

**H09.07 Time constant for accelerating to max. speed during inertia auto-tuning**

Address:	0x0907	Effective mode:	Real time
Min.:	20	Unit:	ms
Max.:	800	Data Type:	UInt16
Default:	125	Change:	At stop



**Value Range:**

20 ms to 800 ms

**Description**

Defines the time for the motor to accelerate from 0 rpm to the maximum speed of inertia auto-tuning during offline inertia auto-tuning.

**H09.08 Interval time after an individual inertia auto-tuning**

Address:	0x0908	Effective mode:	Real time
Min.:	50	Unit:	ms
Max.:	10000	Data Type:	UInt16
Default:	800	Change:	At stop

**Value Range:**

50 ms to 10000 ms

**Description**

Defines the time interval between two consecutive speed references when bi-directional offline inertia auto-tuning mode is used.

**H09.09 Number of motor revolutions per inertia auto-tuning**

Address:	0x0909	Effective mode:	Real time
Min.:	0.00	Unit:	-
Max.:	100.00	Data Type:	UInt16
Default:	1.00	Change:	Real-time

**Value Range:**

0.00 to 100.00

**Description**

Displays the number of motor revolutions needed when bi-directional offline inertia auto-tuning mode is used.

**H09.11 Vibration threshold**

Address:	0x090B	Effective mode:	Real time
Min.:	0.0	Unit:	%
Max.:	100.0	Data Type:	UInt16
Default:	5.0	Change:	Immediately

**Value Range:**

0.0% to 100.0%

**Description**

Defines the threshold of vibration detected by the notch. When the current feedback exceeds the threshold, the notch starts working.

**H09.12 Frequency of the 1st notch**

Address: 0x090C

Effective	Real time
mode:	
Unit:	Hz
Data Type:	UInt16
Change:	Real-time

Min.: 50  
Max.: 8000  
Default: 8000

**Value Range:**

50Hz to 8000Hz

**Description**

Defines the center frequency of the notch, which is the mechanical resonance frequency.

In the torque control mode, setting the notch frequency to 8000Hz deactivates the notch function.

**H09.13 Width level of the 1st notch**

Address: 0x090D

Effective	Real time
mode:	
Unit:	-
Data Type:	UInt16
Change:	Real-time

Min.: 0  
Max.: 20  
Default: 2

**Value Range:**

0 to 20

**Description**

Defines the width level of the notch. Use the default setpoint in general cases. Width level is the ratio of the notch width to the notch center frequency.

**H09.14 Depth level of the 1st notch**

Address: 0x090E

Effective	Real time
mode:	
Unit:	-
Data Type:	UInt16
Change:	Real-time

Min.: 0  
Max.: 99  
Default: 0

**Value Range:**

0 to 99

### Description

Defines the depth level of the notch.

The depth level of the notch is the ratio between the input to the output at the notch center frequency.

The higher the setpoint, the lower the notch depth and the weaker the mechanical resonance suppression will be. Note that an excessively high setpoint may cause system instability.

For use of notches, see section "Vibration Suppression" in SV660P Series Servo Drive Function Guide.

#### H09.15 Frequency of the 2nd notch

Address: 0x090F

Min.: 50  
Max.: 8000  
Default: 8000

##### Value Range:

50 Hz to 8000 Hz

##### Description

-

Effective mode:  
Unit: Hz  
Data Type: UInt16  
Change: Immediately

#### H09.16 Width level of the 2nd notch

Address: 0x0910

Min.: 0  
Max.: 20  
Default: 2

##### Value Range:

0 to 20

##### Description

-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Immediately

#### H09.17 Depth level of the 2nd notch

Address: 0x0911

Min.: 0  
Max.: 99  
Default: 0

##### Value Range:

0 to 99

Effective mode:  
Unit: -  
Data type: UInt16  
Change: Immediately

**Description**

Descriptions for parameters of the 2nd notch are the same as that of the 1st notch.

**H09.18 Frequency of the 3rd notch**

Address: 0x0912

Min.: 50  
Max.: 8000  
Default: 8000

**Value Range:**

50 Hz to 8000 Hz

**Description**

-

Effective mode: Real time  
Unit: Hz  
Data Type: UInt16  
Change: Immediately

**H09.19 Width level of the 3rd notch**

Address: 0x0913

Min.: 0  
Max.: 20  
Default: 2

**Value Range:**

0 to 20

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H09.20 Depth level of the 3rd notch**

Address: 0x0914

Min.: 0  
Max.: 99  
Default: 0

**Value Range:**

0 to 99

**Description**

Descriptions for parameters of the 3rd notch are the same as that of the 1st notch.

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

**H09.21 Frequency of the 4th notch**

Address: 0x0915

Min.: 50

Effective mode: Real time  
Unit: Hz

Max.: 8000

Default: 8000

**Value Range:**

50 Hz to 8000 Hz

**Description**

-

Data Type: UInt16

Change: Immediately

**H09.22 Width level of the 4th notch**

Address: 0x0916

Min.: 0

Max.: 20

Default: 2

**Value Range:**

0 to 20

**Description**

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Immediately

**H09.23 Depth level of the 4th notch**

Address: 0x0917

Min.: 0

Max.: 99

Default: 0

**Value Range:**

0 to 99

**Description**

Descriptions for parameters of the 4th notch are the same as that of the 1st notch.

Effective mode: Real time

Unit: -

Data type: UInt16

Change: Immediately

**H09.24 Auto-tuned resonance frequency**

Address: 0x0918

Min.: 0

Max.: 5000

Default: 0

**Value Range:**

0 Hz to 5000 Hz

**Description**

When adaptive notch mode is set to 3, the current mechanical resonance frequency is displayed.

Effective mode: -

Unit: Hz

Data type: UInt16

Change: Unchangeable

**H09.26 ITune response**

Address: 0x091A

Min.: 50.0

Max.: 500.0

Default: 100.0

**Value Range:**

50.0% to 500.0%

**Description**

-

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

**H09.27 ITune mode**

Address: 0x091B

Min.: 0

Max.: 2

Default: 0

**Value Range:**

0: Disabled

1: ITune mode 1

2: ITune mode 2

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H09.28 Minimum inertia ratio of ITune**

Address: 0x091C

Min.: 0.0

Max.: 80.0

Default: 0.0

**Value Range:**

0.0% to 80.0%

**Description**

-

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

**H09.29 Maximum inertia ratio of ITune**

Address: 0x091D

Min.: 1.0

Max.: 120.0

Default: 30.0

**Value Range:**

Effective mode: Real time  
 Unit: %  
 Data Type: UInt16  
 Change: Immediately

1.0% to 120.0%

**Description**

-

**H09.32 Gravity compensation value**

Address: 0x0920

Effective mode: Real time

Min.: 0.0

Unit: %

Max.: 100.0

Data Type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0% to 100.0%

**Description**

-

**H09.33 Positive friction compensation value**

Address: 0x0921

Effective mode: Real time

Min.: 0.0

Unit: %

Max.: 100.0

Data Type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0% to 100.0%

**Description**

-

**H09.34 Negative friction compensation value**

Address: 0x0922

Effective mode: Real time

Min.: -100

Unit: %

Max.: 0.0

Data Type: Int16

Default: 0.0

Change: Immediately

**Value Range:**

-100.0% to 0.0%

**Description**

-

**H09.35 Friction compensation speed**

Address: 0x0923

Effective mode: Real time

Min.: 0.0

Unit: -

Max.: 20.0

Default: 2.0

**Value Range:**

0.0 to 20.0

**Description**

-

Data Type: UInt16

Change: Immediately

**H09.36 Friction compensation speed**

Address: 0x0924

Effective mode: Real time

Min.: 0

Unit: -

Max.: 19

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: 0x00 Slow mode+Speed reference

0: 0x01 Slow mode+Model speed

0: 0x02 Slow mode+Speed feedback

0: 0x03 Slow mode+Observe speed

0: 0x10 Quick mode +Speed reference

0: 0x11 Quick mode +Model speed

0: 0x12 Quick mode +Speed feedback

0: 0x13 Quick mode+Observe speed

**Description**

Selects the setpoint.

**H09.37 Vibration monitoring time**

Address: 0x0925

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 600

Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H09.38 Frequency of low-frequency resonance suppression 1 at the mechanical end**

Address: 0x0926

Effective mode: Real time

Min.: 1.0

Unit: Hz

Max.: 100.0

Data type: UInt16



Default: 100.0

Change: Immediately

**Value Range:**

1.0 Hz to 100.0 Hz

**Description**

-

**H09.39 Low-frequency resonance suppression 1 at the mechanical end**

Address: 0x0927

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 2

Change: At stop

**Value Range:**

0 to 3

**Description**

-

**H09.44 Frequency of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092C

Effective Real time

mode:

Min.: 0.0

Unit: -

Max.: 100.0

Data Type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0 to 100.0

**Description**

-

**H09.45 Responsiveness of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092D

Effective Real time

mode:

Min.: 0.01

Unit: -

Max.: 5.00

Data Type: UInt16

Default: 1.00

Change: Immediately

**Value Range:**

0.01 to 5.00

**Description**

-

**H09.47 Width of low-frequency resonance suppression 2 at mechanical load end**

Address: 0x092F

Effective Real time

mode:

Min.: 0.00

Unit: -

Max.: 2.00

Data Type: UInt16

Default: 1.00

Change: Immediately

**Value Range:**

0.00 to 2.00

**Description**

-

**H09.49 Frequency of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0931

Effective Real time

mode:

Min.: 0.0

Unit: -

Max.: 100.0

Data Type: UInt16

Default: 0.0

Change: Immediately

**Value Range:**

0.0 to 100.0

**Description**

-

**H09.50 Responsiveness of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0932

Effective Real time

mode:

Min.: 0.01

Unit: -

Max.: 5.00

Data Type: UInt16

Default: 1.00

Change: Immediately

**Value Range:**

0.01 to 5.00

**Description**

-

**H09.52 Width of low-frequency resonance suppression 3 at mechanical load end**

Address: 0x0934

Effective Real time

mode:

Min.: 0.00

Unit: -

Max.: 2.00

Data Type: UInt16

Default: 1.00

Change: Immediately

**Value Range:**

0.00 to 2.00

## Description

-

### H09.54 Vibration threshold

Address: 0x0936

Effective mode: Real time  
Unit: %  
Data Type: UInt16  
Change: Real-time

Min.: 0.0  
Max.: 300.0  
Default: 50.0

#### Value Range:

0.0%–300.0%

#### Description

Defines the threshold of vibration detected by the notch. When the current feedback exceeds the threshold, the notch starts working.

### H09.56 Max. overshoot allowed by ETune

Address: 0x0938

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

Min.: 0  
Max.: 65535  
Default: 2936

#### Value Range:

0 to 65535

#### Description

-

### H09.57 STune resonance suppression switchover frequency

Address: 0x0939

Effective mode: Real time  
Unit: Hz  
Data type: UInt16  
Change: Immediately

Min.: 0  
Max.: 4000  
Default: 900

#### Value Range:

0 Hz to 4000 Hz

#### Description

-

### H09.58 STune resonance suppression reset selection

Address: 0x093A

Effective mode: Real time  
Unit: -

Min.: 0

Max.: 1	Data Type: UInt16
Default: 0	Change: Immediately
<b>Value Range:</b>	
0: Disabled	
1: Enabled	
<b>Description</b>	
-	

## 4.11 H0A Fault and Protection Parameters

### H0A.00 Power input phase loss protection

Address: 0x0A00	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 2	Data Type:	UInt16
Default: 0	Change:	Real-time

**Value Range:**

0: Enable

1: Disable

**Description**

Servo drives supporting single-phase/three-phase 220 V and three-phase 380 V power supplies Objects available. When voltage fluctuation or phase loss occurs on the power supply, the drive triggers power input phase loss protection according to the setting.

### H0A.01 Absolute position limit

Address: 0x0A01	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 2	Data Type:	UInt16
Default: 0	Change:	Real-time

**Value Range:**

0: Disabled

1: Enabled

2: Enabled after homing

### Description

Defines whether the absolute position limit is active and the condition for activation.

- After the absolute position limit is enabled, when the target position reference exceeds the position limit in the position control mode, the servo drive takes the position limit as the target and stops after reaching the limit.
- When the absolute position feedback reaches the position limit in other control modes, the servo drive reports an overtravel warning and stops in the mode defined by the set stop mode at overtravel.

### H0A.04 Motor overload protection gain

Address: 0x0A04

Min.: 50  
Max.: 300  
Default: 100

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Real-time

#### Value Range:

50 to 300

### Description

Defines the motor overload duration before E620.0 (Motor overload fault) is reported.

You can change the setpoint to advance or delay the time when overload protection is triggered based on the motor temperature. The setpoint 50% indicates the time is cut by half; 150% indicates the time is increased by 50%. Set this parameter based on the actual temperature of the motor.

### H0A.08 Overspeed threshold

Address: 0x0A08

Min.: 0  
Max.: 20000  
Default: 0

Effective mode: Real time  
Unit: RPM  
Data Type: UInt16  
Change: Real-time

#### Value Range:

0rpm–20000rpm

**Description**

Defines the overspeed threshold of the motor.

Setpoint	Threshold	Condition for Reporting E500.0
0	Maximum motor speed x 1.2	If the speed feedback exceeds the overspeed threshold several times, the drive reports E500.0 (Motor overspeed).
1 to 20000	If H0A-08 $\geq$ (Maximum motor speed x 1.2): Overspeed threshold = Maximum motor speed x 1.2	
	If H0A-08 < (Maximum motor speed x 1.2): Overspeed threshold = H0A.08	

**H0A.09 Max. pulse input frequency in position control**

Address: 0x0A09

Effective Real time

mode:

Min.: 100

Unit: kHz

Max.: 8000

Data type: UInt16

Default: 8000

Change: At stop

**Value Range:**

100 kHz to 8000 kHz

**Description**

-

**H0A.10 Threshold of excessive local position deviation**

Address: 0x0A0A

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 25185824

Change: Real-time

**Value Range:**

0 to 4294967295

**Description**

Defines the threshold for reporting EB00.0 (Position deviation too large). The function of 200A-0Bh is the same as 6065h (Following error window), both of which are active.

**H0A.12 Runaway protection enable**

Address: 0x0A0C

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 1

Change: Immediately

**Value Range:**

0: Disable

1: Enable

**Description**

Used to enable runaway protection.

**H0A.17 Reference unit**

Address: 0x0A11

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Pulse unit

1: Reference unit

**Description**

-

**H0A.18 IGBT over-temperature threshold**

Address: 0x0A12

Effective mode: Real time

Min.: 120

Unit: °C

Max.: 175

Data Type: UInt16

Default: 140

Change: Immediately

**Value Range:**

120°C to 175°C

**Description**

Defines the over-temperature protection threshold of the power module.

**H0A.19 Filter time constant of touch probe 1**

Address: 0x0A13

Effective mode: Real time

Min.: 0.00

Unit: us

Max.: 6.30

Data type: UInt16

Default: 2.00

Change: Immediately

**Value Range:**

0.00us–6.30us

**Description**

-

**H0A.20 Filter time constant of touch probe 2**

Address: 0x0A14

Effective mode: Real time

Min.: 0.00

Unit: us

Max.: 6.30

Data Type: UInt16

Default: 2.00

Change: Real-time

**Value Range:**

0.00us–6.30us

**Description**

Probe 1 and Probe 2 are high speed DI terminals. When there is peak interference in the external input signal, note that the oscilloscope in the software tool displays the unfiltered signals of touch probe 1 and touch probe 2. Signals with width lower than 0.25 ms will not be displayed.

**H0A.23 TZ signal filter time**

Address: 0x0A17

Effective mode: Upon the next power-on

Min.: 0

Unit: 25ns

Max.: 31

Data Type: UInt16

Default: 15

Change: At stop

**Value Range:**

0ns to 31ns

**Description**

-

**H0A.24 Filter time constant of low-speed pulse input terminal**

Address: 0x0A18

Effective mode: Upon the next power-on

Min.: 0

Unit: 25ns

Max.: 255

Data type: UInt16

Default: 30

Change: At stop

**Value Range:**

025ns to 25525ns

**Description**

-

**H0A.26 Motor overload detection**

Address: 0x0A1A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Real-time



**Value Range:**

0: Show motor overload warning (E909.0) and fault (E620.0)

1: Hide motor overload warning (E909.0) and fault (E620.0)

**Description**

Defines whether to enable motor overload detection.

**H0A.27 Motor rotation DO speed filter time**

Address: 0x0A1B	Effective mode:	Real time
Min.: 0	Unit:	ms
Max.: 100	Data Type:	UInt16
Default: 50	Change:	At stop

**Value Range:**

0 ms to 100 ms

**Description**

Defines the low-pass filter time constant of speed feedback signals.

This parameter is effective only when the speed feedback signals are used to judge the speed-related DO signals.

**H0A.29 Fully closed-loop encoder (ABZ) filter time**

Address: 0x0A1D	Effective mode:	Upon the next power-on
Min.: 0	Unit:	25ns
Max.: 255	Data type:	UInt16
Default: 15	Change:	At stop

**Value Range:**

025ns to 25525ns

**Description**

-

**H0A.30 Filter time constant of high-speed pulse input terminal**

Address: 0x0A1E	Effective mode:	Upon the next power-on
Min.: 0	Unit:	ns
Max.: 255	Data type:	UInt16
Default: 3	Change:	At stop

**Value Range:**

0ns to 255ns

**Description**

-

**H0A.32 Time threshold for locked motor overheat protection**

Address:	0x0A20	Effective mode:	Real time
Min.:	10	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	200	Change:	Real-time

**Value Range:**

10 ms to 65535 ms

**Description**

Defines the overtemperature duration before E630.0 (Motor stall) is detected by the servo drive.

**H0A.33 Locked motor overheat protection**

Address:	0x0A21	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	1	Data type:	UInt16
Default:	1	Change:	Immediately

**Value Range:**

0: Disabled

1: Enabled

**Description**

Defines whether to enable the detection for E630.0 (Motor stall overtemperature protection).

**H0A.36 Encoder multi-turn overflow fault selection**

Address:	0x0A24	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

0: Not hide

1: Hide

**Description**

Defines whether to hide E735.0 (Encoder multi-turn counting overflow) in the absolute position linear mode.

**H0A.39 Current sampling clock signal tolerance count**

Address:	0x0A27	Effective mode:	Upon the next power-on
Min.:	0	Unit:	-

Max.: 3

Default: 0

**Value Range:**

0 to 3

**Description**

-

Data Type: UInt16

Change: At stop

#### H0A.40 Compensation function selection

Address: 0x0A28

Effective mode: Real time

Min.: 0

Unit: -

Max.: 15

Data Type: UInt16

Default: 6

Change: At stop

**Value Range:**

bit	Name	Description
0	Overtravel compensation	0: Enabled
		1: Disabled
1	Probe rising edge compensation	0: Disabled
		1: Enabled
2	Probe falling edge compensation	0: Disabled
		1: Enabled
3	Probe solution	0: New solution
		1: Old solution (same as SV660N)

**Description**

-

#### H0A.41 Forward position of software position limit

Address: 0x0A29

Effective mode: Real time

Min.: -2147483648

Unit: Encoder unit

Max.: 2147483647

Data Type: Int32

Default: 2147483647

Change: At stop

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H0A.43 Reverse position of software position limit**

Address: 0x0A2B

Effective mode: Real time

Min.: -2147483648

Unit: Encoder unit

Max.: 2147483647

Data Type: Int32

Default: -2147483648

Change: At stop

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H0A.49 Regenerative resistor overtemperature threshold**

Address: 0x0A31

Effective mode: Real time

Min.: 100

Unit: °C

Max.: 175

Data Type: UInt16

Default: 115

Change: Immediately

**Value Range:**

100°C to 175°C

**Description**

-

**H0A.50 Encoder communication fault tolerance threshold**

Address: 0x0A32

Effective mode: Real time

Min.: 0

Unit: -

Max.: 31

Data Type: UInt16

Default: 3

Change: Immediately

**Value Range:**

0 to 31

**Description**

-

**H0A.51 Phase loss detection filter times**

Address: 0x0A33

Effective mode: Real time

Min.:	3	Unit:	55ms
Max.:	36	Data Type:	UInt16
Default:	20	Change:	Immediately

**Value Range:**

3ms to 36ms

**Description**

-

**H0A.52 Encoder temperature protection threshold**

Address:	0x0A34	Effective mode:	Real time
Min.:	0	Unit:	°C
Max.:	175	Data Type:	UInt16
Default:	105	Change:	Immediately

**Value Range:**

0°C to 175°C

**Description**

0: Disable

**H0A.53 Probe DI ON compensation time**

Address:	0x0A35	Effective mode:	Real time
Min.:	-3000	Unit:	25ns
Max.:	3000	Data Type:	Int16
Default:	128	Change:	Immediately

**Value Range:**

-3000ns to 3000ns

**Description**

-

**H0A.54 Probe DI OFF compensation time**

Address:	0x0A36	Effective mode:	Real time
Min.:	-3000	Unit:	25ns
Max.:	3000	Data Type:	Int16
Default:	1512	Change:	Immediately

**Value Range:**

-3000ns to 3000ns

**Description**

-

**H0A.55 Runaway current threshold**

Address: 0x0A37

Min.: 100.0

Max.: 400.0

Default: 200.0

**Value Range:**

100.0% to 400.0%

**Description**

-

Effective mode:  
Unit: %  
Data type: UInt16  
Change: Immediately

**H0A.56 Fault reset delay**

Address: 0x0A38

Min.: 0

Max.: 60000

Default: 10000

**Value Range:**

0 ms to 60000 ms

**Description**

Faults E620.0, E630.0, E640.0, E640.1, and E650.0 can be reset only after the set delay.

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Real-time

**H0A.57 Runaway speed threshold**

Address: 0x0A39

Min.: 1

Max.: 1000

Default: 50

**Value Range:**

1rpm–1000rpm

**Description**

-

Effective mode:  
Unit: RPM  
Data Type: UInt16  
Change: Immediately

**H0A.58 Runaway speed filter time**

Address: 0x0A3A

Min.: 0.1

Max.: 100.0

Default: 2.0

**Value Range:**

0.1ms to 100.0ms

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Immediately

Upon the next power-on

Description

-

H0A.59 Runaway protection detection time

Address:	0x0A3B	Effective mode:	Real time
Min.:	10	Unit:	ms
Max.:	1000	Data Type:	UInt16
Default:	30	Change:	Immediately

**Value Range:**  
10ms to 1000ms

Description

-

H0A.60 Black box function mode

Address:	0x0A3C	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	3	Data type:	UInt16
Default:	1	Change:	Immediately

**Value Range:**  
0: Disable  
1: Any fault  
2: Designated fault  
3: Triggered based on designated condition

Description

-

H0A.61 Designated fault code

Address:	0x0A3D	Effective mode:	Real time
Min.:	0.0	Unit:	-
Max.:	6553.5	Data Type:	UInt16
Default:	0.0	Change:	Immediately

**Value Range:**  
0.0 to 6553.5

Description

-

H0A.62 Trigger source

Address:	0x0A3E	Effective mode:	Real time
----------	--------	-----------------	-----------

Min.: 0	Unit: -
Max.: 25	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0 to 25

**Description**

-

**H0A.63 Trigger level**

Address: 0x0A3F

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H0A.65 Trigger level**

Address: 0x0A41

Effective mode: Real time

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Rising edge

1: Equal

2: Falling edge

3: Edge-triggered

**Description**

-

**H0A.66 Trigger position**

Address: 0x0A42

Effective mode: Real time

Min.: 0

Unit: %

Max.: 100

Data Type: UInt16

Default: 75

Change: Immediately

**Value Range:**

0% to 100%



**Description**

-

**H0A.67    Sampling frequency**

Address: 0x0A43	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 2	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

- 0: Current loop
- 1: Position loop
- 2: Main cycle

**Description**

-

**H0A.70    Overspeed threshold 2**

Address: 0x0A46	Effective mode:	Real time
Min.: 0	Unit:	RPM
Max.: 20000	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0rpm–20000rpm

**Description**

-

**H0A.71    MS1 motor overload curve switchover**

Address: 0x0A47	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 3	Data Type:	UInt16
Default: 2	Change:	Immediately

**Value Range:**

0 to 3

**Description**

-

**H0A.72    Maximum stop time in ramp-to-stop**

Address: 0x0A48	Effective mode:	Real time
-----------------	-----------------	-----------

Min.:	0	Unit:	ms
Max.:	65535	Data Type:	UInt16
Default:	10000	Change:	At stop

**Value Range:**

0 ms to 65535 ms

**Description**

Defines the maximum time taken by the motor in decelerating from 6000 RPM to 0 RPM under ramp stop.

**H0A.73 STO 24 V disconnection filter time**

Address: 0x0A49

Effective mode:	Real time
-----------------	-----------

Min.: 1

Unit: ms

Max.: 5

Data Type: UInt16

Default: 5

Change: Immediately

**Value Range:**

1ms to 5ms

**Description**

-

**H0A.74 Filter time for two inconsistent STO channels**

Address: 0x0A4A

Effective mode:	Real time
-----------------	-----------

Min.: 0

Unit: ms

Max.: 1000

Data Type: UInt16

Default: 100

Change: Immediately

**Value Range:**

0ms to 1000ms

**Description**

-

**H0A.75 Servo OFF delay after STO triggered**

Address: 0x0A4B

Effective mode:	Real time
-----------------	-----------

Min.: 0

Unit: ms

Max.: 25

Data Type: UInt16

Default: 10

Change: Immediately

**Value Range:**

0ms to 25ms

**Description**

-

**H0A.90 Average filter time constant for speed display**

Address: 0x0A5A	Effective mode:	Real time
Min.: 0	Unit:	ms
Max.: 100	Data Type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0ms to 100ms

**Description**

-

**H0A.91 Average filter time constant for torque display**

Address: 0x0A5B	Effective mode:	Real time
Min.: 0	Unit:	ms
Max.: 100	Data Type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0ms to 100ms

**Description**

-

**H0A.92 Average filter time constant for position display**

Address: 0x0A5C	Effective mode:	Real time
Min.: 0	Unit:	ms
Max.: 100	Data Type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0ms to 100ms

**Description**

-

**H0A.93 Low-pass filter time constant for voltage display**

Address: 0x0A5D	Effective mode:	Real time
Min.: 0	Unit:	ms
Max.: 250	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0ms to 250ms

**Description**

-

**H0A.94 Low-pass filter time constant for thermal display**

Address: 0x0A5E

Effective Real time

mode:

Min.: 0

Unit: ms

Max.: 250

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0ms to 250ms

**Description**

-

**4.12 H0b Monitoring Parameters****H0b.00 Motor speed actual value**

Address: 0x0B00

Effective -

mode:

Min.: -32767

Unit: RPM

Max.: 32767

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-32767rpm to 32767rpm

**Description**

It displays the actual speed of the servo motor after round-off, in unit of 1 RPM. You can set the filter time constant for H0B-00 in filter time constant of speed feedback display.

**H0b.01 Speed reference**

Address: 0x0B01

Effective -

mode:

Min.: -32767

Unit: RPM

Max.: 32767

Data type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-32767 RPM to 32767 RPM

**Description**

Local speed mode, speed reference

**H0b.02 Internal torque reference**

Address: 0x0B02

Effective -  
mode:  
Unit: %  
Data Type: Int16  
Change: Unchangeable

Min.: -500

Max.: 500.0

Default: 0.0

**Value Range:**

-500.0% to 500.0%

**Description**

Displays present torque reference (accurate to 0.1%). The value 100.0% corresponds to the rated torque of the motor.

**H0b.03 Input (DI) signal monitoring**

Address: 0x0B03

Effective -  
mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535


**Description**

Indicates the level status of DI1 to DI5 without filtering.

Upper LED segments ON: high level (indicated by "1") Lower LED segments ON: low level (indicated by "0")

For example, if DI1 is low level and DI2 to DI5 are high level, and the binary value is 11110, then the decimal value read from Inovance servo commissioning software is 30.

The panel display is as follows:



**H0b.05 Output (DO) signal monitoring**

Address: 0x0B05

Effective -  
mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

Min.: 0

Max.: 65535

Default: 0

**Value Range:**


0 to 65535

### Description

It displays the level states of the 3 DO terminals without filtering.

Upper LED segments ON: high level (indicated by "1") Lower LED segments ON: low level (indicated by "0")

For example, if DO1 is low level and DO2 to DO3 are high level, and the binary value is 110, then the decimal value of H0B-05 read from Inovance servo commissioning software is 6, and the keypad displays the following figure:  
The panel display is as follows:



## H0b.07 Absolute position counter

Address: 0x0B07

Effective -  
mode:

Min.: -2147483648

Unit: p

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

### Value Range:

-2147483648p to 2147483647p

### Description

It displays the current motor absolute position (reference unit) in the position control mode.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

## H0b.09 Mechanical angle

Address: 0x0B09

Effective -  
mode:

Min.: 0.0

Unit: °

Max.: 360.0

Data Type: UInt16

Default: 0.0

Change: Unchangeable

### Value Range:

0.0° to 360.0°

### Description

Displays present mechanical angle (encoder unit) of the motor. The setpoint 0 indicates the mechanical angle is 0°.

**H0b.10 Electrical angle**

Address: 0x0B0A

Effective -

mode:

Min.: 0.0

Unit: °

Max.: 360.0

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0° to 360.0°

**Description**

Indicates the present electrical angle of the motor, which is accurate to 0.1°.

The electrical angle varies from -360° to +360.0° when the motor is rotating.

Similarly, if the motor has 4 pairs of poles, each revolution generates 4 rounds of angle changes from 0° to 359.9°.

Also, if the motor has 5 pairs of poles, each revolution generates 5 rounds of angle changes from 0° to 359.9°.

**H0b.12 Average load ratio**

Address: 0x0B0C

Effective -

mode:

Min.: 0.0

Unit: %

Max.: 800.0

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0%–800.0%

**Description**

Displays the percentage of the average load torque to the rated torque of the motor, which is accurate to 0.1%. The value 100.0% corresponds to the rated torque of the motor.

**H0b.13 Input reference counter**

Address: 0x0B0D

Effective -

mode:

Min.: -2147483648

Unit: p

Max.: 2147483647

Data type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

-

**H0b.15 Position following error (encoder unit)**

Address: 0x0B0F	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

Used to count the position pulses fed back by the encoder in any control mode.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

**H0b.17 Feedback pulse counter**

Address: 0x0B11	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

-

**H0b.19 Total power-on time**

Address: 0x0B13	Effective mode:	-
Min.: 0.0	Unit:	-
Max.: 429496729.5	Data Type:	UInt32
Default: 0.0	Change:	Unchangeable

**Value Range:**

0.0s–429496729.5s

**Description**

Used to record the total operating time of the servo drive.

This parameter is a 32-bit integer, which is displayed as a decimal on the keypad.

**H0b.24 Phase current RMS value**

Address: 0x0B18	Effective mode:	-
Min.: 0.0	Unit:	A
Max.: 6553.5	Data type:	UInt16
Default: 0.0	Change:	Unchangeable



**Value Range:**

0.0 A to 6553.5 A

**Description**

Displays the RMS value of the phase current of the motor, accurate to 0.1 A.

**H0b.25 Angle obtained upon voltage injection auto-tuning**

Address: 0x0B19

Effective -

mode:

Min.: 0.0

Unit: °

Max.: 360.0

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0° to 360.0°

**Description**

-

**H0b.26 Bus voltage**

Address: 0x0B1A

Effective -

mode:

Min.: 0.0

Unit: V

Max.: 6553.5

Data Type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0V to 6553.5V

**Description**

Displays the DC bus voltage of the main circuit input voltage after rectification, which is accurate to 0.1V.

**H0b.27 Module temperature**

Address: 0x0B1B

Effective -

mode:

Min.: -20

Unit: °C

Max.: 200

Data type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

-20°C to 200°C

**Description**

Indicates the temperature of the module inside the servo drive, which can be used as a reference for estimating the actual temperature of the drive.

**H0b.28 Absolute encoder fault information given by FPGA**

Address:	0x0B1C	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable
<b>Value Range:</b>			
0 to 65535			
<b>Description</b>			
-			

**H0b.29 Axis status information given by FPGA**

Address:	0x0B1D	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable
<b>Value Range:</b>			
0 to 65535			
<b>Description</b>			
-			

**H0b.30 Axis fault information given by FPGA**

Address:	0x0B1E	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable
<b>Value Range:</b>			
0 to 65535			
<b>Description</b>			
-			

**H0b.31 Encoder fault information**

Address:	0x0B1F	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately
<b>Value Range:</b>			
0 to 65535			

**Description**

-

**H0b.33 Fault log**

Address: 0x0B21

Effective -

mode:

Min.: 0

Unit: -

Max.: 20

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: Present fault

1: Last fault

2: 2nd to last fault

3: 3rd to last fault

4: 4th to last fault

5: 5th to last fault 6: 6th to last fault

7: 7th to last fault

8: 8th to last fault

9: 9th to last fault

10: 10th to last fault

11: 11th to last fault

12: 12th to last fault

13: 13th to last fault

14: 14th to last fault

15: 15th to last fault

16: 16th to last fault

17: 17th to last fault

18: 18th to last fault

19: 19th to last fault

**Description**

Used to view any one of the latest 10 faults that occurred on the servo drive.

**H0b.34 Fault code set by H0B-33**

Address: 0x0B22

Effective -

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.35 Timestamp of the selected fault**

Address: 0x0B23	Effective mode:	-
Min.: 0.0	Unit:	-
Max.: 429496729.5	Data type:	UInt32
Default: 0.0	Change:	Unchangeable

**Value Range:**  
0.0s–429496729.5s

**Description**  
-

**H0b.37 Motor speed upon occurrence of the selected fault**

Address: 0x0B25	Effective mode:	-
Min.: -32767	Unit:	RPM
Max.: 32767	Data type:	Int16
Default: 0	Change:	Unchangeable

**Value Range:**  
-32767rpm to 32767rpm

**Description**  
-

**H0b.38 Motor phase U current upon occurrence of the selected fault**

Address: 0x0B26	Effective mode:	-
Min.: -3276.7	Unit:	A
Max.: 3276.7	Data Type:	Int16
Default: 0.0	Change:	Unchangeable

**Value Range:**  
-3276.7A to 3276.7A

**Description**  
-

**H0b.39 Motor phase V current upon occurrence of the selected fault**

Address: 0x0B27	Effective mode:	-
Min.: -3276.7	Unit:	A
Max.: 3276.7	Data Type:	Int16
Default: 0.0	Change:	Unchangeable

**Value Range:**  
-3276.7A to 3276.7A

**Description**

-

**H0b.40 Bus voltage upon occurrence of the selected fault**

Address:	0x0B28	Effective mode:	-
Min.:	0.0	Unit:	V
Max.:	6553.5	Data Type:	UInt16
Default:	0.0	Change:	Unchangeable

**Value Range:**

0.0V to 6553.5V

**Description**

-

**H0b.41 Input terminal status upon occurrence of the selected fault**

Address:	0x0B29	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.43 Output terminal status upon occurrence of the selected fault**

Address:	0x0B2B	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

Displays the related data when a fault occurred.

**H0b.45 Internal fault code**

Address:	0x0B2D	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.46 Absolute encoder fault information given by FPGA upon occurrence of the selected fault**

Address: 0x0B2E

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.47 System status information given by FPGA upon occurrence of the selected fault**

Address: 0x0B2F

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.48 System fault information given by FPGA upon occurrence of the selected fault**

Address: 0x0B30

Effective mode: -

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.49 Encoder fault information upon occurrence of the selected fault**

Address: 0x0B31	Effective	-
	mode:	
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable
<b>Value Range:</b>		
0 to 65535		
<b>Description</b>		
-		

**H0b.51 Internal fault code upon occurrence of the selected fault**

Address: 0x0B33	Effective	-
	mode:	
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable
<b>Value Range:</b>		
0 to 65535		
<b>Description</b>		
-		

**H0b.52 FPGA timeout fault standard bit upon occurrence of the selected fault**

Address: 0x0B34	Effective	-
	mode:	
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable
<b>Value Range:</b>		
0 to 65535		
<b>Description</b>		
-		

**H0b.53 Position following error (reference unit)**

Address: 0x0B35	Effective	-
	mode:	
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable
<b>Value Range:</b>		
-2147483648p to 2147483647p		

**Description**

-

**H0b.55 Motor speed actual value**

Address: 0x0B37

Effective -

mode:

Min.: -2147483648

Unit: RPM

Max.: 2147483647.0

Data Type: Int32

Default: 0.0

Change: Unchangeable

**Value Range:**

-2147483648.0rpm to 2147483647.0rpm

**Description**

It displays the actual speed of the servo motor after round-off, in unit of 1 RPM. You can set the filter time constant for H0B-00 in filter time constant of speed feedback display.

**H0b.57 Bus voltage of the control circuit**

Address: 0x0B39

Effective -

mode:

Min.: 0.0

Unit: V

Max.: 6553.5

Data type: UInt16

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0V to 6553.5V

**Description**

It displays the DC bus voltage of the input control power after rectification.

**H0b.58 Mechanical absolute position (low 32 bits)**

Address: 0x0B3A

Effective -

mode:

Min.: -2147483648

Unit: p

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

Displays the low 32-bit value (encoder unit) of the mechanical position feedback when the absolute encoder is used.



**H0b.60 Mechanical absolute position (high 32 bits)**

Address: 0x0B3C	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

-

**H0b.63 NotRdy state**

Address: 0x0B3F	Effective mode:	-
Min.: 0	Unit:	-
Max.: 5	Data Type:	UInt16
Default: 0	Change:	Unchangeable

**Value Range:**

- 1: Control power error
- 2: Main circuit power input error
- 3: Undervoltage
- 4: Soft start failed
- 5: Encoder initialization not completed
- 6: Short circuit to ground failed
- 7: Others

**Description**

-

**H0b.64 Real-time input position reference counter**

Address: 0x0B40	Effective mode:	-
Min.: -2147483648	Unit:	Reference unit
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H0b.66 Encoder temperature**

Address: 0x0B42	Effective mode:	-
-----------------	-----------------	---

Min.:	-32768	Unit:	°C
Max.:	32767	Data Type:	Int16
Default:	0	Change:	Unchangeable

**Value Range:**

-32768°C to 32767°C

**Description**

Indicates the encoder temperature value.

**H0b.67 Load rate of regenerative resistor**

Address:	0x0B43	Effective mode:	-
Min.:	0.0	Unit:	%
Max.:	200.0	Data type:	UInt16
Default:	0.0	Change:	Unchangeable

**Value Range:**

0.0% to 200.0%

**Description**

Indicates the brake load rate. When the load rate exceeds 100%, the servo drive stops braking.

**H0b.70 Number of absolute encoder revolutions**

Address:	0x0B46	Effective mode:	-
Min.:	0	Unit:	Rev
Max.:	65535	Data type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0Rev–65535Rev

**Description**

Indicates the number of revolutions of the absolute encoder.

**H0b.71 Single-turn position fed back by the absolute encoder**

Address:	0x0B47	Effective mode:	-
Min.:	2147483648	Unit:	p
Max.:	2147483647	Data Type:	UInt32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648 p to +2147483647 p

**Description**

It displays the single-turn position feedback of the absolute encoder.

**H0b.74 System fault information given by FPGA**

Address: 0x0B4A	Effective mode:	-
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable
<b>Value Range:</b> 0 to 65535		
<b>Description</b> -		

**H0b.77 Encoder position (low 32 bits)**

Address: 0x0B4D	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Unchangeable
<b>Value Range:</b> -2147483648p to 2147483647p		
<b>Description</b> -		

**H0b.79 Encoder position (high 32 bits)**

Address: 0x0B4F	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Unchangeable
<b>Value Range:</b> -2147483648p to 2147483647p		
<b>Description</b> -		

**H0b.81 Single-turn position of the rotary load (low 32 bits)**

Address: 0x0B51	Effective mode:	-
Min.: -2147483648	Unit:	p
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable
<b>Value Range:</b> -2147483648p to 2147483647p		

**Description**

Indicates the low 32-bit value (encoder unit) of the position feedback of the load when the absolute encoder system works in the rotation mode.

**H0b.83 Single-turn position of the rotary load (high 32 bits)**

Address:	0x0B53	Effective	-
		mode:	
Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

-

**H0b.85 Single-turn position of the rotary load (reference unit)**

Address:	0x0B55	Effective	-
		mode:	
Min.:	-2147483648	Unit:	p
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Unchangeable

**Value Range:**

-2147483648p to 2147483647p

**Description**

-

**H0b.87 IGBT junction temperature**

Address:	0x0B57	Effective	-
		mode:	
Min.:	0	Unit:	-
Max.:	200	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 200

**Description**

-

**H0b.90 Group No. of the abnormal parameter**

Address:	0x0B5A	Effective	-
		mode:	
Min.:	0	Unit:	-

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Data Type: UInt16

Change: Unchangeable

**H0b.91 Offset within the group of the abnormal parameter**

Address: 0x0B5B

Effective -

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0b.94 Individual power-on time**

Address: 0x0B5E

Effective -

mode:

Min.: 0.0

Unit: -

Max.: 429496729.5

Data Type: UInt32

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0s–429496729.5s

**Description**

-

**H0b.96 Individual power-on time upon occurrence of the selected fault**

Address: 0x0B60

Effective -

mode:

Min.: 0.0

Unit: -

Max.: 429496729.5

Data type: UInt32

Default: 0.0

Change: Unchangeable

**Value Range:**

0.0s–429496729.5s

**Description**

-

## 4.13 H0d Auxiliary Parameters

### H0d.00 Software reset

Address: 0x0D00

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: No operation

1: Enable

#### Description

Defines whether to enable software reset.

Software reset is available in the following cases:

The servo is in the S-OFF state.

No. 1 non-resettable faults do not occur.

No EEPROM operation is performed. The software reset function is ineffective.

### H0d.01 Fault reset

Address: 0x0D01

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

#### Value Range:

0: No operation

1: Enable

#### Description

Defines whether to enable fault reset.

For fault classification, see the Troubleshooting Guide.

The fault reset function, once enabled, stops the keypad from displaying the fault only. It does not activate modifications made on parameters.

This function is not applicable to non-resettable faults. Use this function with caution in cases where the fault causes are not rectified.

### H0d.02 Inertia auto-tuning enable

Address: 0x0D02

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65

Data Type: UInt16

Default: 0

Change: Immediately

#### Value Range:

0 to 65

**Description**

-

**H0d.04 Read/write in encoder ROM**

Address: 0x0D04

Effective mode: Real time

Min.: 0

Unit: -

Max.: 3

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Write ROM

2: Read ROM

3: ROM failure

**Description**

-

**H0d.05 Emergency stop**

Address: 0x0D05

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: No operation

1: Emergency stop

**Description**

Defines whether to enable emergency stop. When this function is enabled, the servo drive immediately stops according to the Stop mode at S-ON OFF regardless of its state.

**H0d.12 Phase U/V current balance correction**

Address: 0x0D0C

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Disabled

1: Enabled

**Description**

-

**H0d.17 Forced DI/DO enable switch**

Address: 0x0D11

Effective mode: Real time

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

bit0: Forced DI enable switch

0: Disabled

1: Enabled

bit1: Forced DO enable switch

0: Disabled

1: Enabled

**Description**

-

**H0d.18 Forced DI value**

Address: 0x0D12

Effective mode: Real time

Min.: 0

Unit: -

Max.: 255

Data Type: UInt16

Default: 255

Change: Real-time

**Value Range:**

0 to 255

**Description**

Defines the level logic of the DI functions set by the parameter when forced DI is activated.

The value of H0d.18 is displayed as a hexadecimal on the keypad. When it is converted to a binary value, "bit(n) = 1" indicates the level logic of DI function is high level; "bit(n) = 0" indicates the level logic of the DI function is low level.

**H0d.19 Forced DO value**

Address: 0x0D13

Effective mode: Real time

Min.: 0

Unit: -

Max.: 31

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0 to 31



**Description**

Defines whether the DO functions assigned by the parameter are active when forced DO is active.

The value of H0d.19 is displayed as a hexadecimal on the keypad. When it is converted to a binary value, "bit(n) = 1" indicates the DO function is active; "bit(n) = 0" indicates the DO function is inactive.

**H0d.20 Absolute encoder reset**

Address: 0x0D14

Effective      Real time  
mode:

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: No operation

1: Reset

2: Reset the fault and multi-turn data

**Description**

You can reset the encoder error or the multi-turn data fed back by the encoder by setting H0d.20.

**H0d.23 Torque fluctuation auto-tuning**

Address: 0x0D17

Effective      Real time  
mode:

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 1

**Description**

-

**H0d.26 Brake and dynamic brake started forcibly**

Address: 0x0D1A

Effective      Real time  
mode:

Min.: 0

Unit: -

Max.: 3

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

- 0: No forcible operations
- 1: Dynamic brake deactivated forcibly
- 2: Brake released forcibly
- 3: Dynamic brake deactivated and brake released forcibly

**Description**

-

## 4.14 H0E Communication Function Parameters

**H0E.00 Node address**

Address: 0x0E00	Effective mode:	Real time
Min.: 1	Unit:	-
Max.: 127	Data Type:	UInt16
Default: 1	Change:	At stop

**Value Range:**

1 to 127

**Description**

Defines the servo drive axis address during RS232 communication.

- 0: Broadcast address. The host controller performs the write operation on all the servo drives through the broadcast address. The servo drives acts accordingly after receiving the broadcast address frames without responding.
- 1 to 127: Each of the servo drive networked must have a unique address. Otherwise, communication error or failure will occur.

**H0E.01 Save objects written through communication to EEPROM**

Address: 0x0E01	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 4	Data Type:	UInt16
Default: 1	Change:	Real-time

**Value Range:**

0: Not save

- 1: Save parameters written through communication to EEPROM
- 2: Save object dictionaries written through communication to EEPROM
- 3: Save parameters and object dictionaries written through communication to EEPROM
- 4: Save object dictionaries written before communication (OP) to EEPROM

**Description**

Sets whether parameters written by 232 communication and PN communication are saved in e2prom.

**H0E.07 Object dictionary unit selection**

Address: 0x0E07

Effective mode:	Real time
Unit:	-
Data type:	UInt16
Change:	At stop

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Reference unit system (p/s, p/s2)

1: User unit system (0.01 RPM, ms)

**Description**

-

**H0E.10 CAN selection**

Address: 0x0E0A

Effective mode:	Upon the next power-on
Unit:	-
Data Type:	UInt16
Change:	At stop

Min.: 0

Max.: 2

Default: 0

**Value Range:**

0: Pulse/Axis control command

1: Enhanced axis control command

2: CANopen

**Description**

-

**H0E.11 CAN baud rate**

Address: 0x0E0B

Effective mode:	Real time
Unit:	-
Data Type:	UInt16
Change:	At stop

Min.: 0

Max.: 7

Default: 5

**Value Range:**

0: 20kbps

1: 50kbps

2: 100kbps

3: 125kbps

4: 250kbps

5: 500kbps

7: 1Mbps

**Description**

-

**H0E.12 Excessive IP position command increment count**

Address: 0x0E0C

Effective Real time

mode:

Min.: 1

Unit: -

Max.: 30

Data Type: UInt16

Default: 20

Change: Immediately

**Value Range:**

1 to 30

**Description**

-

**H0E.13 CANopen sync period error limit**

Address: 0x0E0D

Effective -

mode:

Min.: 0

Unit: -

Max.: 5

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

0: 1/4

1: 1/2

2: 3/4

3: 1

4: 2

5: Disabled

**Description**

-

**H0E.14 CANopen communication state**

Address: 0x0E0E

Effective -

mode:

Min.: 0

Unit: -

Max.: 9

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 9

**Description**

-

**H0E.17 Get the count of received NMT frames with incorrect length**

Address: 0x0E11

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Data type: UInt16

Change: Unchangeable

**H0E.18 Get the count of received NMT frames with incorrect command**

Address: 0x0E12

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.19 Get received heartbeat frames of wrong length**

Address: 0x0E13

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H0E.80 Modbus baud rate**

Address: 0x0E50

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 10

Data Type: UInt16

Default: 9

Change: Real-time

**Value Range:**

4: 4800 bps

5: 9600 bps

6: 19200 bps

7: 38400 bps

8: 57600 bps

9: 115200 bps

**Description**

-

**H0E.81 Modbus data format**

Address: 0x0E51

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 3

Change: Immediately

**Value Range:**

3: No parity, 1 stop bit (N-1)

**Description**

-

**H0E.82 Modbus response delay**

Address: 0x0E52

Effective Real time

mode:

Min.: 0

Unit: ms

Max.: 20

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0ms to 20ms

**Description**

-

**H0E.83 Modbus communication timeout**

Address: 0x0E53

Effective Real time

mode:

Min.: 0

Unit: ms

Max.: 600

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0ms to 600ms

**Description**

-

**H0E.84 Sequence of Modbus communication data bits**

Address: 0x0E54

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 1

**Value Range:**  
0: High bits before low bits  
1: Low bits before high bits

**Description**  
-

Change: Immediately

**H0E.90 Modbus version**  
Address: 0x0E5A

Min.: 0.00  
Max.: 655.35  
Default: 0.00

**Value Range:**  
0.00 to 655.35

**Description**  
-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

**H0E.91 CANopen version number**  
Address: 0x0E5B

Min.: 0.00  
Max.: 655.35  
Default: 0.00

**Value Range:**  
0.00 to 655.35

**Description**  
-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

**H0E.92 CANlink version**  
Address: 0x0E5C

Min.: 0.00  
Max.: 655.35  
Default: 0.00

**Value Range:**  
0.00 to 655.35

**Description**  
-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

**H0E.97 Communication monitoring parameter 1**

Address: 0x0E61	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
0 to 65535		
<b>Description</b>		
-		

**H0E.98 Communication monitoring parameter 2**

Address: 0x0E62	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
0 to 65535		
<b>Description</b>		
-		

**4.15 H12 Multi-Speed****H12.00 Multi-speed operation mode**

Address: 0x1200	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 2	Data Type:	UInt16
Default: 1	Change:	At stop
<b>Value Range:</b>		
0: Individual operation (number of speeds selected in H12.01)		
1: Cyclic operation (number of speeds selected in H12.01)		
2: DI-based operation		
<b>Description</b>		
-		

**H12.01 Number of speed references in multi-speed mode**

Address: 0x1201	Effective mode:	Real time
-----------------	-----------------	-----------



Min.: 1  
 Max.: 16  
 Default: 16

**Value Range:**

1 to 16

**Description**

-

Unit: -  
 Data Type: UInt16  
 Change: At stop

**H12.02 Operating time unit**

Address: 0x1202

Min.: 0  
 Max.: 1  
 Default: 0

**Value Range:**

0: s

1: min

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: At stop

**H12.03 Acceleration time 1**

Address: 0x1203

Min.: 0  
 Max.: 65535  
 Default: 10

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode: Real time  
 Unit: ms  
 Data Type: UInt16  
 Change: Immediately

**H12.04 Deceleration time 1**

Address: 0x1204

Min.: 0  
 Max.: 65535  
 Default: 10

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode: Real time  
 Unit: ms  
 Data Type: UInt16  
 Change: Immediately

**H12.05 Acceleration time 2**

Address: 0x1205

Min.: 0

Max.: 65535

Default: 50

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**H12.06 Deceleration time 2**

Address: 0x1206

Min.: 0

Max.: 65535

Default: 50

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**H12.07 Acceleration time 3**

Address: 0x1207

Min.: 0

Max.: 65535

Default: 100

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**H12.08 Deceleration time 3**

Address: 0x1208

Min.: 0

Max.: 65535

Default: 100

**Value Range:**

0ms to 65535ms

Effective mode:  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**Description**

-

**H12.09 Acceleration time 4**

Address: 0x1209

Min.: 0

Max.: 65535

Default: 150

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode: Real time  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**H12.10 Deceleration time 4**

Address: 0x120A

Min.: 0

Max.: 65535

Default: 150

**Value Range:**

0ms to 65535ms

**Description**

-

Effective mode: Real time  
Unit: ms  
Data Type: UInt16  
Change: Immediately

**H12.20 Speed reference 1**

Address: 0x1214

Min.: -10000

Max.: 10000

Default: 0

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time  
Unit: RPM  
Data type: Int16  
Change: Immediately

**H12.21 Operating time of speed 1**

Address: 0x1215

Min.: 0.0

Max.: 6553.5

Effective mode: Real time  
Unit: s (m)  
Data type: UInt16

Default: 5.0

Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.22 Acc./dec. time of speed 1**

Address: 0x1216

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4

Data type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Zero acceleration/deceleration time

1: Acceleration/Deceleration time 1

2: Acceleration/Deceleration time 2

3: Acceleration/Deceleration time 3

4: Acceleration/Deceleration time 4

**Description**

-

**H12.23 Reference 2**

Address: 0x1217

Effective mode: Real time

Min.: -10000

Unit: RPM

Max.: 10000

Data type: Int16

Default: 100

Change: Immediately

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

**H12.24 Operating time of speed 2**

Address: 0x1218

Effective mode: Real time

Min.: 0.0

Unit: s (m)

Max.: 6553.5

Data type: UInt16

Default: 5.0

Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.25 Acc./dec. time of speed 2**

Address: 0x1219

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H12.26 Reference 3**

Address: 0x121A

Min.: -10000

Max.: 10000

Default: 300

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time  
Unit: RPM  
Data type: Int16  
Change: Immediately

**H12.27 Operating time of speed 3**

Address: 0x121B

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time  
Unit: s (m)  
Data Type: UInt16  
Change: Immediately

**H12.28 Acc./dec. time of speed 3**

Address: 0x121C

Min.: 0

Max.: 4

Effective mode: Real time  
Unit: -  
Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.29 Reference 4**

Address: 0x121D

Effective mode: Real time

Min.: -6000

mode:

Max.: 6000

Unit: rpm

Default: 500

Data Type: Int16

Change: Immediately

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

**H12.30 Operating time of speed 4**

Address: 0x121E

Effective mode: Real time

Min.: 0.0

mode:

Max.: 6553.5

Unit: s (m)

Default: 5.0

Data type: UInt16

Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.31 Acc./dec. time of speed 4**

Address: 0x121F

Effective mode: Real time

Min.: 0

mode:

Max.: 4

Unit: -

Default: 0

Data Type: UInt16

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.32 Reference 5**

Address: 0x1220

Effective mode: Real time

mode:

Min.: -10000

Max.: 10000

Default: 700

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Unit: RPM

Data type: Int16

Change: Immediately

**H12.33 Operating time of speed 5**

Address: 0x1221

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time

Unit: s (m)

Data Type: UInt16

Change: Immediately

**H12.34 Acc./dec. time of speed 5**

Address: 0x1222

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Immediately

**H12.35 Reference 6**

Address: 0x1223

Min.: -10000

Max.: 10000

Default: 900

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time

Unit: RPM

Data type: Int16

Change: Immediately

**H12.36 Operating time of speed 6**

Address: 0x1224

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode:  
 Unit: s (m)  
 Data Type: UInt16  
 Change: Immediately

**H12.37 Acc./dec. time of speed 6**

Address: 0x1225

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode:  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H12.38 Reference 7**

Address: 0x1226

Min.: -10000

Max.: 10000

Default: 600

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode:  
 Unit: rpm  
 Data Type: Int16  
 Change: Immediately

**H12.39 Operating time of speed 7**

Address: 0x1227

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

Effective mode:  
 Unit: s (m)  
 Data Type: UInt16  
 Change: Immediately



**Description**

-

**H12.40 Acc./dec. time of speed 7**

Address: 0x1228

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H12.41 Reference 8**

Address: 0x1229

Min.: -10000

Max.: 10000

Default: 300

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time  
Unit: RPM  
Data type: Int16  
Change: Immediately

**H12.42 Operating time of speed 8**

Address: 0x122A

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time  
Unit: s (m)  
Data Type: UInt16  
Change: Immediately

**H12.43 Acc./dec. time of speed 8**

Address: 0x122B

Min.: 0

Max.: 4

Effective mode: Real time  
Unit: -  
Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.44 Reference 9**

Address: 0x122C

Effective mode: Real time

Min.: -10000

Unit: RPM

Max.: 10000

Data type: Int16

Default: 100

Change: Immediately

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

**H12.45 Operating time of speed 9**

Address: 0x122D

Effective mode: Real time

Min.: 0.0

Unit: s (m)

Max.: 6553.5

Data Type: UInt16

Default: 5.0

Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.46 Acc./dec. time of speed 9**

Address: 0x122E

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.47 Reference 10**

Address: 0x122F

Effective mode: Real time

Min.:	-10000	Unit:	rpm
Max.:	10000	Data Type:	Int16
Default:	-100	Change:	Immediately

**Value Range:**

-10000 rpm to +10000 rpm

**Description**

-

**H12.48 Operating time of speed 10**

Address: 0x1230

Effective mode: Real time

Min.: 0.0  
Max.: 6553.5  
Default: 5.0

Unit: s (m)  
Data Type: UInt16  
Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.49 Acc./dec. time of speed 10**

Address: 0x1231

Effective mode: Real time

Min.: 0  
Max.: 4  
Default: 0

Unit: -  
Data Type: UInt16  
Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.50 Reference 11**

Address: 0x1232

Effective mode: Real time

Min.: -10000  
Max.: 10000  
Default: -300

Unit: rpm  
Data Type: Int16  
Change: Immediately

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

**H12.51 Operating time of speed 11**

Address: 0x1233

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode:  
 Unit: s (m)  
 Data Type: UInt16  
 Change: Immediately

**H12.52 Acc./dec. time of speed 11**

Address: 0x1234

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode:  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H12.53 Reference 12**

Address: 0x1235

Min.: -10000

Max.: 10000

Default: -500

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode:  
 Unit: RPM  
 Data type: Int16  
 Change: Immediately

**H12.54 Operating time of speed 12**

Address: 0x1236

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

Effective mode:  
 Unit: s (m)  
 Data type: UInt16  
 Change: Immediately

**Description**

-

**H12.55 Acc./dec. time of speed 12**

Address: 0x1237

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H12.56 Reference 13**

Address: 0x1238

Min.: -10000

Max.: 10000

Default: -700

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time  
Unit: rpm  
Data Type: Int16  
Change: Immediately

**H12.57 Operating time of speed 13**

Address: 0x1239

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time  
Unit: s (m)  
Data Type: UInt16  
Change: Immediately

**H12.58 Acc./dec. time of speed 13**

Address: 0x123A

Min.: 0

Max.: 4

Effective mode: Real time  
Unit: -  
Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.59 Reference 14**

Address: 0x123B

Effective Real time

mode:

Min.: -10000

Unit: rpm

Max.: 10000

Data Type: Int16

Default: -900

Change: Immediately

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

**H12.60 Operating time of speed 14**

Address: 0x123C

Effective Real time

mode:

Min.: 0.0

Unit: s (m)

Max.: 6553.5

Data type: UInt16

Default: 5.0

Change: Immediately

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

**H12.61 Acc./dec. time of speed 14**

Address: 0x123D

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 4

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H12.22.

**Description**

-

**H12.62 Reference 15**

Address: 0x123E

Effective Real time

mode:

Min.: -10000

Max.: 10000

Default: -600

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Unit: RPM

Data type: Int16

Change: Immediately

**H12.63 Operating time of speed 15**

Address: 0x123F

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time

Unit: s (m)

Data Type: UInt16

Change: Immediately

**H12.64 Acc./dec. time of speed 15**

Address: 0x1240

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Immediately

**H12.65 Reference 16**

Address: 0x1241

Min.: -10000

Max.: 10000

Default: -300

**Value Range:**

-10000 RPM to +10000 RPM

**Description**

-

Effective mode: Real time

Unit: RPM

Data type: Int16

Change: Immediately

**H12.66 Operating time of speed 16**

Address: 0x1242

Min.: 0.0

Max.: 6553.5

Default: 5.0

**Value Range:**

0.0s(m) to 6553.5s(m)

**Description**

-

Effective mode: Real time  
 Unit: s (m)  
 Data type: UInt16  
 Change: Immediately

**H12.67 Acc./dec. time of speed 16**

Address: 0x1243

Min.: 0

Max.: 4

Default: 0

**Value Range:**

Same as H12.22.

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**4.16 H17 Virtual DI/DO****H17.90 Communication VDI enable**

Address: 0x175A

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Disabled

1: Enabled

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: At stop

**H17.91 VDI default value upon power-on**

Address: 0x175B

Min.: 0

Max.: 65535

Effective mode: Upon the next power-on  
 Unit: -  
 Data Type: UInt16



Default:	0	Change:	Immediately
<b>Value Range:</b>			
0: No default			
1: VDI1 default value			
2: VDI2 default value			
4: VDI3 default value			
8: VDI4 default value			
16: VDI5 default value			
32: VDI6 default value			
64: VDI7 default value			
128: VDI8 default value			
256: VDI9 default value			
512: VDI10 default value			
1024: VDI11 default value			
2048: VDI12 default value			
4096: VDI13 default value			
8092: VDI14 default value			
16384: VDI15 default value			
32768: VDI16 default value			
<b>Description</b>			
-			

<b>H17.00</b>	<b>VDI1 function</b>			
	Address:	0x1700		
		Effective mode:	At stop	
	Min.:	0	Unit:	-
	Max.:	56	Data Type:	UInt16
	Default:	0	Change:	Immediately
	<b>Value Range:</b>			

0: No assignment  
 1: Servo ON  
 3: Gain switchover  
 14: Positive limit switch  
 15: Negative limit switch  
 16: Positive external torque limit  
 17: Negative external torque limit  
 18: Forward jog  
 19: Reverse jog  
 31: Home switch  
 34: Emergency stop  
 36: Internal speed limit source  
 41: Current position as home  
 56: External switchover switch of EPOS program segment

#### Description

-

#### H17.01 VDI1 logic level selection

Address: 0x1701	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

#### Value Range:

0: Active when the written value is 1  
 1: Active when the written value changes from 0 to 1

#### Description

-

#### H17.02 VDI2 function

Address: 0x1702	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 56	Data Type:	UInt16
Default: 0	Change:	Immediately

#### Value Range:

Same as H17.00.

#### Description

-

### H17.03 VDI2 logic level selection

Address: 0x1703	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

#### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

#### Description

-

### H17.04 VDI3 function

Address: 0x1704	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 56	Data Type:	UInt16
Default: 0	Change:	Immediately

#### Value Range:

Same as H17.00.

#### Description

-

### H17.05 VDI3 logic level selection

Address: 0x1705	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

#### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

#### Description

-

### H17.06 VDI4 function

Address: 0x1706	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 56	Data Type:	UInt16
Default: 0	Change:	Immediately

#### Value Range:

Same as H17.00.

### Description

-

### H17.07 VDI4 logic level selection

Address: 0x1707

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

### Description

-

### H17.08 VDI5 function

Address: 0x1708

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

### Value Range:

Same as H17.00.

### Description

-

### H17.09 VDI5 logic level selection

Address: 0x1709

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

### Description

-

### H17.10 VDI6 function

Address: 0x170A

Effective mode: At stop

Min.: 0	Unit: -
Max.: 56	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.11 VDI6 logic level selection**

Address: 0x170B	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.12 VDI7 function**

Address: 0x170C	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 56	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.13 VDI7 logic level selection**

Address: 0x170D	Effective mode:	At stop
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.14 VDI8 function**

Address: 0x170E

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

Min.: 0

Max.: 56

Default: 0

**Value Range:**

Same as H17.00.

**Description**

-

**H17.15 VDI8 logic level selection**

Address: 0x170F

Effective mode: At stop  
 Unit: -  
 Data type: UInt16  
 Change: At stop

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.16 VDI9 function**

Address: 0x1710

Effective mode: At stop  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

Min.: 0

Max.: 56

Default: 0

**Value Range:**

Same as H17.00.

**Description**

-

**H17.17 VDI9 logic level selection**

Address: 0x1711

Effective mode: At stop  
 Unit: -  
 Data type: UInt16  
 Change: At stop

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.18 VDI10 function**

Address: 0x1712

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.19 VDI10 logic level selection**

Address: 0x1713

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.20 VDI11 function**

Address: 0x1714

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.21 VDI11 logic level selection**

Address: 0x1715

Effective mode: At stop

Min.:	0	Unit:	-
Max.:	1	Data type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.22 VDI12 function**

Address: 0x1716

Effective mode:	At stop
-----------------	---------

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.23 VDI12 logic level selection**

Address: 0x1717

Effective mode:	At stop
-----------------	---------

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.24 VDI13 function**

Address: 0x1718

Effective mode:	At stop
-----------------	---------

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-



**H17.25 VDI13 logic level selection**

Address: 0x1719

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.26 VDI14 function**

Address: 0x171A

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

**Description**

-

**H17.27 VDI14 logic level selection**

Address: 0x171B

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

**Description**

-

**H17.28 VDI15 function**

Address: 0x171C

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.00.

### Description

-

### H17.29 VDI15 logic level selection

Address: 0x171D

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

### Description

-

### H17.30 VDI16 function

Address: 0x171E

Effective mode: At stop

Min.: 0

Unit: -

Max.: 56

Data Type: UInt16

Default: 0

Change: Immediately

### Value Range:

Same as H17.00.

### Description

-

### H17.31 VDI16 logic level selection

Address: 0x171F

Effective mode: At stop

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

### Value Range:

0: Active when the written value is 1

1: Active when the written value changes from 0 to 1

### Description

-

### H17.92 Communication VDO enable

Address: 0x175C

Effective mode: Real time

Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop
<b>Value Range:</b>			
0: Disabled			
1: Enabled			
<b>Description</b>			
-			

**H17.93 VDO default value after power-on**

Address:	0x175D	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At stop
<b>Value Range:</b>			
0: No default			
1: VDI1 default value			
2: VDI2 default value			
4: VDI3 default value			
8: VDI4 default value			
16: VDI5 default value			
32: VDI6 default value			
64: VDI7 default value			
128: VDI8 default value			
256: VDI9 default value			
512: VDI10 default value			
1024: VDI11 default value			
2048: VDI12 default value			
4096: VDI13 default value			
8192: VDI14 default value			
16384: VDI15 default value			
32768: VDI16 default value			
<b>Description</b>			
-			

**H17.32 VDO virtual level**

Address:	0x1720	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H17.33 VDO1 function selection**

Address: 0x1721

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Real-time

Min.: 0

Max.: 33

Default: 0

**Value Range:**

0: No assignment

1: Servo ready

2: Motor rotating

3: Zero speed

4: Speed matching

5: Positioning completed

6: Proximity

7: Torque limited

8: Speed limited

9: Brake

10: Warning

11: Fault

16: Homing completed

18: Torque reach

19: Speed reach

25: Comparison output

30: Warning or fault output

32: EDM output

**Description**

-

**H17.34 VDO1 logic level selection**

Address: 0x1722

Effective mode: Real time  
 Unit: -  
 Data type: UInt16  
 Change: Immediately

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

### Description

-

#### H17.35 VDO2 function

Address: 0x1723

Min.: 0

Max.: 33

Default: 0

#### Value Range:

Same as H17.33.

### Description

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

#### H17.36 VDO2 logic level selection

Address: 0x1724

Min.: 0

Max.: 1

Default: 0

#### Value Range:

0: Output 1 upon active logic

1: Output 0 upon active logic

### Description

-

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

#### H17.37 VDO3 function

Address: 0x1725

Min.: 0

Max.: 33

Default: 0

#### Value Range:

Same as H17.33.

### Description

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

#### H17.38 VDO3 logic level selection

Address: 0x1726

Min.: 0

Effective mode: Real time  
Unit: -

Max.: 1	Data type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.39 VDO4 function**

Address: 0x1727

Effective mode: Real time

Unit: -

Min.: 0

Data Type: UInt16

Max.: 33

Change: Immediately

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

**H17.40 VDO4 logic level selection**

Address: 0x1728

Effective mode: Real time

Unit: -

Min.: 0

Data type: UInt16

Max.: 1

Change: Immediately

Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.41 VDO5 function**

Address: 0x1729

Effective mode: Real time

Unit: -

Min.: 0

Data Type: UInt16

Max.: 33

Change: Immediately

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

**H17.42 VDO5 logic level selection**

Address: 0x172A	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
0: Output 1 upon active logic		
1: Output 0 upon active logic		
<b>Description</b>		
-		

**H17.43 VDO6 function**

Address: 0x172B	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 33	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
Same as H17.33.		
<b>Description</b>		
-		

**H17.44 VDO6 logic level selection**

Address: 0x172C	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
0: Output 1 upon active logic		
1: Output 0 upon active logic		
<b>Description</b>		
-		

**H17.45 VDO7 function**

Address: 0x172D	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 33	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		

Same as H17.33.

#### Description

-

#### H17.46 VDO7 logic level selection

Address: 0x172E

Min.: 0

Max.: 1

Default: 0

#### Value Range:

0: Output 1 upon active logic

1: Output 0 upon active logic

#### Description

-

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

#### H17.47 VDO8 function

Address: 0x172F

Min.: 0

Max.: 33

Default: 0

#### Value Range:

Same as H17.33.

#### Description

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

#### H17.48 VDO8 logic level selection

Address: 0x1730

Min.: 0

Max.: 1

Default: 0

#### Value Range:

0: Output 1 upon active logic

1: Output 0 upon active logic

#### Description

-

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

#### H17.49 VDO9 function

Address: 0x1731

Effective mode: Real time



Min.: 0  
Max.: 33  
Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Unit: -  
Data Type: UInt16  
Change: Immediately

**H17.50 VDO9 logic level selection**

Address: 0x1732

Min.: 0  
Max.: 1  
Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

**H17.51 VDO10 function**

Address: 0x1733

Min.: 0  
Max.: 33  
Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H17.52 VDO10 logic level selection**

Address: 0x1734

Min.: 0  
Max.: 1  
Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

Effective mode: Real time  
Unit: -  
Data type: UInt16  
Change: Immediately

**H17.53 VDO11 function**

Address: 0x1735

Min.: 0

Max.: 33

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H17.54 VDO11 logic level selection**

Address: 0x1736

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data type: UInt16  
 Change: Immediately

**H17.55 VDO12 function**

Address: 0x1737

Min.: 0

Max.: 33

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

**H17.56 VDO12 logic level selection**

Address: 0x1738

Min.: 0

Max.: 1

Default: 0

**Value Range:**

Effective mode: Real time  
 Unit: -  
 Data type: UInt16  
 Change: Immediately

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.57 VDO13 function**

Address: 0x1739

Min.: 0

Max.: 33

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Immediately

**H17.58 VDO13 logic level selection**

Address: 0x173A

Min.: 0

Max.: 1

Default: 0

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

Effective mode: Real time

Unit: -

Data type: UInt16

Change: Immediately

**H17.59 VDO14 function**

Address: 0x173B

Min.: 0

Max.: 33

Default: 0

**Value Range:**

Same as H17.33.

**Description**

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Immediately

**H17.60 VDO14 logic level selection**

Address: 0x173C

Effective mode: Real time

Min.: 0	Unit: -
Max.: 1	Data type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.61 VDO15 function**

Address: 0x173D

Effective mode: Real time

Min.: 0

Unit: -

Max.: 33

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.33.

**Description**

-

**H17.62 VDO15 logic level selection**

Address: 0x173E

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**H17.63 VDO16 function**

Address: 0x173F

Effective mode: Real time

Min.: 0

Unit: -

Max.: 33

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H17.33.

**Description**

-

**H17.64 VDO16 logic level selection**

Address: 0x1740	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0: Output 1 upon active logic

1: Output 0 upon active logic

**Description**

-

**4.17 H18 Position Comparison Output**

**H18.00 Position comparison output selection**

Address: 0x1800	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0: Disable

1: Enable (rising edge-triggered)

**Description**

-

**H18.01 Position comparison output feedback source**

Address: 0x1801	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 1	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

0: Motor encoder feedback

1: Fully closed-loop position feedback

**Description**

-

**H18.02 Position comparison resolution**

Address: 0x1802	Effective mode:	Real time
-----------------	-----------------	-----------

Min.: 0	Unit: -
Max.: 7	Data Type: UInt16
Default: 0	Change: Real-time

**Value Range:**

0: 24-bit

1: 23-bit

2: 22-bit

3: 21-bit

4: 20-bit

5: 19-bit

6: 18-bit

7: 17-bit

**Description**

-

**H18.03 Position comparison mode**

Address: 0x1803

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Individual comparison mode

1: Cyclic comparison mode

2: Fixed cyclic comparison mode

**Description**

-

**H18.04 Current position as zero**

Address: 0x1804

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: Disable

1: Enable (rising edge-triggered)

**Description**

-

### H18.05 Position comparison output width

Address: 0x1805      Effective mode: Real time  
 Min.: 0.1      Unit: ms  
 Max.: 204.7      Data Type: UInt16  
 Default: 0.1      Change: Immediately

**Value Range:**  
 0.1ms to 204.7ms

**Description**  
 -

### H18.06 Position comparison output ABZ port polarity

Address: 0x1806      Effective mode: Real time  
 Min.: 0      Unit: -  
 Max.: 65535      Data Type: UInt16  
 Default: 0      Change: Real-time

**Value Range:**

bit	Name	Description
0	OCZ output logic	0: Positive, output high level upon active logic
		1: Negative, output low level upon active logic
1	Z output logic	0: Positive, output high level upon active logic
		1: Negative, output low level upon active logic
2	A/B output logic	0: Positive, output high level upon active logic
		1: Negative, output low level upon active logic

**Description**

-

### H18.07 Position comparison start point

Address: 0x1807      Effective mode: Real time  
 Min.: 0      Unit: -  
 Max.: 40      Data Type: UInt16  
 Default: 0      Change: Immediately

**Value Range:**  
 0 to 40

**Description**  
 -

**H18.08 Position comparison end point**

Address: 0x1808

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Immediately

Min.: 0  
 Max.: 40  
 Default: 0

**Value Range:**

0 to 40

**Description**

-

**H18.09 Current state of position comparison**

Address: 0x1809

Effective mode: Real time  
 Unit: -  
 Data Type: UInt16  
 Change: Unchangeable

Min.: 0  
 Max.: 1024  
 Default: 0

**Value Range:**

0 to 1024

**Description**

-

**H18.10 Real-time position of position comparison**

Address: 0x180A

Effective mode: Real time  
 Unit: -  
 Data type: Int32  
 Change: Unchangeable

Min.: -2147483648  
 Max.: 2147483647  
 Default: 0

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H18.12 Zero offset of position comparison**

Address: 0x180C

Effective mode: Real time  
 Unit: -  
 Data type: Int32  
 Change: Immediately

Min.: -2147483648  
 Max.: 2147483647  
 Default: 0

**Value Range:**

-2147483648 to 2147483647



**Description**

-

**H18.14    Position comparison output delay compensation**

Address:	0x180E	Effective mode:	Upon the next power-on
Min.:	-30	Unit:	us
Max.:	30.00	Data type:	Int16
Default:	0.00	Change:	Immediately

**Value Range:**  
-30.00us to 30.00us

**Description**

-

**H18.15    Fixed cyclic comparison**

Address:	0x180F	Effective mode:	Real time
Min.:	1	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	1	Change:	Immediately

**Value Range:**  
1 to 65535

**Description**

-

**H18.16    ABZ output function setting**

Address:	0x1810	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Real-time

**Value Range:**

bit	Name	Description
0	OCZ output function	0: Frequency-division output
		1: Position comparison
1	Z port output function	0: Frequency-division output
		1: Position comparison
2	A/B port output function	0: Frequency-division output
		1: Position comparison

**Description**

-

**H18.17 Number of fixed mode cycles**

Address: 0x1811

Effective mode: -

Min.: 1

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1

Change: Unchangeable

**Value Range:**

1 to 65535

**Description**

-

**4.18 H19 Target Position Parameters****H19.00 Target value of position comparison 1**

Address: 0x1900

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.02 Attribute value of position comparison 1**

Address: 0x1902

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Real-time

**Value Range:**

bit	Description
0	Output DO active signal if current position changes from "less than" to "more than" the comparison point
1	Output DO active signal if current position changes from "more than" to "less than" the comparison point
2 to 5	Reserved
6	Output maintaining
7	DO1 output
8	DO2 output
9	DO3 output
10	DO4 output
12	Frequency-division A output
13	Frequency-division B output
14	Frequency-division Z output
15	Frequency-division OCZ output

**Description**

-

**H19.03 Target value of position comparison 2**

Address: 0x1903

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.05 Attribute value of position comparison 2**

Address: 0x1905

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Default: 0

**Value Range:**

Same as H19.02.

**Description**

-

Data Type: UInt16

Change: Immediately

**H19.06 Target value of position comparison 3**

Address: 0x1906

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.08 Attribute value of position comparison 3**

Address: 0x1908

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.09 Target value of position comparison 4**

Address: 0x1909

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.11 Attribute value of position comparison 4**

Address: 0x190B	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.12 Target value of position comparison 5**

Address: 0x190C	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.14 Attribute value of position comparison 5**

Address: 0x190E	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.15 Target value of position comparison 6**

Address: 0x190F	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.17 Attribute value of position comparison 6**

Address: 0x1911

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.18 Target value of position comparison 7**

Address: 0x1912

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.20 Attribute value of position comparison 7**

Address: 0x1914

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.21 Target value of position comparison 8**

Address: 0x1915

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0	Change: Immediately
<b>Value Range:</b> -2147483648 to 2147483647	
<b>Description</b> -	

**H19.23 Attribute value of position comparison 8**

Address: 0x1917	Effective mode: Real time
Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Immediately
<b>Value Range:</b> Same as H19.02.	
<b>Description</b> -	

**H19.24 Target value of position comparison 9**

Address: 0x1918	Effective mode: Real time
Min.: -2147483648	Unit: -
Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b> -2147483648 to 2147483647	
<b>Description</b> -	

**H19.26 Attribute value of position comparison 9**

Address: 0x191A	Effective mode: Real time
Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Immediately
<b>Value Range:</b> Same as H19.02.	
<b>Description</b> -	

**H19.27 Target value of position comparison 10**

Address: 0x191B	Effective mode: Real time
-----------------	---------------------------

Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.29 Attribute value of position comparison 10**

Address:	0x191D	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.30 Target value of position comparison 11**

Address:	0x191E	Effective mode:	Real time
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.32 Attribute value of position comparison 11**

Address:	0x1920	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-



**H19.33 Target value of position comparison 12**

Address: 0x1921	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b> -2147483648 to 2147483647		
<b>Description</b> -		

**H19.35 Attribute value of position comparison 12**

Address: 0x1923	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b> Same as H19.02.		
<b>Description</b> -		

**H19.36 Target value of position comparison 13**

Address: 0x1924	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b> -2147483648 to 2147483647		
<b>Description</b> -		

**H19.38 Attribute value of position comparison 13**

Address: 0x1926	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b> Same as H19.02.		

**Description**

-

**H19.39 Target value of position comparison 14**

Address: 0x1927	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.41 Attribute value of position comparison 14**

Address: 0x1929	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.42 Target value of position comparison 15**

Address: 0x192A	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.44 Attribute value of position comparison 15**

Address: 0x192C	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16

Effective mode:      Real time

Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.51 Target value of position comparison 18**

Address: 0x1933	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.53 Attribute value of position comparison 18**

Address: 0x1935	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.54 Target value of position comparison 19**

Address: 0x1936	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.56 Attribute value of position comparison 19**

Address: 0x1938	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
Same as H19.02.		
<b>Description</b>		
-		

**H19.57 Target value of position comparison 20**

Address: 0x1939	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b>		
-2147483648 to 2147483647		
<b>Description</b>		
-		

**H19.59 Attribute value of position comparison 20**

Address: 0x193B	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
Same as H19.02.		
<b>Description</b>		
-		

**H19.60 Target value of position comparison 21**

Address: 0x193C	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b>		
-2147483648 to 2147483647		

**Description**

-

**H19.62 Attribute value of position comparison 21**

Address: 0x193E

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.63 Target value of position comparison 22**

Address: 0x193F

Effective Real time

mode:

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.65 Attribute value of position comparison 22**

Address: 0x1941

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.66 Target value of position comparison 23**

Address: 0x1942

Effective Real time

mode:

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**  
-2147483648 to 2147483647

**Description**  
-

**H19.68    Attribute value of position comparison 23**

Address: 0x1944

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
Same as H19.02.

**Description**  
-

**H19.69    Target value of position comparison 24**

Address: 0x1945

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**  
-2147483648 to 2147483647

**Description**  
-

**H19.71    Attribute value of position comparison 24**

Address: 0x1947

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
Same as H19.02.

**Description**  
-

**H19.72    Target value of position comparison 25**

Address: 0x1948

Effective mode: Real time

Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.74 Attribute value of position comparison 25**

Address:	0x194A	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.75 Target value of position comparison 26**

Address:	0x194B	Effective mode:	Real time
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.77 Attribute value of position comparison 26**

Address:	0x194D	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-



**H19.78 Target value of position comparison 27**

Address: 0x194E	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b> -2147483648 to 2147483647		
<b>Description</b> -		

**H19.80 Attribute value of position comparison 27**

Address: 0x1950	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b> Same as H19.02.		
<b>Description</b> -		

**H19.81 Target value of position comparison 28**

Address: 0x1951	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b> -2147483648 to 2147483647		
<b>Description</b> -		

**H19.83 Attribute value of position comparison 28**

Address: 0x1953	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b> Same as H19.02.		

**Description**

-

**H19.84 Target value of position comparison 29**

Address: 0x1954

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.86 Attribute value of position comparison 29**

Address: 0x1956

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.87 Target value of position comparison 30**

Address: 0x1957

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.89 Attribute value of position comparison 30**

Address: 0x1959

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16



Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.96 Target value of position comparison 33**

Address:	0x1960	Effective mode:	Real time
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.98 Attribute value of position comparison 33**

Address:	0x1962	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.99 Target value of position comparison 34**

Address:	0x1963	Effective mode:	Real time
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.101 Attribute value of position comparison 34**

Address: 0x1965	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
Same as H19.02.		
<b>Description</b>		
-		

**H19.102 Target value of position comparison 35**

Address: 0x1966	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b>		
-2147483648 to 2147483647		
<b>Description</b>		
-		

**H19.104 Attribute value of position comparison 35**

Address: 0x1968	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Immediately
<b>Value Range:</b>		
Same as H19.02.		
<b>Description</b>		
-		

**H19.105 Target value of position comparison 36**

Address: 0x1969	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data type:	Int32
Default: 0	Change:	Immediately
<b>Value Range:</b>		
-2147483648 to 2147483647		

**Description**

-

**H19.107 Attribute value of position comparison 36**

Address: 0x196B

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.108 Target value of position comparison 37**

Address: 0x196C

Effective Real time

mode:

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.110 Attribute value of position comparison 37**

Address: 0x196E

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**H19.111 Target value of position comparison 38**

Address: 0x196F

Effective Real time

mode:

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**  
-2147483648 to 2147483647

**Description**  
-

**H19.113 Attribute value of position comparison 38**

Address: 0x1971

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
Same as H19.02.

**Description**  
-

**H19.114 Target value of position comparison 39**

Address: 0x1972

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**  
-2147483648 to 2147483647

**Description**  
-

**H19.116 Attribute value of position comparison 39**

Address: 0x1974

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
Same as H19.02.

**Description**  
-

**H19.117 Target value of position comparison 40**

Address: 0x1975

Effective mode: Real time

Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Immediately

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H19.119 Attribute value of position comparison 40**

Address:	0x1977	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Immediately

**Value Range:**

Same as H19.02.

**Description**

-

**4.19 H24 PN Bus Communication Parameters****H24.00 Message number selection [PN922]**

Address:	0x2400	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	3	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H24.01 Heartbeat warning threshold [PN925]**

Address:	0x2401	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	5	Change:	At stop

**Value Range:**

0 to 65535



**Description**

-

**H24.02    Fault message counter [PN944]**

Address:	0x2402	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H24.03    Fault code [PN947]**

Address:	0x2403	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H24.04    Fault No.**

Address:	0x2404	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	63	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 to 63

**Description**

-

**H24.05    Fault condition counter [PN952]**

Address:	0x2405	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0 to 65535

**Description**

-

**H24.06 Sensor header [PN979[0]]**

Address: 0x2406

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4294967295

Data type: UInt32

Default: 20754

Change: At stop

**Value Range:**

0 to 4294967295

**Description**

-

**H24.08 Sensor type [PN979[1]]**

Address: 0x2408

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4294967295

Data type: UInt32

Default: 2147483650

Change: At stop

**Value Range:**

0 to 4294967295

**Description**

-

**H24.10 Sensor resolution [PN979[2]]**

Address: 0x240A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 4294967295

Data Type: UInt32

Default: 256

Change: At stop

**Value Range:**

0 to 4294967295

**Description**

-

**H24.12 Sensor G1\_X1ST1 displacement factor [PN979[3]]**

Address: 0x240C

Effective mode: Upon the next power-on

Min.:	0	Unit:	-
Max.:	24	Data type:	UInt32
Default:	15	Change:	At stop

**Value Range:**

0 to 24

**Description**

-

**H24.14 Sensor G1\_X1ST2 displacement factor [PN979[4]]**

Address:	0x240E	Effective mode:	Upon the next power-on
Min.:	0	Unit:	-
Max.:	24	Data type:	UInt32
Default:	15	Change:	At stop

**Value Range:**

0 to 24

**Description**

-

**H24.16 Sensor multi-turn number [PN979[5]]**

Address:	0x2410	Effective mode:	Upon the next power-on
Min.:	0	Unit:	-
Max.:	4294967295	Data type:	UInt32
Default:	512	Change:	At stop

**Value Range:**

0 to 4294967295

**Description**

-

**H24.19 Synchronization cycle**

Address:	0x2413	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	999	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H24.20 Network parameter write flag**

Address: 0x2414

Min.: 0

Max.: 3

Default: 0

**Value Range:**

0 to 3

**Description**

-

Effective mode:

Real time

Unit: -

Data Type: UInt16

Change: At stop

**H24.22 IP Address**

Address: 0x2416

Min.: 0

Max.: 0

Default: 0

**Value Range:**

0 to 0

**Description**

-

Effective mode:

Real time

Unit: -

Data Type: UInt32

Change: Immediately

**H24.24 Subnet mask**

Address: 0x2418

Min.: 0

Max.: 0

Default: 0

**Value Range:**

0 to 0

**Description**

-

Effective mode:

Real time

Unit: -

Data Type: UInt32

Change: Immediately

**H24.26 Default gateway**

Address: 0x241A

Min.: 0

Max.: 0

Default: 0

**Value Range:**

0 to 0

Effective mode:

Real time

Unit: -

Data Type: UInt32

Change: Immediately

**Description**

-

**H24.28 AC1 speed feedback selection**

Address: 0x241C

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Normal

1: High precision

**Description**

-

**H24.32 DSC position loop gain selection**

Address: 0x2420

Effective mode: Real time

Min.: 0

Unit: -

Max.: 3

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Local position loop gain

1: PLC position loop gain

3: DSC manual tuning

**Description**

-

**H24.35 Customized telegram 850 transmission**

Address: 0x2423

Effective mode: Real time

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: No assignment

1: VDO

2: External DI state

**Description**

-

**H24.36 User-defined 850 reception**

Address: 0x2424

Effective mode: Real time

mode:

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: No assignment

1: VDI

2: External DO state

**Description**

-

**H24.37 Extra telegram**

Address: 0x2425

Effective mode: Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: At stop

**Value Range:**

0 to 65535

**Description**

-

**H24.38 Customized receive word**

Address: 0x2426

Effective mode: Real time

mode:

Min.: 0

Unit: -

Max.: 2

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0: No function

1: Additive torque

2: Forced DO

**Description**

-

**H24.39 Customized transmission word**

Address: 0x2427

Effective mode: Real time

mode:

Min.: 0

Unit: -

Max.: 3

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
0: No function  
1: Actual torque  
2: Actual current  
3: DI state

**Description**  
-

**H24.41 Device name loss warning selection**

Address: 0x2429

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**  
0 to 1

**Description**  
-

**H24.42 Number of consecutive loss detections**

Address: 0x242A

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 8

Change: Immediately

**Value Range:**  
0 to 65535

**Description**  
-

**H24.43 Communication timeout time**

Address: 0x242B

Effective mode: Real time

Min.: 1

Unit: -

Max.: 65535

Data Type: UInt16

Default: 1000

Change: Immediately

**Value Range:**  
1 to 65535

**Description**  
-

**H24.44 FPGA synchronous detection deviation threshold**

Address: 0x242C

Effective Real time

mode:

Min.: 0

Unit: ns

Max.: 65535

Data type: UInt16

Default: 3000

Change: At stop

**Value Range:**

0ns to 65535ns

**Description**

-

**H24.45 MAC address**

Address: 0x242D

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H24.46 MAC address**

Address: 0x242E

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H24.47 MAC address**

Address: 0x242F

Effective Real time

mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Immediately

**Value Range:**

0 to 65535



**Description**

-

**H24.33 Number of Sync with advanced DSC position feedback**

Address: 0x2421

Effective mode: Real time

Min.: 0

Unit: -

Max.: 16

Data Type: UInt16

Default: 1

Change: Immediately

**Value Range:**

0 to 16

**Description**

-

**H24.34 Loop gain selection switch**

Address: 0x2422

Effective mode: Real time

Min.: 0

Unit: -

Max.: 1

Data type: UInt16

Default: 0

Change: At stop

**Value Range:**

0: Stiffness level adapted based on DSC gain

1: Stiffness level adapted based on H09.01

**Description**

-

**H24.48 DSC position loop gain coefficient**

Address: 0x2430

Effective mode: Real time

Min.: 1

Unit: -

Max.: 31

Data Type: UInt16

Default: 4

Change: At stop

**Value Range:**

1 to 31

**Description**

-

**H24\_48 DSC position loop gain coefficient**

Address: 0x2430

Effective mode: Real time

Min.: 1

Unit: -

Max.: 31	Data Type: UInt16
Default: 10	Change: At stop
<b>Value Range:</b>	
1 to 31	
<b>Description</b>	
-	

## 4.20 H25 AC3 Control Parameters

### H25.00 EPOS max. speed

Address: 0x2500	Effective mode:	Real time
Min.: 1	Unit:	1000 LU/min
Max.: 40000000	Data type:	UInt32
Default: 30000	Change:	Immediately
<b>Value Range:</b>		
1 Lu/min–40000000 LU/min		
<b>Description</b>		
-		

### H25.02 EPOS max. acceleration

Address: 0x2502	Effective mode:	Real time
Min.: 1	Unit:	1000 LU/s/s
Max.: 2000000	Data type:	UInt32
Default: 100	Change:	Immediately
<b>Value Range:</b>		
1 LU/s/s–2000000 LU/s/s		
<b>Description</b>		
-		

### H25.04 EPOS max. deceleration

Address: 0x2504	Effective mode:	Real time
Min.: 1	Unit:	1000 LU/s/s
Max.: 2000000	Data type:	UInt32
Default: 100	Change:	Immediately
<b>Value Range:</b>		
1 LU/s/s–2000000 LU/s/s		
<b>Description</b>		
-		

**H25.06 EPOS ramp deceleration**

Address: 0x2506

Effective mode: Real time  
Unit: 1000 LU/s/s  
Data type: UInt32  
Change: Immediately

Min.: 1  
Max.: 2000000  
Default: 100

**Value Range:**

1 LU/s/s–2000000 LU/s/s

**Description**

-

**H25.10 EPOS positioning reach threshold**

Address: 0x250A

Effective mode: Real time  
Unit: 1LU  
Data type: UInt32  
Change: Immediately

Min.: 0  
Max.: 2147483647  
Default: 7

**Value Range:**

0LU–2147483647LU

**Description**

-

**H25.12 EPOS positioning reached window time**

Address: 0x250C

Effective mode: Real time  
Unit: ms  
Data type: UInt32  
Change: Immediately

Min.: 0  
Max.: 2147483647  
Default: 0

**Value Range:**

0ms to 2147483647ms

**Description**

-

**H25.14 Jog1**

Address: 0x250E

Effective mode: Real time  
Unit: 1000 LU/min  
Data Type: Int32  
Change: Real-time

Min.: -40000000  
Max.: 40000000  
Default: -300

**Value Range:**

-40000000 Lu/min to 40000000 LU/min

**Description**

-

**H25.16 Jog2**

Address: 0x2510

Effective mode: Real time

Min.: -40000000

Unit: 1000 LU/min

Max.: 40000000

Data Type: Int32

Default: 300

Change: Real-time

**Value Range:**

-40000000 Lu/min to 40000000 LU/min

**Description**

-

**H25.18 EPOS-JOG1 position increment**

Address: 0x2512

Effective mode: Real time

Min.: 0

Unit: LU

Max.: 2147483648

Data type: UInt32

Default: 1000

Change: Immediately

**Value Range:**

0LU–2147483648LU

**Description**

-

**H25.20 EPOS-JOG2 position increment**

Address: 0x2514

Effective mode: Real time

Min.: 0

Unit: LU

Max.: 2147483648

Data Type: UInt32

Default: 1000

Change: Immediately

**Value Range:**

0LU–2147483648LU

**Description**

-

**H25.22 Homing type**

Address: 0x2516

Effective mode: Real time

Min.: -2

Unit: -

Max.: 35

Data Type: Int16

Default: 0

Change: Immediately

**Value Range:**

-2 to 35

**Description**

-

**H25.23 Homing high speed**

Address: 0x2517

Effective mode: Real time

Min.: 0

Unit: 1000 LU/min

Max.: 40000000

Data type: UInt32

Default: 5000

Change: Immediately

**Value Range:**

0 LU/min–40000000 LU/min

**Description**

-

**H25.25 Homing low speed**

Address: 0x2519

Effective mode: Real time

Min.: 0

Unit: 1000 LU/min

Max.: 40000000

Data type: UInt32

Default: 300

Change: Immediately

**Value Range:**

0 LU/min–40000000 LU/min

**Description**

-

**H25.27 Homing acc./dec. override**

Address: 0x251B

Effective mode: Real time

Min.: 0.00

Unit: %

Max.: 100.00

Data type: UInt16

Default: 100.00

Change: Immediately

**Value Range:**

0.00% to 100.00%

**Description**

-

## 4.21 H27 Program Block Parameters

### H27.00 Current block

Address: 0x2700

Min.: 0

Max.: 15

Default: 0

#### Value Range:

0 to 15

#### Description

-

Effective mode: Real time

Unit: -

Data Type: UInt16

Change: Unchangeable

### H27.01 Block 0 task

Address: 0x2701

Min.: 1

Max.: 8

Default: 1

#### Value Range:

1: Positioning

2: Fixed stopper

3: Forward cycle

4: Reverse cycle

5: Waiting

6: Switching

7: Setting I/O

8: Resetting I/O

#### Description

-

Effective mode: At stop

Unit: -

Data type: UInt16

Change: Immediately

### H27.02 Block 1 task

Address: 0x2702

Min.: 1

Max.: 8

Default: 1

#### Value Range:

Same as H27.01.

#### Description

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

<b>H27.03</b>	<b>Block 2 task</b> Address: 0x2703  Min.: 1 Max.: 8 Default: 1 <b>Value Range:</b> Same as H27.01. <b>Description</b> -	Effective mode: Unit: - Data Type: UInt16 Change: Immediately	At stop
<b>H27.04</b>	<b>Block 3 task</b> Address: 0x2704  Min.: 1 Max.: 8 Default: 1 <b>Value Range:</b> Same as H27.01. <b>Description</b> -	Effective mode: Unit: - Data Type: UInt16 Change: Immediately	At stop
<b>H27.05</b>	<b>Block 4 task</b> Address: 0x2705  Min.: 1 Max.: 8 Default: 1 <b>Value Range:</b> Same as H27.01. <b>Description</b> -	Effective mode: Unit: - Data Type: UInt16 Change: Immediately	At stop
<b>H27.06</b>	<b>Block 5 task</b> Address: 0x2706  Min.: 1 Max.: 8 Default: 1 <b>Value Range:</b> Same as H27.01.	Effective mode: Unit: - Data Type: UInt16 Change: Immediately	At stop

**Description**

-

**H27.07 Block 6 task**

Address: 0x2707

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop

Unit:

-

Data Type: UInt16

Change: Immediately

**H27.08 Segment 7 task**

Address: 0x2708

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop

Unit:

-

Data Type: UInt16

Change: Immediately

**H27.09 Block 8 task**

Address: 0x2709

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop

Unit:

-

Data Type: UInt16

Change: Immediately

**H27.10 Block 9 task**

Address: 0x270A

Min.: 1

Max.: 8

Default: 1

Effective mode: At stop

Unit:

-

Data Type: UInt16

Change: Immediately



**Value Range:**

Same as H27.01.

**Description**

-

**H27.11 Block 10 task**

Address: 0x270B

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H27.12 Block 11 task**

Address: 0x270C

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H27.13 Block 12 task**

Address: 0x270D

Min.: 1

Max.: 8

Default: 1

**Value Range:**

Same as H27.01.

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H27.14 Block 13 task**

Address: 0x270E

Min.: 1

Effective mode: At stop  
Unit: -

Max.: 8	Data Type: UInt16
Default: 1	Change: Immediately
<b>Value Range:</b>	
Same as H27.01.	
<b>Description</b>	
-	

**H27.15 Block 14 task**

Address: 0x270F	Effective mode: At stop
Min.: 1	Unit: -
Max.: 8	Data Type: UInt16
Default: 1	Change: Immediately
<b>Value Range:</b>	
Same as H27.01.	
<b>Description</b>	
-	

**H27.16 Block 15 task**

Address: 0x2710	Effective mode: At stop
Min.: 1	Unit: -
Max.: 8	Data Type: UInt16
Default: 1	Change: Immediately
<b>Value Range:</b>	
Same as H27.01.	
<b>Description</b>	
-	

**H27.17 Position of block 0**

Address: 0x2711	Effective mode: At stop
Min.: -2147483648	Unit: 1LU
Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b>	
-2147483648LU to 2147483647LU	
<b>Description</b>	
-	

<b>H27.19</b>	<b>Position of block 1</b>		
	Address: 0x2713	Effective mode:	At stop
	Min.: -2147483648	Unit:	1LU
	Max.: 2147483647	Data type:	Int32
	Default: 0	Change:	Immediately
	<b>Value Range:</b> -2147483648LU to 2147483647LU		
	<b>Description</b> -		
<b>H27.21</b>	<b>Position of block 2</b>		
	Address: 0x2715	Effective mode:	At stop
	Min.: -2147483648	Unit:	1LU
	Max.: 2147483647	Data type:	Int32
	Default: 0	Change:	Immediately
	<b>Value Range:</b> -2147483648LU to 2147483647LU		
	<b>Description</b> -		
<b>H27.23</b>	<b>Position of block 3</b>		
	Address: 0x2717	Effective mode:	At stop
	Min.: -2147483648	Unit:	1LU
	Max.: 2147483647	Data type:	Int32
	Default: 0	Change:	Immediately
	<b>Value Range:</b> -2147483648LU to 2147483647LU		
	<b>Description</b> -		
<b>H27.25</b>	<b>Position of block 4</b>		
	Address: 0x2719	Effective mode:	At stop
	Min.: -2147483648	Unit:	1LU
	Max.: 2147483647	Data type:	Int32
	Default: 0	Change:	Immediately
	<b>Value Range:</b> -2147483648LU to 2147483647LU		

**Description**

-

**H27.27 Position of block 5**

Address: 0x271B

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.29 Position of block 6**

Address: 0x271D

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.31 Position of block 7**

Address: 0x271F

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.33 Position of block 8**

Address: 0x2721

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.35 Position of block 9**

Address: 0x2723

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.37 Position of block 10**

Address: 0x2725

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.39 Position of block 11**

Address: 0x2727

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647

Data type: Int32

Default: 0

Change: Immediately

**Value Range:**

-2147483648LU to 2147483647LU

**Description**

-

**H27.41 Position of block 12**

Address: 0x2729

Effective mode: At stop

Min.: -2147483648

Unit: 1LU

Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b>	
-2147483648LU to 2147483647LU	
<b>Description</b>	
-	

**H27.43 Position of block 13**

Address: 0x272B	Effective mode: At stop
Min.: -2147483648	Unit: 1LU
Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b>	
-2147483648LU to 2147483647LU	
<b>Description</b>	
-	

**H27.45 Position of block 14**

Address: 0x272D	Effective mode: At stop
Min.: -2147483648	Unit: 1LU
Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b>	
-2147483648LU to 2147483647LU	
<b>Description</b>	
-	

**H27.47 Position of block 15**

Address: 0x272F	Effective mode: At stop
Min.: -2147483648	Unit: 1LU
Max.: 2147483647	Data type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b>	
-2147483648LU to 2147483647LU	
<b>Description</b>	
-	

**H27.49    Block 0 speed**

Address: 0x2731

Effective mode: At stop  
Unit: 1000 LU/min  
Data type: UInt32  
Change: Immediately

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

**H27.51    Block 1 speed**

Address: 0x2733

Effective mode: At stop  
Unit: 1000 LU/min  
Data type: UInt32  
Change: Immediately

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

**H27.53    Block 2 speed**

Address: 0x2735

Effective mode: At stop  
Unit: 1000 LU/min  
Data type: UInt32  
Change: Immediately

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

**H27.55    Block 3 speed**

Address: 0x2737

Effective mode: At stop  
Unit: 1000 LU/min  
Data type: UInt32  
Change: Immediately

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

**H27.57 Block 4 speed**

Address: 0x2739

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

Effective mode: At stop  
 Unit: 1000 LU/min  
 Data type: UInt32  
 Change: Immediately

**H27.59 Block 5 speed**

Address: 0x273B

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

Effective mode: At stop  
 Unit: 1000 LU/min  
 Data type: UInt32  
 Change: Immediately

**H27.61 Block 6 speed**

Address: 0x273D

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 Lu/min–4294967295 LU/min

**Description**

-

Effective mode: At stop  
 Unit: 1000 LU/min  
 Data type: UInt32  
 Change: Immediately

**H27.63 Block 7 speed**

Address: 0x273F

Min.: 0

Max.: 4294967295

Effective mode: At stop  
 Unit: 1000 LU/min  
 Data type: UInt32



Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.65 Block 8 speed**

Address: 0x2741

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.67 Block 9 speed**

Address: 0x2743

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.69 Block 10 speed**

Address: 0x2745

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.71 Block 11 speed**

Address: 0x2747

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.73 Block 12 speed**

Address: 0x2749

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.75 Block 13 speed**

Address: 0x274B

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.77 Block 14 speed**

Address: 0x274D

Effective mode: At stop

Min.: 0

Unit: 1000 LU/min

Max.: 4294967295

Data type: UInt32

Default: 600

Change: Immediately

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

**H27.79 Block 15 speed**

Address: 0x274F

Min.: 0

Max.: 4294967295

Default: 600

**Value Range:**

0 LU/min–4294967295 LU/min

**Description**

-

Effective mode: At stop  
Unit: 1000 LU/min  
Data type: UInt32  
Change: Immediately

**H27.81 Block 0 acc. override**

Address: 0x2751

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**H27.82 Block 1 acc. override**

Address: 0x2752

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**H27.83 Block 2 acc. override**

Address: 0x2753

Min.: 1.00

Max.: 100.00

Default: 100.00

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-

**H27.84 Block 3 acc. override**

Address: 0x2754

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.85 Block 4 acc. override**

Address: 0x2755

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.86 Block 5 acc. override**

Address: 0x2756

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.87 Block 6 acc. override**

Address: 0x2757

Min.: 1.00

Effective mode: At stop  
 Unit: %

Max.: 100.00  
 Default: 100.00  
**Value Range:**  
 1.00% to 100.00%

Data type: UInt16  
 Change: Immediately

**Description**

-

#### **H27.88 Block 7 acc. override**

Address: 0x2758

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**  
 1.00% to 100.00%

**Description**

-

#### **H27.89 Block 8 acc. override**

Address: 0x2759

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**  
 1.00% to 100.00%

**Description**

-

#### **H27.90 Block 9 acc. override**

Address: 0x275A

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**  
 1.00% to 100.00%

**Description**

-

**H27.91 Block 10 acc. override**

Address: 0x275B

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.92 Block 11 acc. override**

Address: 0x275C

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.93 Block 12 acc. override**

Address: 0x275D

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**H27.94 Block 13 acc. override**

Address: 0x275E

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

**Value Range:**

1.00% to 100.00%

Effective mode: At stop  
 Unit: %  
 Data type: UInt16  
 Change: Immediately

**Description**

-

**H27.95 Block 14 acc. override**

Address: 0x275F

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

Unit: %

Data type: UInt16

Change: Immediately

**H27.96 Block 15 acc. override**

Address: 0x2760

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

Unit: %

Data type: UInt16

Change: Immediately

## 4.22 H28 Program Block Parameters

**H28.00 Block 0 dec. override**

Address: 0x2800

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

Unit: %

Data type: UInt16

Change: Immediately

**H28.01 Block 1 dec. override**

Address: 0x2801

Effective mode: At stop

mode:

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-

**H28.02 Block 2 dec. override**

Address: 0x2802

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-

**H28.03 Block 3 dec. override**

Address: 0x2803

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-

**H28.04 Block 4 dec. override**

Address: 0x2804

Effective mode: At stop

Min.: 1.00  
 Max.: 100.00  
 Default: 100.00

Unit: %  
 Data type: UInt16  
 Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-



**H28.05    Block 5 dec. override**

Address: 0x2805

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode:  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.06    Block 6 dec. override**

Address: 0x2806

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode:  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.07    Block 7 dec. override**

Address: 0x2807

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode:  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.08    Block 8 dec. override**

Address: 0x2808

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

Effective mode:  
Unit: %  
Data type: UInt16  
Change: Immediately

**Description**

-

**H28.09 Block 9 dec. override**

Address: 0x2809

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

mode:

Unit: %

Data type: UInt16

Change: Immediately

**H28.10 Block 10 dec. override**

Address: 0x280A

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

mode:

Unit: %

Data type: UInt16

Change: Immediately

**H28.11 Block 11 dec. override**

Address: 0x280B

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop

mode:

Unit: %

Data type: UInt16

Change: Immediately

**H28.12 Block 12 dec. override**

Address: 0x280C

Min.: 1.00

Max.: 100.00

Default: 100.00

Effective mode: At stop

mode:

Unit: %

Data type: UInt16

Change: Immediately

**Value Range:**

1.00% to 100.00%

**Description**

-

**H28.13 Block 13 dec. override**

Address: 0x280D

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.14 Block 14 dec. override**

Address: 0x280E

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.15 Block 15 dec. override**

Address: 0x280F

Min.: 1.00

Max.: 100.00

Default: 100.00

**Value Range:**

1.00% to 100.00%

**Description**

-

Effective mode: At stop  
Unit: %  
Data type: UInt16  
Change: Immediately

**H28.16 Task mode of block 0**

Address: 0x2810

Min.: 0

Effective mode: At stop  
Unit: -

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Data Type: UInt16

Change: Immediately

**H28.17 Task mode of block 1**

Address: 0x2811

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: UInt16

Change: Immediately

**H28.18 Task mode of block 2**

Address: 0x2812

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: UInt16

Change: Immediately

**H28.19 Task mode of block 3**

Address: 0x2813

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: UInt16

Change: Immediately

**H28.20 Task mode of block 4**

Address: 0x2814

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.21 Task mode of block 5**

Address: 0x2815

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.22 Task mode of block 6**

Address: 0x2816

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.23 Task mode of block 7**

Address: 0x2817

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**Description**

-

**H28.24 Task mode of block 8**

Address: 0x2818

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H28.25 Task mode of block 9**

Address: 0x2819

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H28.26 Task mode of block 10**

Address: 0x281A

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**H28.27 Task mode of block 11**

Address: 0x281B

Min.: 0

Max.: 65535

Default: 0

Effective mode: At stop

Unit: -

Data Type: UInt16

Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H28.28 Task mode of block 12**

Address: 0x281C

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.29 Task mode of block 13**

Address: 0x281D

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.30 Task mode of block 14**

Address: 0x281E

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode: At stop  
Unit: -  
Data Type: UInt16  
Change: Immediately

**H28.31 Task mode of block 15**

Address: 0x281F

Min.: 0

Effective mode: At stop  
Unit: -

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Data Type: UInt16

Change: Immediately

**H28.32 Block 0 task parameter**

Address: 0x2820

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately

**H28.34 Block 1 task parameter**

Address: 0x2822

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately

**H28.36 Block 2 task parameter**

Address: 0x2824

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately



**H28.38    Block 3 task parameter**

Address:	0x2826	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Immediately
<b>Value Range:</b>			
	0 to 2147483647		
<b>Description</b>			
	-		

**H28.40    Block 4 task parameter**

Address:	0x2828	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Immediately
<b>Value Range:</b>			
	0 to 2147483647		
<b>Description</b>			
	-		

**H28.42    Block 5 task parameter**

Address:	0x282A	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Immediately
<b>Value Range:</b>			
	0 to 2147483647		
<b>Description</b>			
	-		

**H28.44    Block 6 task parameter**

Address:	0x282C	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	2147483647	Data Type:	Int32
Default:	0	Change:	Immediately
<b>Value Range:</b>			
	0 to 2147483647		

**Description**

-

**H28.46 Block 7 task parameter**

Address: 0x282E

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately

**H28.48 Block 8 task parameter**

Address: 0x2830

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately

**H28.50 Block 9 task parameter**

Address: 0x2832

Min.: 0

Max.: 2147483647

Default: 0

**Value Range:**

0 to 2147483647

**Description**

-

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Change: Immediately

**H28.52 Block 10 task parameter**

Address: 0x2834

Min.: 0

Max.: 2147483647

Effective mode: At stop

mode:

Unit: -

Data Type: Int32

Default: 0	Change: Immediately
<b>Value Range:</b> 0 to 2147483647	
<b>Description</b> -	

**H28.54 Block 11 task parameter**

Address: 0x2836	Effective mode: At stop
Min.: 0	Unit: -
Max.: 2147483647	Data Type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b> 0 to 2147483647	
<b>Description</b> -	

**H28.56 Block 12 task parameter**

Address: 0x2838	Effective mode: At stop
Min.: 0	Unit: -
Max.: 2147483647	Data Type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b> 0 to 2147483647	
<b>Description</b> -	

**H28.58 Task parameter of block 13**

Address: 0x283A	Effective mode: At stop
Min.: 0	Unit: -
Max.: 2147483647	Data Type: Int32
Default: 0	Change: Immediately
<b>Value Range:</b> 0 to 2147483647	
<b>Description</b> -	

**H28.60 Block 14 task parameter**

Address: 0x283C	Effective mode: At stop
-----------------	-------------------------

Min.: 0  
Max.: 2147483647  
Default: 0

Unit: -  
Data Type: Int32  
Change: Immediately

**Value Range:**

0 to 2147483647

**Description**

-

**H28.62 Block 15 task parameter**

Address: 0x283E

Effective mode: At stop

Min.: 0  
Max.: 2147483647  
Default: 0

Unit: -  
Data Type: Int32  
Change: Immediately

**Value Range:**

0 to 2147483647

**Description**

-

**H28.64 Fixed stopper monitoring window**

Address: 0x2840

Effective mode: At stop

Min.: 0  
Max.: 4294967295  
Default: 0

Unit: -  
Data Type: UInt32  
Change: Immediately

**Value Range:**

0 to 4294967295

**Description**

-

**H28.66 Max. following error of fixed stopper**

Address: 0x2842

Effective mode: At stop

Min.: 0  
Max.: 4294967295  
Default: 0

Unit: -  
Data type: UInt32  
Change: Immediately

**Value Range:**

0 to 4294967295

**Description**

-

**H28.68 External trigger source**

Address:	0x2844	Effective mode:	At stop
Min.:	0	Unit:	-
Max.:	1	Data Type:	UInt16
Default:	0	Change:	At stop

**Value Range:**

0: Triggered by STW1.bit13

1: Triggered by DI

**Description**

-

**4.23 H29 PN Message Value**

**H29.00 Control word 1 (STW1)**

Address:	0x2900	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

Bit0: 1 = Pulse enable allowed; 0 = OFF1, ramp to stop, pulse cleared, ready to switch on  
 bit1: 1 = No OFF2 (pulse enable allowed); 0 = OFF2, coast to stop, pulse cleared immediately, switch-on inhibited  
 bit2: 1 = No OFF3 (pulse enable allowed); 0 = OFF3 quick stop, P1135 brake, pulse cleared, switch-on inhibited  
 bit3: 1 = Enable allowed; 0 = Operation inhibited (pulse cleared)  
 bit4: 1 = Ramp function generator available; 0 = Ramp function generator inhibited  
 bit5: 1 = Ramp function generator continued; 0 = Ramp function generator output frozen  
 bit6: 1 = Setpoint enabled; 0 = Setpoint inhibited (ramp function generator input being zero)  
 bit7: Rising edge-triggered, response fault  
 bit8: JOG1  
 bit9: JOG2  
 bit10: 1 = PLC controlled  
 bit11: Reserved  
 bit12: Reserved  
 bit13: Reserved  
 bit14: Reserved  
 bit15: Reserved

**Description**

-

**H29.01 Control word 2 (STW2)**

Address: 0x2901

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.02 Speed setpoint A (VEL\_NSOLL\_A)**

Address: 0x2902

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.04 Speed setpoint B (VEL\_NSOLL\_B)**

Address: 0x2904

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data Type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H29.06 Encoder control word (G1\_STW)**

Address: 0x2906

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

Bit0: bit7 = 0, searching for reference point 1; bit7 = 1, measure pointer 1  
 bit1: bit7 = 0, searching for reference point 2; bit7 = 1, measure pointer 2  
 bit2: bit7 = 0, searching for reference point 3; bit7 = 1, measure pointer 3  
 bit3: bit7 = 0, searching for reference point 4; bit7 = 1, measure pointer 4  
 bit4: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel operation  
 bit5: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel operation  
 bit6: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel operation  
 bit7: Mode selection 1 = Real-time measurement 0 = Searching for the reference point  
 bit8: Reserved  
 bit9: Reserved  
 bit10: Reserved  
 bit11: Zero setting mode 0 = Absolute position 1 = Relative position  
 bit12: Rising edge-triggered Request for setting the zero bit  
 bit13: Rising edge-triggered Request for cyclic transmission of absolute position in G1\_XIST2  
 bit14: Parking encoder  
 bit15: Rising-edge triggered Response encoder gripper fault

#### Description

-

### H29.07 Position deviation (XERR)

Address:	0x2907	Effective mode:	-
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Unchangeable

#### Value Range:

-2147483648 to 2147483647

#### Description

-

### H29.09 Position loop gain (KPC)

Address:	0x2909	Effective mode:	-
Min.:	-2147483648	Unit:	-
Max.:	2147483647	Data type:	Int32
Default:	0	Change:	Unchangeable

#### Value Range:



-2147483648 to 2147483647

**Description**

-

**H29.11 Position control word 1 (POS\_STW1)**

Address: 0x290B

Effective      Real time  
mode:

Min.:      0

Unit:      -

Max.:      65535

Data Type:    UInt16

Default:    0

Change:      Unchangeable

**Value Range:**

bit0: bit0–bit5 block selection IS620F supports up to 16 blocks

bit1: bit0–bit5 block selection IS620F supports up to 16 blocks

bit2: bit0–bit5 block selection IS620F supports up to 16 blocks

bit3: bit0–bit5 block selection IS620F supports up to 16 blocks

bit4: bit0–bit5 block selection IS620F supports up to 16 blocks

bit5: bit0–bit5 block selection IS620F supports up to 16 blocks

bit6: Reserved

bit7: Reserved

bit8: 1 = Absolute positioning 0 = Relative positioning

bit9: 1 = Forward

bit10: 1 = Reverse

bit11: Reserved

bit12: 1 = Continuous transmission 0 = MDI block modification activated by running the rising edge of the program segment (STW1.6)

bit13: Reserved

bit14: 1 = Setting signal selected 0 = Positioning signal selected

bit15: 1= MDI sub-mode 0 = Program segment sub-mode

**Description**

-

**H29.12 MDI position setting (EPOS)**

Address: 0x290C

Effective      Real time  
mode:

Min.:      -2147483648

Unit:      -

Max.:      2147483647

Data Type:    Int32

Default:    0

Change:      Unchangeable

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H29.14 MDI speed setting (EPOS)**

Address: 0x290E

Min.: 0

Max.: 4294967295

Default: 0

**Value Range:**

0 to 4294967295

**Description**

-

Effective mode:  
Unit: -  
Data type: UInt32  
Change: Unchangeable

**H29.16 MDI acceleration override (EPOS)**

Address: 0x2910

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

**H29.17 MDI deceleration override (EPOS)**

Address: 0x2911

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

0 to 65535

**Description**

-

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

**H29.18 MDI mode (EPOS)**

Address: 0x2912

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

Effective mode:  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

bit0: 1 = Absolute positioning 0 = Relative positioning  
bit1: 1 = Forward  
bit2: 1 = Reverse  
bit3: Reserved  
bit4: Reserved  
bit5: Reserved  
bit6: Reserved  
bit7: Reserved  
bit8: Reserved  
bit9: Reserved  
bit10: Reserved  
bit11: Reserved  
bit12: Reserved  
bit13: Reserved  
bit14: Reserved  
bit15: Reserved

**Description**

-

**H29.19    Position control word 2 (POS\_STW2)**

Address:	0x2913	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

bit0: 1 = Tracking mode activated  
 bit1: 1 = Set reference point  
 bit2: 1 = Reference point stopper activated  
 bit3: Reserved  
 bit4: Reserved  
 bit5: 1 = JOG incremental positioning activated 0 = Speed activated  
 bit6: Reserved  
 bit7: Reserved  
 bit8: Reserved  
 bit9: 1 = Searching for the reference point in the reverse direction 0 = Start  
 searching for the reference point in the forward direction  
 bit10: Reserved  
 bit11: Reserved  
 bit12: Reserved  
 bit13: Reserved  
 bit14: 1 = Software limit switch activated  
 bit15: 1 = Stopper activated

**Description**

-

**H29.20 Position speed override (EPOS)**

Address: 0x2914

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.21 Customized receive word for telegram 111**

Address: 0x2915

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

#### H29.22 Torque reduction (MOMRED)

Address: 0x2916

Effective mode: Real time  
Unit: -  
Data Type: UInt16  
Change: Unchangeable

Min.: 0  
Max.: 16363  
Default: 0

##### **Value Range:**

0 to 16363

##### **Description**

-

#### H29.23 Torque reference (AdditiveTorque)

Address: 0x2917

Effective mode: Real time  
Unit: -  
Data Type: Int16  
Change: Unchangeable

Min.: -32768  
Max.: 32767  
Default: 0

##### **Value Range:**

-32768 to 32767

##### **Description**

-

#### H29.24 Torque upper limit

Address: 0x2918

Effective mode: Real time  
Unit: -  
Data type: Int16  
Change: Unchangeable

Min.: -32768  
Max.: 32767  
Default: 0

##### **Value Range:**

-32768 to 32767

##### **Description**

-

#### H29.25 Torque lower limit

Address: 0x2919

Effective mode: Real time  
Unit: -  
Data type: Int16  
Change: Unchangeable

Min.: -32768  
Max.: 32767  
Default: 0

##### **Value Range:**

-32768 to 32767

**Description**

-

**H29.26 Customized receive word for 850 additive telegram**

Address: 0x291A

Effective mode: Real time

Min.: 0

Unit: -

Max.: -1

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

0 to -1

**Description**

-

**H29.27 Message word (EPOS\_MELDW)**

Address: 0x291B

Effective mode: Real time

Min.: 0

Unit: -

Max.: -1

Data Type: Int16

Default: 0

Change: Unchangeable

**Value Range:**

0 to -1

**Description**

-

**H29.50 Status word 1 (ZSW1)**

Address: 0x2932

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

- bit0: 1 = Ready to switch on, control circuit switched on, initialization done
- bit1: 1 = Ready to run, main circuit switched on
- bit2: 1 = Run enable
- bit3: 1 = Fault
- bit4: 1 = Coast to stop deactivated (OFF2 deactivated) 0 = Cost to stop activated (OFF2 activated)
- bit5: 1 = Quick stop deactivated (OFF2 deactivated) 0 = Quick stop activated (OFF2 activated)
- bit6: 1 = Switch-on inhibited
- bit7: 1 = Warning existed
- bit8: Reserved
- bit9: 1 = PLC control request
- bit10: Reserved
- bit11: Reserved
- bit12: Reserved
- bit13: Reserved
- bit14: Reserved
- bit15: Reserved

**Description**

-

**H29.51    Status word 2 (ZSW2)**

Address: 0x2933

Min.:     0  
Max.:    65535  
Default: 0

**Value Range:**

Effective	Real time
mode:	
Unit:	-
Data Type:	UInt16
Change:	Unchangeable

bit0: Reserved  
 bit1: Reserved  
 bit2: Reserved  
 bit3: Reserved  
 bit4: Reserved  
 bit5: Reserved  
 bit6: Reserved  
 bit7: Reserved  
 bit8: Reserved  
 bit9: Reserved  
 bit10: Reserved  
 bit11: Reserved  
 bit12: bit12–bit15 drive heartbeat count value, uploaded to PLC  
 bit13: bit12–bit15 drive heartbeat count value, uploaded to PLC  
 bit14: bit12–bit15 drive heartbeat count value, uploaded to PLC  
 bit15: bit12–bit15 drive heartbeat count value, uploaded to PLC

**Description**

-

**H29.52 Speed actual value A (VEL\_NIST\_A)**

Address: 0x2934	Effective mode:	Real time
Min.: -32768	Unit:	-
Max.: 32767	Data type:	Int16
Default: 0	Change:	Unchangeable

**Value Range:**

-32768 to 32767

**Description**

-

**H29.53 Speed actual B (VEL\_NSOLL\_B)**

Address: 0x2935	Effective mode:	Real time
Min.: -2147483648	Unit:	-
Max.: 2147483647	Data Type:	Int32
Default: 0	Change:	Unchangeable

**Value Range:**

-2147483648 to 2147483647

**Description**

-



**H29.55 Encoder status word (G1\_ZSW)**

Address: 0x2937

Effective mode:	Real time
Unit:	-
Data Type:	UInt16
Change:	Unchangeable

Min.: 0

Max.: 65535

Default: 0

**Value Range:**

bit0: 1 = Function 1 activated

bit1: 1 = Function 2 activated

bit2: 1 = Function 3 activated

bit3: 1 = Function 4 activated

bit4: 1 = Actual value 1 readable

bit5: 1 = Actual value 2 readable

bit6: 1 = Actual value 3 readable

bit7: 1 = Actual value 4 readable

bit8: Touch probe 1

bit9: Touch probe 2

bit10: Reserved

bit11: Response encoder fault

bit12: Set zero response

bit13: Cyclic transmission of the absolute position in G1\_XIST2

bit14: Parking encoder activated

bit15: The encoder is faulty.

**Description**

-

**H29.56 Encoder 1 position actual value 1 (G1\_XIST1)**

Address: 0x2938

Effective mode:	Real time
-----------------	-----------

Min.: 0

Max.: 0

Default: 0

Unit:	-
Data type:	UInt32
Change:	Unchangeable

**Value Range:**

0 to 0

**Description**

-

**H29.58 Encoder 1 position actual value 2 (G1\_XIST2)**

Address: 0x293A

Effective mode:	Real time
-----------------	-----------

Min.: 0

Max.: 0

Unit:	-
Data type:	UInt32

Default: 0

Change: Unchangeable

**Value Range:**

0 to 0

**Description**

-

**H29.60 Position status word 1 (POS\_ZSW1)**

Address: 0x293C

Effective Real time  
mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

bit0: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit1: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit2: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit3: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit4: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit5: bit0–bit5 effective traversing block IS620F supports up to 16 blocks

bit6: Reserved

bit7: Reserved

bit8: 1 = Reverse stopper activated

bit9: 1 = Forward stopper activated

bit10: 1 = JOG activated bit11: 1 = Proactive reference point approach

activated bit12: Reserved bit13: 1 = Running block activated bit14: 1 = Setting

activated bit15: 1 = MDI activated 0 = MDI deactivated

**Description**

-

**H29.61 Position status word 2 (POS\_ZSW2)**

Address: 0x293D

Effective Real time  
mode:

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

bit0: 1 = Tracking mode activated  
bit1: 1 = Speed limit activated  
bit2: 1 = Setpoint available  
bit3: Reserved  
bit4: 1 = Axis moving forwardly  
bit5: 1 = Axis moving reversely  
bit6: 1 = Negative limit switch reached  
bit7: 1 = Positive limit switch reached  
bit8: 1 = Position actual value <= Limit switch position 1  
bit9: 1 = Position actual value <= limit switch position 2  
bit10: 1 = Direct output 1 through running block setting  
bit11: 1 = Direct output 2 through running block setting  
bit12: 1 = Fixed stop point reached  
bit13: 1 = Fixed stop point fastening torque reached  
bit14: 1 = Running to the fixed stop point activated  
bit15: 1 = Running command effective

**Description**

-

**H29.63 Customized send word for telegram 111**

Address: 0x293F	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.65 Fault code**

Address: 0x2941	Effective mode:	Real time
Min.: 0	Unit:	-
Max.: 65535	Data Type:	UInt16
Default: 0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.66 Warning code**

Address: 0x2942

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data Type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.67 Actual torque**

Address: 0x2943

Effective mode: Real time

Min.: 32768

Unit: -

Max.: 32767

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

32768 to 32767

**Description**

-

**H29.68 User-defined send word for 850 additive telegram**

Address: 0x2944

Effective mode: Real time

Min.: 0

Unit: -

Max.: 65535

Data type: UInt16

Default: 0

Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H29.69 XIST\_A position feedback**

Address: 0x2945

Effective mode: Real time

Min.: -2147483648

Unit: -

Max.: 2147483647

Data type: Int32

Default: 0

Change: Unchangeable

**Value Range:**

-2147483648 to 2147483647

**Description**

-

**H29.90 Modulo axis modulus**

Address:	0x295A	Effective mode:	Real time
Min.:	0	Unit:	-
Max.:	2147483647	Data Type:	UInt32
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 2147483647

**Description**

-

**4.24 H30 Related Variables Read through Communication**

**H30.00 Servo state read by communication**

Address:	0x3000	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H30.01 DO function state 1 read through communication**

Address:	0x3001	Effective mode:	-
Min.:	0	Unit:	-
Max.:	65535	Data Type:	UInt16
Default:	0	Change:	Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**H30.02 DO function state 2 read through communication**

Address:	0x3002	Effective mode:	-
----------	--------	-----------------	---

Min.: 0	Unit: -
Max.: 65535+H941	Data type: UInt16
Default: 0	Change: Unchangeable

**Value Range:**

0–65535+H941

**Description**

-

**H30.03 Input pulse reference sampling read via communication**

Address: 0x3003	Effective mode: -
Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Unchangeable

**Value Range:**

0 to 65535

**Description**

-

**4.25 H31 Communication Setting****H31.00 VDI virtual level set through communication**

Address: 0x3100	Effective mode: Real time
Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H31.04 DO state set through communication**

Address: 0x3104	Effective mode: Real time
Min.: 0	Unit: -
Max.: 65535	Data Type: UInt16
Default: 0	Change: Immediately

**Value Range:**

0 to 65535

**Description**

-

**H31.05 AO set through communication**

Address: 0x3105

Effective mode: Real time

Min.: -10000

Unit: mV

Max.: 10000

Data type: Int16

Default: 0

Change: Immediately

**Value Range:**

-10000mV to 10000mV

**Description**

-

**H31.09 Speed reference set via communication**

Address: 0x3109

Effective mode: Real time

Min.: -6000

Unit: RPM

Max.: 6000.000

Data type: Int32

Default: 0.000

Change: Immediately

**Value Range:**

-6000.000 RPM to 6000.000 RPM

**Description**

-

**H31.11 Torque reference set via communication**

Address: 0x310B

Effective mode: Real time

Min.: -100

Unit: %

Max.: 100.000

Data Type: Int32

Default: 0.000

Change: Immediately

**Value Range:**

-100.000% to 100.000%

**Description**

-

## 5 Parameter List

### 5.1 Parameter Group H00

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H00.00	2000-01h	Motor SN	0 to 65535	14101	-	At stop	<a href="#">"H00_en.00" on page 132</a>
H00.02	2000-03h	Customized No.	0.00 to 4294967295.00	0.00	-	Unchangeable	<a href="#">"H00_en.02" on page 132</a>
H00.04	2000-05h	Encoder version	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">"H00_en.04" on page 132</a>
H00.05	2000-06h	Serial-type motor code	0 to 65535	0	-	Unchangeable	<a href="#">"H00_en.05" on page 133</a>
H00.06	2000-07h	FPGA customized No.	0.00 to 655.35	0.00	-	Unchangeable	<a href="#">"H00_en.06" on page 133</a>
H00.07	2000-08h	STO version	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">"H00_en.07" on page 133</a>
H00.08	2000-09h	Serial encoder type	0 to 65535	0	-	At stop	<a href="#">"H00_en.08" on page 133</a>

### 5.2 Parameter Group H01

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H01.00	2001-01h	MCU software version	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">"H01_en.00" on page 134</a>
H01.01	2001-02h	FPGA software version	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">"H01_en.01" on page 134</a>
H01.02	2001-03h	Servo drive series No.	0 to 65535	0	-	Unchangeable	<a href="#">"H01_en.02" on page 134</a>
H01.08	2001-09h	Model parameter version 1	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">"H01_en.08" on page 135</a>
H01.09	2001-0Ah	Model parameter version 2	0 to 65535	0	-	Unchangeable	<a href="#">"H01_en.09" on page 135</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H01.10	2001-0Bh	Drive series No.	2: S1R6 3: S2R8 5: S5R5 60005: S6R6 6: S7R6 7: S012 8: S018 9: S022 10: S027 10001: T3R5 10002: T5R4 10003: T8R4 10004: T012 10005: T017 10006: T021 10007: T026	3	-	At stop	<a href="#">" H01_en.10"</a> <a href="#">on page 135</a>
H01.11	2001-0Ch	DC-AC voltage class	0V to 65535V	220	V	Unchangeable	<a href="#">" H01_en.11"</a> <a href="#">on page 136</a>
H01.12	2001-0Dh	Drive rated power	0.00 kW–10737418.24 kW	0.40	kW	Unchangeable	<a href="#">" H01_en.12"</a> <a href="#">on page 136</a>
H01.14	2001-0Fh	Max. output power of the drive	0.00 kW–10737418.24 kW	0.40	kW	Unchangeable	<a href="#">" H01_en.14"</a> <a href="#">on page 137</a>
H01.16	2001-11h	Rated output current of the drive	0.00A to 10737418.24A	2.80	A	Unchangeable	<a href="#">" H01_en.16"</a> <a href="#">on page 137</a>
H01.18	2001-13h	Max. output current of the drive	0.00A to 10737418.24A	10.10	A	Unchangeable	<a href="#">" H01_en.18"</a> <a href="#">on page 137</a>
H01.40	2001-29h	DC bus overvoltage protection threshold	0V to 2000V	420	V	Real-time	<a href="#">" H01_en.40"</a> <a href="#">on page 137</a>
H01.75	2001-4Ch	Current loop amplification factor	0.00 to 655.35	1.00	-	Real-time	<a href="#">" H01_en.75"</a> <a href="#">on page 138</a>
H01.88	2001-59h	Junction temperature parameter version 1	0.0 to 6553.5	0.0	-	Unchangeable	<a href="#">" H01_en.88"</a> <a href="#">on page 138</a>
H01.89	2001-5Ah	Junction temperature parameter version 2	0 to 65535	0	-	Unchangeable	<a href="#">" H01_en.89"</a> <a href="#">on page 138</a>

### 5.3 Parameter Group H02

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H02.00	2002-01h	Control mode	0: Speed control mode 1: Position control mode 2: Torque control mode 3: Torque<->Speed control mode 4: Speed<->Position control mode 5: Torque<->Position control mode 6: Torque<->Speed<->Position compound mode 11: PN communication mode	11	-	At stop	<a href="#">" H02_en.00" on page 139</a>
H02.01	2002-02h	Absolute system selection	0: Incremental mode 1: Absolute position linear mode 2: Absolute position rotation mode 3: Absolute position linear mode (without encoder overflow warning) 4: Absolute position single-turn mode 5: Absolute position rotational mode, modal axis single modal revolution absolute command	0	-	At stop	<a href="#">" H02_en.01" on page 139</a>
H02.02	2002-03h	Rotation direction selection	0: Counterclockwise (CCW) as forward direction 1: Clockwise (CW) as forward direction	0	-	At stop	<a href="#">" H02_en.02" on page 139</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H02.05	2002-06h	Stop mode at S-ON OFF	-5: Stop in PN communication state (ramp-to-stop/quick stop/coast-to-stop), keeping dynamic braking state -4: Stop based on ramp 2, keeping dynamic braking state -3: Stop at zero speed, keeping dynamic braking state -2: Stop based on ramp 1, keeping dynamic braking state -1: Dynamic braking stop, keeping dynamic braking state 0: Coast to stop, keeping de-energized state 1: Stop based on ramp 1, keeping de-energized state 2: Dynamic braking stop, keeping de-energized state 3: Stop in PN communication state (ramp-to-stop/quick stop/coast-to-stop), keeping de-energized state	3	-	Immediately	<a href="#">" H02_en.05" on page 141</a>
H02.06	2002-07h	Stop mode at No.2 fault	-5: Stop at zero speed, keeping dynamic braking state -4: Stop at emergency stop torque, keeping dynamic braking state -3: Stop based on ramp 2, keeping dynamic braking state -2: Stop based on ramp 1, keeping dynamic braking state -1: Dynamic braking stop, keeping dynamic braking state 0: Coast to stop, keeping de-energized state 1: Stop based on ramp 1, keeping de-energized state 2: Stop based on ramp 2, keeping de-energized state 3: Stop at emergency stop torque, keeping de-energized state 4: Dynamic braking stop, keeping de-energized state	2	-	Immediately	<a href="#">" H02_en.06" on page 142</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H02.07	2002-08h	Stop mode at overtravel	0: Coast to stop, keeping de-energized state 1: Stop at zero speed, keeping position lock state 2: Stop at zero speed, keeping de-energized state 3: Stop based on ramp 2, keeping de-energized state 4: Stop based on ramp 2, keeping position lock state 5: Dynamic braking stop, keeping de-energized state 6: Dynamic braking stop, keeping dynamic braking state 7: Not responding to overtravel	8	-	Immediately	<a href="#">" H02_en.07" on page 142</a>
H02.08	2002-09h	Stop mode at No.1 fault	0: Coast to stop, keeping de-energized state 1: Dynamic braking stop, keeping de-energized state 2: Dynamic braking stop, keeping dynamic braking state	2	-	Immediately	<a href="#">" H02_en.08" on page 143</a>
H02.09	2002-0Ah	Delay from brake output ON to command received	0 ms to 500 ms	250	ms	Real-time	<a href="#">" H02_en.09" on page 143</a>
H02.10	2002-0Bh	Delay from brake output OFF to motor de-energized	50 ms to 1000 ms	150	ms	Real-time	<a href="#">" H02_en.10" on page 143</a>
H02.11	2002-0Ch	Motor speed threshold at brake output OFF in rotation state	20 rpm to 3000 rpm	30	RPM	Real-time	<a href="#">" H02_en.11" on page 144</a>
H02.12	2002-0Dh	Delay from S-ON OFF to brake output OFF in rotation state	1 ms to 65535 ms	500	ms	Real-time	<a href="#">" H02_en.12" on page 144</a>
H02.15	2002-10h	LED warning display	0: Output warning information immediately 1: Not output warning information	0	-	Real-time	<a href="#">" H02_en.15" on page 144</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H02.17	2002-12h	Stop mode upon main circuit power failure	0: Keep current action 1: Stop upon fault as defined by H0206 2: Stop at S-ON OFF as defined by H0205 3: Stop quickly as defined by H0218	2	-	Real-time	<a href="#">" H02_en.17" on page 145</a>
H02.18	2002-13h	DI emergency stop mode selection	0: Coast to stop, keeping de-energized state 1: Ramp 1 stop, keeping de-energized state 2: Ramp 2 stop, keeping de-energized state 3: Stop at emergency stop torque, keeping de-energized state	2	-	Real-time	<a href="#">" H02_en.18" on page 145</a>
H02.21	2002-16h	Permissible minimum resistance of regenerative resistor	1Ω to 1000 Ω	40	Ω	Unchangeable	<a href="#">" H02_en.21" on page 145</a>
H02.22	2002-17h	Power of built-in regenerative resistor	0W to 65535W	50	W	Unchangeable	<a href="#">" H02_en.22" on page 146</a>
H02.23	2002-18h	Resistance of built-in regenerative resistor	0Ω to 65535Ω	50	Ω	Unchangeable	<a href="#">" H02_en.23" on page 146</a>
H02.24	2002-19h	Resistor heat dissipation coefficient	10%–100%	30	%	Real-time	<a href="#">" H02_en.24" on page 147</a>
H02.25	2002-1Ah	Regenerative resistor type	0: Built-in 1: External, natural cooling 2: External, forced air cooling 3: No resistor needed	3	-	Real-time	<a href="#">" H02_en.25" on page 148</a>
H02.26	2002-1Bh	Power of external regenerative resistor	1W to 65535W	40	W	Real-time	<a href="#">" H02_en.26" on page 148</a>
H02.27	2002-1Ch	Resistance of external regenerative resistor	15 Ω to 1000 Ω	50	Ω	Real-time	<a href="#">" H02_en.27" on page 148</a>
H02.30	2002-1Fh	User password	0 to 65535	0	-	Real-time	<a href="#">" H02_en.30" on page 149</a>
H02.31	2002-20h	System parameter initialization	0: No operation 1: Restore default settings 2: Clear fault records	0	-	At stop	<a href="#">" H02_en.31" on page 149</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H02.32	2002-21h	Selection of parameters in group H0b	0 to 99	50	-	Real-time	<a href="#">"H02_en.32" on page 149</a>
H02.33	2002-22h	200P software version	0.0 to 65535.0	0.0	-	Unchangeable	<a href="#">"H02_en.33" on page 149</a>
H02.35	2002-24h	Keypad data update frequency	0Hz–20Hz	0	Hz	Real-time	<a href="#">"H02_en.35" on page 150</a>
H02.41	2002-2Ah	Manufacturer password	0 to 65535	0	-	Real-time	<a href="#">"H02_en.41" on page 150</a>

## 5.4 Parameter Group H03

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H03.00	2003-01h	DI function allocation 1 (activated upon power-on)	0: Corresponding to null 1: Corresponding to FunIN.1 2: Corresponding to FunIN.2 4: Corresponding to FunIN.3 8: Corresponding to FunIN.4 16: Corresponding to FunIN.5 32: Corresponding to FunIN.6 64: Corresponding to FunIN.7 128: Corresponding to FunIN.8 256: Corresponding to FunIN.9 512: Corresponding to FunIN.10 1024: Corresponding to FunIN.11 2048: Corresponding to FunIN.12 4096: Corresponding to FunIN.13 8192: Corresponding to FunIN.14 16384: Corresponding to FunIN.15 32768: Corresponding to FunIN.16	0	-	Real-time	<i>"H03_en.00" on page 150</i>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H03.01	2003-02h	DI function allocation 2 (activated upon power-on)	0: Corresponding to null 1: Corresponding to FunIN.17 2: Corresponding to FunIN.18 4: Corresponding to FunIN.19 8: Corresponding to FunIN.20 16: Corresponding to FunIN.21 32: Corresponding to FunIN.22 64: Corresponding to FunIN.23 128: Corresponding to FunIN.24 256: Corresponding to FunIN.25 512: Corresponding to FunIN.26 1024: Corresponding to FunIN.27 2048: Corresponding to FunIN.28 4096: Corresponding to FunIN.29 16384: Corresponding to FunIN.31 32768: Corresponding to FunIN.32	0	-	Real-time	<a href="#">"H03_en.01" on page 151</a>
H03.02	2003-03h	DI1 function selection	0: Undefined 1: S-ON 3: Gain switchover 14: Forward overtravel switch 15: Reverse overtravel switch 16: Positive external torque limit 17: Negative external torque limit 18: Forward jog 19: Reverse jog 31: Home switch 32: Homing enabled 34: Emergency stop 36: Internal speed limit source 38: Probe 1 39: Probe 2 41: Current position as home 56: EPOS program block external toggle switch	14	-	Real-time	<a href="#">"H03_en.02" on page 152</a>
H03.03	2003-04h	DI1 logic selection	0: Active low 1: Active high	0	-	Real-time	<a href="#">"H03_en.03" on page 153</a>
H03.04	2003-05h	DI2 function selection	Same as H03.02.	15	-	Real-time	<a href="#">"H03_en.04" on page 153</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H03.05	2003-06h	DI2 logic selection	0: Active low 1: Active high	0	-	Real-time	<a href="#">"H03_en.05" on page 154</a>
H03.06	2003-07h	DI3 function selection	Same as H03.02.	31	-	Real-time	<a href="#">"H03_en.06" on page 154</a>
H03.07	2003-08h	DI3 logic selection	0: Active low 1: Active high	0	-	Real-time	<a href="#">"H03_en.07" on page 154</a>
H03.08	2003-09h	DI4 function selection	Same as H03.02.	34	-	Real-time	<a href="#">"H03_en.08" on page 155</a>
H03.09	2003-0Ah	DI4 logic selection	0: Active low 1: Active high	0	-	Real-time	<a href="#">"H03_en.09" on page 155</a>
H03.10	2003-0Bh	DI5 function selection	Same as H03.02.	38	-	Real-time	<a href="#">"H03_en.10" on page 155</a>
H03.11	2003-0Ch	DI5 logic selection	0: Active low 1: Active high	0	-	Real-time	<a href="#">"H03_en.11" on page 155</a>
H03.34	2003-23h	DI function allocation 3 (activated upon power-on)	0: Corresponding to null 1: Corresponding to FunIN.33 2: Corresponding to FunIN.34 4: Corresponding to FunIN.35 8: Corresponding to FunIN.36 16: Corresponding to FunIN.37 32: Corresponding to FunIN.38 64: Corresponding to FunIN.39 128: Corresponding to FunIN.40 256: Corresponding to FunIN.41 512: Corresponding to FunIN.42 1024: Corresponding to FunIN.43 2048: Corresponding to FunIN.44 4096: Corresponding to FunIN.45 8192: Corresponding to FunIN.46 16384: Corresponding to FunIN.47 32768: Corresponding to FunIN.48	0	-	Real-time	<a href="#">"H03_en.34" on page 157</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H03.35	2003-24h	DI function allocation 4 (activated upon power-on)	0: Corresponding to null 1: Corresponding to FunIN.49 2: Corresponding to FunIN.50 4: Corresponding to FunIN.51 8: Corresponding to FunIN.52 16: Corresponding to FunIN.53 32: Corresponding to FunIN.54 64: Corresponding to FunIN.55 128: Corresponding to FunIN.56 256: Corresponding to FunIN.57 512: Corresponding to FunIN.58 1024: Corresponding to FunIN.59 2048: Corresponding to FunIN.60 4096: Corresponding to FunIN.61 8192: Corresponding to FunIN.62 16384: Corresponding to FunIN.63	0	-	Real-time	<a href="#">"H03_en.35" on page 158</a>
H03.60	2003-3Dh	DI1 filter time	0.00 ms to 500.00 ms	3.00	ms	Real-time	<a href="#">"H03_en.60" on page 160</a>
H03.61	2003-3Eh	DI2 filter time	0.00 ms to 500.00 ms	3.00	ms	Real-time	<a href="#">"H03_en.61" on page 161</a>
H03.62	2003-3Fh	DI3 filter time	0.00 ms to 500.00 ms	3.00	ms	Real-time	<a href="#">"H03_en.62" on page 161</a>
H03.63	2003-40h	DI4 filter time	0.00 ms to 500.00 ms	3.00	ms	Real-time	<a href="#">"H03_en.63" on page 161</a>
H03.64	2003-41h	DI5 filter time	0.00 ms to 500.00 ms	3.00	ms	Real-time	<a href="#">"H03_en.64" on page 161</a>

## 5.5 Parameter Group H04

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H04.00	2004-01h	DO1 function selection	0: No function 1: Servo ready 2: Motor rotation signal 3: Zero speed signal 4: Speed matching signal 5: Positioning completed 6: Positioning near 7: Torque limited signal 8: Speed limited signal 9: Braking 10: Warning 11: Fault 16: Homing completed 18: Torque reached signal 19: Speed reached signal 21: Enable completed 25: Comparison output 30: Warning or fault output 32: EDM output	1	-	Real-time	<a href="#">"H04_en.00" on page 163</a>
H04.01	2004-02h	DO1 logic selection	0: Normally open 1: Closed	0	-	Real-time	<a href="#">"H04_en.01" on page 164</a>
H04.02	2004-03h	DO2 function selection	See H04.00.	11	-	Real-time	<a href="#">"H04_en.02" on page 165</a>
H04.03	2004-04h	DO2 logic selection	0: Normally open 1: Closed	0	-	Real-time	<a href="#">"H04_en.03" on page 165</a>
H04.04	2004-05h	DO3 function selection	See H04.00.	9	-	Real-time	<a href="#">"H04_en.04" on page 165</a>
H04.05	2004-06h	DO3 logic selection	0: Normally open 1: Closed	0	-	Real-time	<a href="#">"H04_en.05" on page 165</a>
H04.22	2004-17h	DO source selection	bit0: DO1 0: DO1 function output 1: H04.bit0 bit1: DO2 0: DO2 function output 1: H04.bit1 bit2: DO3 0: DO3 function output 1: H04.bit2	0	-	Real-time	<a href="#">"H04_en.22" on page 167</a>

## 5.6 Parameter Group H05

Param	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H05.02	2005-03h	Pulses per revolution	0 PPR to 4294967295 PPR	0	PPR	At stop	<a href="#">"H05_en.02" on page 170</a>
H05.04	2005-05h	First-order low-pass filter time constant	0.0 ms to 6553.5 ms	0.0	ms	At stop	<a href="#">"H05_en.04" on page 170</a>
H05.06	2005-07h	Moving average filter time constant 1	0.0 ms to 128.0 ms	0.0	ms	At stop	<a href="#">"H05_en.06" on page 171</a>
H05.07	2005-08h	Electronic gear ratio 1 (numerator)	1 to 1073741824	8388608	-	Real-time	<a href="#">"H05_en.07" on page 171</a>
H05.09	2005-0Ah	Electronic gear ratio 1 (denominator)	1 to 1073741824	10000	-	Real-time	<a href="#">"H05_en.09" on page 171</a>
H05.11	2005-0Ch	Electronic gear ratio 2 (numerator)	1 to 1073741824	8388608	-	Real-time	<a href="#">"H05_en.11" on page 172</a>
H05.13	2005-0Eh	Electronic gear ratio 2 (denominator)	1 to 1073741824	10000	-	Real-time	<a href="#">"H05_en.13" on page 172</a>
H05.16	2005-11h	Clear action	0: Position deviation cleared upon S-OFF or non-operational state 1: Position deviation cleared upon S-OFF or fault 2: Position deviation cleared upon S-OFF or active DI function 35	0	-	At stop	<a href="#">"H05_en.16" on page 172</a>
H05.19	2005-14h	Speed feedforward control	0: No speed feedforward 1: Internal speed feedforward 2: PLC speed feedforward	1	-	At stop	<a href="#">"H05_en.19" on page 173</a>

Param	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H05.20	2005-15h	Condition for positioning completed signal output	0: Abs. position deviation below H05.21 1: Abs. position deviation below H05.21; filtered position ref. is 0 2: Abs. position deviation below H05.21; unfiltered position ref. is 0 3: Abs. position deviation kept below H05.21 within the time set by H05.60; unfiltered position ref. is 0 4: Abs. position deviation below threshold, window time being active and filtered position ref. being 0 5: Abs. position deviation below threshold, with zero speed signal being active and filtered position ref. being 0 6: Abs. position deviation below threshold, with zero speed signal being active and filtered position ref. being 0 7: COIN signal judged after the change (avail.→unavail.) of position ref. kept active for the defined window time, with filtered position ref. being 0 and position deviation below threshold 8: COIN signal judged after the change (avail.→unavail.) of filtered position ref. kept active for the defined window time, with filtered position ref. being 0 and position deviation below threshold 9: COIN signal judged after the change (avail.→unavail.) of position ref. kept active for the defined window time, with filtered position ref. being 0 and position deviation below threshold 10: COIN signal judged after the change (avail.→unavail.) of filtered position ref. kept active for the defined window time, with filtered position ref. being 0 and position deviation below threshold	0	-	Real-time	<a href="#">"H05_en.20" on page 173</a>
H05.21	2005-16h	Threshold of positioning completed	1 to 65535	7	Encoder unit	Real-time	<a href="#">"H05_en.21" on page 174</a>

Param	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H05.22	2005-17h	Proximity threshold	1 to 65535	65535	Encoder unit	Real-time	<a href="#">"H05_en.22" on page 175</a>
H05.32	2005-21h	Speed of high-speed search for home switch signal	0 RPM to 3000 RPM	100	RPM	Real-time	<a href="#">"H05_en.32" on page 176</a>
H05.33	2005-22h	Speed of low-speed search for home switch signal	0 RPM to 1000 RPM	10	RPM	Real-time	<a href="#">"H05_en.33" on page 176</a>
H05.34	2005-23h	Acceleration/Deceleration time during homing	0 ms to 1000 ms	1000	ms	Real-time	<a href="#">"H05_en.34" on page 176</a>
H05.35	2005-24h	Home search time limit	0 ms to 65535 ms	10000	ms	Real-time	<a href="#">"H05_en.35" on page 177</a>
H05.36	2005-25h	Mechanical home offset	-2147483648 to 2147483647	0	Reference unit	Real-time	<a href="#">"H05_en.36" on page 177</a>
H05.39	2005-28h	Electronic gear ratio switchover condition	0: Switchover after position reference is kept 0 for 2.5 ms 1: Switched in real time	0	-	At stop	<a href="#">"H05_en.39" on page 178</a>
H05.40	2005-29h	Mechanical home offset and action upon overtravel	0: H05.36 as the coordinate after homing, reverse homing applied after homing triggered again on overtravel 1: H05.36 as the relative offset after homing, reverse homing applied after homing triggered again on overtravel 2: H05.36 as the coordinate after homing, reverse homing auto-applied on overtravel 3: H05.36 as the relative offset after homing, reverse homing auto-applied on overtravel	0	-	At stop	<a href="#">"H05_en.40" on page 178</a>
H05.50	2005-33h	Mechanical gear ratio in absolute position rotation mode (numerator)	1 to 65535	1	-	At stop	<a href="#">"H05_en.50" on page 180</a>

Param	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H05.51	2005-34h	Mechanical gear ratio in absolute position rotation mode (denominator)	1 to 65535	1	-	At stop	<a href="#">"H05_en.51" on page 181</a>
H05.52	2005-35h	Pulses per revolution of the load in absolute position rotation mode (low 32 bits)	0 to 2147483647	0	Encoder unit	At stop	<a href="#">"H05_en.52" on page 181</a>
H05.54	2005-37h	Pulses per revolution of the load in absolute position rotation mode (high 32 bits)	0 to 2147483647	0	Encoder unit	At stop	<a href="#">"H05_en.54" on page 181</a>
H05.56	2005-39h	Speed threshold in homing upon hit-and-stop	0 rpm to 1000 rpm	2	RPM	Real-time	<a href="#">"H05_en.56" on page 181</a>
H05.58	2005-3Bh	Torque threshold in homing upon hit-and-stop	0.0%–300.0%	100.0	%	Real-time	<a href="#">"H05_en.58" on page 182</a>
H05.59	2005-3Ch	Positioning window time	0 ms to 30000 ms	0	ms	Real-time	<a href="#">"H05_en.59" on page 182</a>
H05.60	2005-3Dh	Hold time of positioning completed	0 ms to 30000 ms	0	ms	Real-time	<a href="#">"H05_en.60" on page 182</a>
H05.66	2005-43h	Homing time unit	0: 1 ms 1: 10 ms 2: 100 ms	2	-	At stop	<a href="#">"H05_en.66" on page 183</a>
H05.67	2005-44h	Offset between zero point and single-turn absolute position	-2147483648 to 2147483647	0	1 encoder unit	At stop	<a href="#">"H05_en.67" on page 183</a>
H05.69	2005-46h	Auxiliary homing function	0: Inhibited 1: Record offset position 2: Clear offset position	0	-	At stop	<a href="#">"H05_en.69" on page 183</a>

Param	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H05.70	2005-47h	Moving average filter time constant 2	0.0 ms to 1000.0 ms	0.0	ms	At stop	<a href="#">"H05_en.70" on page 183</a>
H05.71	2005-48h	Motor Z signal width	0 ms to 100 ms	4	ms	Real-time	<a href="#">"H05_en.71" on page 184</a>
H05.80	2005-51h	Reference operation mode in rotation mode	0 to 4	0	-	At stop	<a href="#">"H05_en.80" on page 184</a>

## 5.7 Parameter Group H06

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H06.00	2006-01h	Source of main speed reference A	0: Digital setting (H06.03)	0	-	At stop	<a href="#">"H06_en.00" on page 185</a>
H06.01	2006-02h	Source of auxiliary speed reference B	0: Digital setting (H06.03) 5: Multi-speed reference	0	-	At stop	<a href="#">"H06_en.01" on page 185</a>
H06.02	2006-03h	Speed reference source	0: Source of main speed reference A 1: Source of auxiliary speed reference B 2: A+B 3: Switched between A and B 4: Communication	0	-	At stop	<a href="#">"H06_en.02" on page 185</a>
H06.03	2006-04h	Speed reference set through keypad	-10000 RPM to +10000 RPM	200	RPM	Real-time	<a href="#">"H06_en.03" on page 186</a>
H06.04	2006-05h	DI speed reference	0 rpm to 10000 rpm	150	RPM	Real-time	<a href="#">"H06_en.04" on page 186</a>
H06.05	2006-06h	Acceleration ramp time of speed reference	0 ms to 65535 ms	0	ms	Real-time	<a href="#">"H06_en.05" on page 186</a>
H06.06	2006-07h	Deceleration ramp time of speed reference	0 ms to 65535 ms	0	ms	Real-time	<a href="#">"H06_en.06" on page 186</a>
H06.07	2006-08h	Max. speed limit	0 rpm to 10000 rpm	7000	RPM	Real-time	<a href="#">"H06_en.07" on page 187</a>



## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H06.08	2006-09h	Forward speed limit	0 rpm to 10000 rpm	7000	RPM	Real-time	<a href="#">"H06_en.08" on page 187</a>
H06.09	2006-0Ah	Reverse speed limit	0 rpm to 10000 rpm	7000	RPM	Real-time	<a href="#">"H06_en.09" on page 187</a>
H06.10	2006-0Bh	Deceleration unit in emergency stop	0: Multiplied by 1 1: Multiplied by 10 2: Multiplied by 100	0	-	At stop	<a href="#">"H06_en.10" on page 187</a>
H06.11	2006-0Ch	Torque feedforward control	0: No torque feedforward 1: Internal torque feedforward	1	-	Real-time	<a href="#">"H06_en.11" on page 188</a>
H06.12	2006-0Dh	Acceleration ramp time of jog speed	0 ms to 65535 ms	10	ms	Real-time	<a href="#">"H06_en.12" on page 188</a>
H06.13	2006-0Eh	Speed feedforward smoothing filter	0 us to 65535 us	0	us	Real-time	<a href="#">"H06_en.13" on page 189</a>
H06.15	2006-10h	Zero clamp speed threshold	0 rpm to 10000 rpm	10	RPM	Real-time	<a href="#">"H06_en.15" on page 189</a>
H06.16	2006-11h	Threshold of TGON (motor rotation) signal	0 rpm to 1000 rpm	20	RPM	Real-time	<a href="#">"H06_en.16" on page 189</a>
H06.17	2006-12h	Threshold of V-Cmp (speed matching) signal	0 rpm to 100 rpm	10	RPM	Real-time	<a href="#">"H06_en.17" on page 189</a>
H06.18	2006-13h	Threshold of speed reach signal	20 rpm to 10000 rpm	1000	RPM	Real-time	<a href="#">"H06_en.18" on page 190</a>
H06.19	2006-14h	Threshold of zero speed output signal	1 rpm to 10000 rpm	10	RPM	Real-time	<a href="#">"H06_en.19" on page 190</a>
H06.36	2006-25h	Moving average filter time constant of speed references	0 ms to 32 ms	0	ms	At stop	<a href="#">"H06_en.36" on page 190</a>
H06.40	2006-29h	Deceleration time of ramp 1/ PN ramp stop	0 ms to 65535 ms	0	ms	At stop	<a href="#">"H06_en.40" on page 190</a>
H06.41	2006-2Ah	Dec. time of ramp 2/PN quick stop	0 ms to 65535 ms	0	ms	At stop	<a href="#">"H06_en.41" on page 191</a>
H06.50	2006-33h	Speed S-curve enable switch	0 to 1	0	-	At stop	<a href="#">"H06_en.50" on page 191</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H06.51	2006-34h	Increasing acceleration of speed S-curve acceleration segment	0.0%–100.0%	50.0	%	At stop	<a href="#">" H06_en.51" on page 191</a>
H06.52	2006-35h	Decreasing acceleration of speed S-curve acceleration segment	0.0%–100.0%	50.0	%	At stop	<a href="#">" H06_en.52" on page 191</a>
H06.53	2006-36h	Increasing acceleration of speed S-curve deceleration segment	0.0%–100.0%	50.0	%	At stop	<a href="#">" H06_en.53" on page 192</a>
H06.54	2006-37h	Decreasing acceleration of speed S-curve deceleration segment	0.0%–100.0%	50.0	%	At stop	<a href="#">" H06_en.54" on page 192</a>

## 5.8 Parameter Group H07

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H07.00	2007-01h	Source of main torque reference A	0: Keypad (H7.03)	0	-	At stop	<a href="#">" H07_en.00" on page 192</a>
H07.01	2007-02h	Source of auxiliary torque reference B	0: Keypad (H7.03)	0	-	At stop	<a href="#">" H07_en.01" on page 193</a>
H07.02	2007-03h	Torque reference source	0: Source of main torque reference A 1: Source of auxiliary torque reference B 2: Source of A+B 3: Switched between A and B 4: Communication	0	-	At stop	<a href="#">" H07_en.02" on page 193</a>
H07.03	2007-04h	Torque reference set through keypad	-400.0%–400.0%	0.0	%	Real-time	<a href="#">" H07_en.03" on page 193</a>
H07.05	2007-06h	Torque reference filter time constant 1	0.00 ms to 30.00 ms	0.50	ms	Real-time	<a href="#">" H07_en.05" on page 194</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H07.06	2007-07h	Torque reference filter time constant 2	0.00 ms to 30.00 ms	0.27	ms	Real-time	<a href="#">" H07_en.06" on page 194</a>
H07.07	2007-08h	Torque Limit source	0: Positive/Negative internal torque limit 5: PN torque limit	0	-	Real-time	<a href="#">" H07_en.07" on page 194</a>
H07.09	2007-0Ah	Positive internal torque limit	0.0%–400.0%	350.0	%	Real-time	<a href="#">" H07_en.09" on page 194</a>
H07.10	2007-0Bh	Negative internal torque limit	0.0%–400.0%	350.0	%	Real-time	<a href="#">" H07_en.10" on page 195</a>
H07.11	2007-0Ch	Positive external torque limit	0.0%–400.0%	350.0	%	Real-time	<a href="#">" H07_en.11" on page 195</a>
H07.12	2007-0Dh	Negative external torque limit	0.0%–400.0%	350.0	%	Real-time	<a href="#">" H07_en.12" on page 195</a>
H07.15	2007-10h	Emergency-stop torque	0.0%–400.0%	100.0	%	Real-time	<a href="#">" H07_en.15" on page 196</a>
H07.17	2007-12h	Speed limit source	0: Internal speed limit 2: H07.19 or H07.20 as defined by DI	0	-	Real-time	<a href="#">" H07_en.17" on page 196</a>
H07.19	2007-14h	Positive speed limit/Speed limit 1 in torque control	0 rpm to 10000 rpm	3000	RPM	Real-time	<a href="#">" H07_en.19" on page 196</a>
H07.20	2007-15h	Negative speed limit/Speed limit 2 in torque control	0 rpm to 10000 rpm	3000	RPM	Real-time	<a href="#">" H07_en.20" on page 196</a>
H07.21	2007-16h	Torque reach base value	0.0%–300.0%	0.0	%	Real-time	<a href="#">" H07_en.21" on page 197</a>
H07.22	2007-17h	Torque reach valid value	0.0%–400.0%	20.0	%	Real-time	<a href="#">" H07_en.22" on page 197</a>
H07.23	2007-18h	Torque reach invalid value	0.0%–400.0%	10.0	%	Real-time	<a href="#">" H07_en.23" on page 197</a>
H07.24	2007-19h	Field weakening depth	60%–115%	115	%	Real-time	<a href="#">" H07_en.24" on page 197</a>
H07.25	2007-1Ah	Max. permissible demagnetizing current	0%–200%	100	%	Real-time	<a href="#">" H07_en.25" on page 198</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H07.26	2007-1Bh	Field weakening selection	0: Disabled 1: Enabled	0	-	At stop	<a href="#">"H07_en.26" on page 198</a>
H07.27	2007-1Ch	Flux weakening gain	0.001Hz–1.000Hz	0.030	Hz	Real-time	<a href="#">"H07_en.27" on page 198</a>
H07.28	2007-1Dh	Speed of flux weakening point	0 to 65535	0	-	Unchangeable	<a href="#">"H07_en.28" on page 199</a>
H07.36	2007-25h	Time constant of low-pass filter 2	0.00 ms to 10.00 ms	0.00	ms	Real-time	<a href="#">"H07_en.36" on page 199</a>
H07.37	2007-26h	Torque reference filter selection	0: First-order filter 1: Biquad filter	0	-	Real-time	<a href="#">"H07_en.37" on page 199</a>
H07.38	2007-27h	Biquad filter attenuation ratio	0 to 50	16	-	At stop	<a href="#">"H07_en.38" on page 199</a>
H07.40	2007-29h	Speed limit threshold in torque control mode	0.0 ms to 30.0 ms	1.0	ms	Real-time	<a href="#">"H07_en.40" on page 200</a>

## 5.9 Parameter Group H08

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.00	2008-01h	Speed loop gain	0.1Hz to 2000.0Hz	40.0	Hz	Real-time	<a href="#">"H08_en.00" on page 200</a>
H08.01	2008-02h	Speed loop integral time constant	0.15 ms to 512.00 ms	19.89	ms	Real-time	<a href="#">"H08_en.01" on page 200</a>
H08.02	2008-03h	Position loop gain	0.1Hz to 2000.0Hz	64.0	Hz	Real-time	<a href="#">"H08_en.02" on page 201</a>
H08.03	2008-04h	2nd speed loop gain	0.1Hz to 2000.0Hz	75.0	Hz	Real-time	<a href="#">"H08_en.03" on page 201</a>
H08.04	2008-05h	2nd speed loop integral time constant	0.15 ms to 512.00 ms	10.61	ms	Real-time	<a href="#">"H08_en.04" on page 201</a>
H08.05	2008-06h	2nd position loop gain	0.1Hz to 2000.0Hz	120.0	Hz	Real-time	<a href="#">"H08_en.05" on page 202</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.08	2008-09h	2nd gain mode setting	0: Fixed to the 1st group of gains, P/PI switched through external DI1: Switched between the 1st and 2nd group of gains as defined by H08.09	1	-	Real-time	<a href="#">"H08_en.08" on page 202</a>
H08.09	2008-0Ah	Gain switchover condition	0: Fixed to the 1st gain set (PS) 1: Switched as defined by Func3 of DI 2: Torque reference too large (PS) 3: Speed reference too large (PS) 4: Speed reference change rate too large (PS) 5: Speed reference low/high speed threshold (PS) 6: Position deviation too large (P) 7: Position reference available (P) 8: Positioning unfinished (P) 9: Actual speed (P) 10: Position reference + Actual speed (P)	0	-	Real-time	<a href="#">"H08_en.09" on page 202</a>
H08.10	2008-0Bh	Gain switchover delay	0.0 ms to 1000.0 ms	5.0	ms	Real-time	<a href="#">"H08_en.10" on page 204</a>
H08.11	2008-0Ch	Gain switchover level	0 to 20000	50	-	Real-time	<a href="#">"H08_en.11" on page 205</a>
H08.12	2008-0Dh	Gain switchover hysteresis	0 to 20000	30	-	Real-time	<a href="#">"H08_en.12" on page 205</a>
H08.13	2008-0Eh	Position gain switchover time	0.0 ms to 1000.0 ms	3.0	ms	Real-time	<a href="#">"H08_en.13" on page 205</a>
H08.15	2008-10h	Load moment of inertia ratio	0.00 to 120.00	1.00	-	Real-time	<a href="#">"H08_en.15" on page 206</a>
H08.17	2008-12h	Zero phase delay	0.0 ms to 4.0 ms	0.0	ms	Real-time	<a href="#">"H08_en.17" on page 206</a>
H08.18	2008-13h	Time constant of speed feedforward filter	0.00 ms to 64.00 ms	0.50	ms	Real-time	<a href="#">"H08_en.18" on page 206</a>
H08.19	2008-14h	Speed feedforward gain	0.0%–100.0%	0.0	%	Real-time	<a href="#">"H08_en.19" on page 207</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.20	2008-15h	Torque feedforward filter time constant	0.00 ms to 64.00 ms	0.50	ms	Real-time	<a href="#">"H08_en.20" on page 207</a>
H08.21	2008-16h	Torque feedforward gain	0.0%–300.0%	0.0	%	Real-time	<a href="#">"H08_en.21" on page 207</a>
H08.22	2008-17h	Speed feedback filtering option	0: Inhibited 1: 2 times 2: 4 times 3: 8 times 4: 16 times	0	-	At stop	<a href="#">"H08_en.22" on page 207</a>
H08.23	2008-18h	Cutoff frequency of speed feedback low-pass filter	100Hz to 8000Hz	8000	Hz	Real-time	<a href="#">"H08_en.23" on page 208</a>
H08.24	2008-19h	PDFF control coefficient	0.0%–200.0%	100.0	%	Real-time	<a href="#">"H08_en.24" on page 208</a>
H08.27	2008-1Ch	Speed observer cutoff frequency	50Hz to 600Hz	170	Hz	Real-time	<a href="#">"H08_en.27" on page 208</a>
H08.28	2008-1Dh	Speed observer inertia correction coefficient	1%–1600%	100	%	Real-time	<a href="#">"H08_en.28" on page 209</a>
H08.29	2008-1Eh	Speed observer filter time	0.00 ms to 10.00 ms	0.80	ms	Real-time	<a href="#">"H08_en.29" on page 209</a>
H08.31	2008-20h	Disturbance cutoff frequency	10Hz to 4000Hz	600	Hz	Real-time	<a href="#">"H08_en.31" on page 209</a>
H08.32	2008-21h	Disturbance compensation gain	0%–100%	0	%	Real-time	<a href="#">"H08_en.32" on page 210</a>
H08.33	2008-22h	Disturbance observer inertia correction coefficient	0%–1600%	100	%	Real-time	<a href="#">"H08_en.33" on page 210</a>
H08.37	2008-26h	Phase modulation for medium-frequency jitter suppression 2	-90° to 90°	0	°	Real-time	<a href="#">"H08_en.37" on page 210</a>
H08.38	2008-27h	Medium-frequency suppression 2 frequency	0Hz to 1000Hz	0	Hz	Real-time	<a href="#">"H08_en.38" on page 210</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.39	2008-28h	Compensation gain of medium-frequency jitter suppression 2	0%–300%	0	%	Real-time	<a href="#">"H08_en.39" on page 211</a>
H08.40	2008-29h	Speed observer selection	0: Disabled 1: Enabled	0	-	Real-time	<a href="#">"H08_en.40" on page 211</a>
H08.42	2008-2Bh	Model control selection	0: Disable 1: Enable 2: Dual-inertia model	0	-	Real-time	<a href="#">"H08_en.42" on page 211</a>
H08.43	2008-2Ch	Model gain	0.1 to 2000.0	40.0	-	Real-time	<a href="#">"H08_en.43" on page 211</a>
H08.46	2008-2Fh	Feedforward value	0.0 to 102.4	95.0	-	Real-time	<a href="#">"H08_en.46" on page 212</a>
H08.53	2008-36h	Medium- and low-frequency jitter suppression frequency 3	0.0Hz to 300.0Hz	0.0	Hz	Real-time	<a href="#">"H08_en.53" on page 212</a>
H08.54	2008-37h	Medium- and low-frequency jitter suppression compensation 3	0%–200%	0	%	Real-time	<a href="#">"H08_en.54" on page 212</a>
H08.56	2008-39h	Medium- and low-frequency jitter suppression phase modulation 3	0%–600%	100	%	Real-time	<a href="#">"H08_en.56" on page 213</a>
H08.59	2008-3Ch	Medium- and low-frequency jitter suppression frequency 4	0.0Hz to 300.0Hz	0.0	Hz	Real-time	<a href="#">"H08_en.59" on page 213</a>
H08.60	2008-3Dh	Medium- and low-frequency jitter suppression compensation 4	0%–200%	0	%	Real-time	<a href="#">"H08_en.60" on page 213</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.61	2008-3Eh	Medium- and low-frequency jitter suppression phase modulation 4	0%–600%	100	%	Real-time	<a href="#">"H08_en.61" on page 213</a>
H08.62	2008-3Fh	Position loop integral time constant	0.15 to 512.00	512.00	-	Real-time	<a href="#">"H08_en.62" on page 214</a>
H08.63	2008-40h	2nd position loop integral time constant	0.15 to 512.00	512.00	-	Real-time	<a href="#">"H08_en.63" on page 214</a>
H08.64	2008-41h	Speed observer feedback source	0: Disabled 1: Enabled	0	-	Real-time	<a href="#">"H08_en.64" on page 214</a>
H08.65	2008-42h	Zero deviation control selection	0: Disabled 1: Enabled	0	-	Real-time	<a href="#">"H08_en.65" on page 214</a>
H08.66	2008-43h	Zero deviation control position average filter	0.0 ms to 320.0 ms	5.0	ms	Real-time	<a href="#">"H08_en.66" on page 215</a>
H08.68	2008-45h	Speed feedforward of zero deviation control	0.0%–100.0%	0.0	%	Real-time	<a href="#">"H08_en.68" on page 215</a>
H08.69	2008-46h	Torque feedforward of zero deviation control	0.0%–100.0%	0.0	%	Real-time	<a href="#">"H08_en.69" on page 215</a>
H08.81	2008-52h	Anti-resonance frequency of dual-inertia model	0.0Hz to 300.0Hz	0.0	Hz	Real-time	<a href="#">"H08_en.81" on page 216</a>
H08.82	2008-53h	Resonance frequency of dual-inertia model	0.0Hz to 300.0Hz	0.0	Hz	Real-time	<a href="#">"H08_en.82" on page 216</a>
H08.83	2008-54h	Dual-inertia model gain	0.1Hz to 2000.0Hz	40.0	Hz	Real-time	<a href="#">"H08_en.83" on page 216</a>
H08.84	2008-55h	Inertia ratio of dual-inertia model	0.00 to 120.00	1.00	-	Real-time	<a href="#">"H08_en.84" on page 216</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H08.88	2008-59h	Speed feedforward value of dual-inertia model	0.0 to 100.0	100.0	-	Real-time	<a href="#">"H08_en.88" on page 217</a>
H08.89	2008-5Ah	Torque feedforward value of dual-inertia model	0.0 to 100.0	100.0	-	Real-time	<a href="#">"H08_en.89" on page 217</a>

## 5.10 Parameter Group H09

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H09.00	2009-01h	Auto-adjustment mode	0: Disabled, manual gain tuning required 1: Enabled, gain parameters generated automatically based on the stiffness level 2: Positioning mode, gain parameters generated automatically based on the stiffness level 4: Normal mode+Inertia auto-tuning 6: Quick positioning mode+Inertia auto-tuning	0	-	Real-time	<a href="#">"H09_en.00" on page 217</a>
H09.01	2009-02h	Stiffness level selection	0 to 41	15	-	Real-time	<a href="#">"H09_en.01" on page 218</a>
H09.02	2009-03h	Adaptive notch mode	0: Adaptive notch no longer updated; 1: One adaptive notch activated (3rd notch) 2: Two adaptive notches activated (3rd and 4th notches) 3: Resonance point tested only (displayed in H09.24) 4: Adaptive notch cleared, values of 3rd and 4th notches restored to default	3	-	Real-time	<a href="#">"H09_en.02" on page 218</a>
H09.03	2009-04h	Online inertia auto-tuning mode	0: Disabled 1: Enabled, changing slowly 2: Enabled, changing normally 3: Enabled, changing quickly	2	-	Real-time	<a href="#">"H09_en.03" on page 218</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H09.05	2009-06h	Offline inertia auto-tuning mode	0: Bi-directional 1: Unidirectional	1	-	At stop	<a href="#">"H09_en.05" on page 219</a>
H09.06	2009-07h	Max. speed of inertia auto-tuning	100 rpm to 1000 rpm	500	RPM	At stop	<a href="#">"H09_en.06" on page 219</a>
H09.07	2009-08h	Time constant for accelerating to max. speed during inertia auto-tuning	20 ms to 800 ms	125	ms	At stop	<a href="#">"H09_en.07" on page 219</a>
H09.08	2009-09h	Interval time after an individual inertia auto-tuning	50 ms to 10000 ms	800	ms	At stop	<a href="#">"H09_en.08" on page 220</a>
H09.09	2009-0Ah	Number of motor revolutions per inertia auto-tuning	0.00 to 100.00	1.00	-	Real-time	<a href="#">"H09_en.09" on page 220</a>
H09.11	2009-0Ch	Vibration threshold	0.0%–100.0%	5.0	%	Real-time	<a href="#">"H09_en.11" on page 220</a>
H09.12	2009-0Dh	Frequency of the 1st notch	50Hz to 8000Hz	8000	Hz	Real-time	<a href="#">"H09_en.12" on page 221</a>
H09.13	2009-0Eh	Width level of the 1st notch	0 to 20	2	-	Real-time	<a href="#">"H09_en.13" on page 221</a>
H09.14	2009-0Fh	Depth level of the 1st notch	0 to 99	0	-	Real-time	<a href="#">"H09_en.14" on page 221</a>
H09.15	2009-10h	Frequency of the 2nd notch	50Hz to 8000Hz	8000	Hz	Real-time	<a href="#">"H09_en.15" on page 222</a>
H09.16	2009-11h	Width level of the 2nd notch	0 to 20	2	-	Real-time	<a href="#">"H09_en.16" on page 222</a>
H09.17	2009-12h	Depth level of the 2nd notch	0 to 99	0	-	Real-time	<a href="#">"H09_en.17" on page 222</a>
H09.18	2009-13h	Frequency of the 3rd notch	50Hz to 8000Hz	8000	Hz	Real-time	<a href="#">"H09_en.18" on page 223</a>
H09.19	2009-14h	Width level of the 3rd notch	0 to 20	2	-	Real-time	<a href="#">"H09_en.19" on page 223</a>
H09.20	2009-15h	Depth level of the 3rd notch	0 to 99	0	-	Real-time	<a href="#">"H09_en.20" on page 223</a>
H09.21	2009-16h	Frequency of the 4th notch	50Hz to 8000Hz	8000	Hz	Real-time	<a href="#">"H09_en.21" on page 223</a>
H09.22	2009-17h	Width level of the 4th notch	0 to 20	2	-	Real-time	<a href="#">"H09_en.22" on page 224</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H09.23	2009-18h	Depth level of the 4th notch	0 to 99	0	-	Real-time	<a href="#">"H09_en.23" on page 224</a>
H09.24	2009-19h	Auto-tuned resonance frequency	0Hz to 5000Hz	0	Hz	Unchangeable	<a href="#">"H09_en.24" on page 224</a>
H09.26	2009-1Bh	ITune response	50.0%–500.0%	100.0	%	Real-time	<a href="#">"H09_en.26" on page 225</a>
H09.27	2009-1Ch	ITune mode	0: Disabled 1: ITune mode 1 2: ITune mode 2	0	-	Real-time	<a href="#">"H09_en.27" on page 225</a>
H09.28	2009-1Dh	Minimum inertia ratio of ITune	0.0%–80.0%	0.0	%	Real-time	<a href="#">"H09_en.28" on page 225</a>
H09.29	2009-1Eh	Maximum inertia ratio of ITune	1.0%–120.0%	30.0	%	Real-time	<a href="#">"H09_en.29" on page 225</a>
H09.32	2009-21h	Gravity compensation value	0.0%–100.0%	0.0	%	Real-time	<a href="#">"H09_en.32" on page 226</a>
H09.33	2009-22h	Positive friction compensation value	0.0%–100.0%	0.0	%	Real-time	<a href="#">"H09_en.33" on page 226</a>
H09.34	2009-23h	Negative friction compensation value	-100.0%–0.0%	0.0	%	Real-time	<a href="#">"H09_en.34" on page 226</a>
H09.35	2009-24h	Friction compensation speed	0.0 to 20.0	2.0	-	Real-time	<a href="#">"H09_en.35" on page 226</a>
H09.36	2009-25h	Friction compensation speed	0: 0x00 Slow mode+Speed reference 0: 0x01 Slow mode+Model speed 0: 0x02 Slow mode+Speed feedback 0: 0x03 Slow mode+Observe speed 0: 0x10 Quick mode +Speed reference 0: 0x11 Quick mode +Model speed 0: 0x12 Quick mode +Speed feedback 0: 0x13 Quick mode+Observe speed	0	-	Real-time	<a href="#">"H09_en.36" on page 227</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H09.37	2009-26h	Vibration monitoring time	0 to 65535	600	-	Real-time	<a href="#">" H09_en.37" on page 227</a>
H09.38	2009-27h	Frequency of low-frequency resonance suppression 1 at the mechanical end	1.0Hz to 100.0Hz	100.0	Hz	Real-time	<a href="#">" H09_en.38" on page 227</a>
H09.39	2009-28h	Low-frequency resonance suppression 1 at the mechanical end	0 to 3	2	-	At stop	<a href="#">" H09_en.39" on page 228</a>
H09.44	2009-2Dh	Frequency of low-frequency resonance suppression 2 at mechanical load end	0.0 to 100.0	0.0	-	Real-time	<a href="#">" H09_en.44" on page 228</a>
H09.45	2009-2Eh	Responsiveness of low-frequency resonance suppression 2 at mechanical load end	0.01 to 5.00	1.00	-	Real-time	<a href="#">" H09_en.45" on page 228</a>
H09.47	2009-30h	Width of low-frequency resonance suppression 2 at mechanical load end	0.00 to 2.00	1.00	-	Real-time	<a href="#">" H09_en.47" on page 229</a>
H09.49	2009-32h	Frequency of low-frequency resonance suppression 3 at mechanical load end	0.0 to 100.0	0.0	-	Real-time	<a href="#">" H09_en.49" on page 229</a>
H09.50	2009-33h	Responsiveness of low-frequency resonance suppression 3 at mechanical load end	0.01 to 5.00	1.00	-	Real-time	<a href="#">" H09_en.50" on page 229</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H09.52	2009-35h	Width of low-frequency resonance suppression 3 at mechanical load end	0.00 to 2.00	1.00	-	Real-time	<a href="#">"H09_en.52" on page 229</a>
H09.54	2009-37h	Vibration threshold	0.0%–300.0%	50.0	%	Real-time	<a href="#">"H09_en.54" on page 230</a>
H09.56	2009-39h	Max. overshoot allowed by ETune	0 to 65535	2936	-	Real-time	<a href="#">"H09_en.56" on page 230</a>
H09.57	2009-3Ah	STune resonance suppression switchover frequency	0Hz to 4000Hz	900	Hz	Real-time	<a href="#">"H09_en.57" on page 230</a>
H09.58	2009-3Bh	STune resonance suppression reset selection	0: Disabled 1: Enabled	0	-	Real-time	<a href="#">"H09_en.58" on page 230</a>

## 5.11 Parameter Group H0A

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0A.00	200A-01h	Power input phase loss protection	0: Enable 1: Disable	0	-	Real-time	<a href="#">"H0A_en.00" on page 231</a>
H0A.01	200A-02h	Absolute position limit	0: Disabled 1: Enabled 2: Enabled after homing	0	-	Real-time	<a href="#">"H0A_en.01" on page 231</a>
H0A.04	200A-05h	Motor overload protection gain	50 to 300	100	-	Real-time	<a href="#">"H0A_en.04" on page 232</a>
H0A.08	200A-09h	Overspeed threshold	0 rpm to 20000 rpm	0	RPM	Real-time	<a href="#">"H0A_en.08" on page 232</a>
H0A.10	200A-0Bh	Threshold of excessive local position deviation	0 to 4294967295	25185824	-	Real-time	<a href="#">"H0A_en.10" on page 233</a>
H0A.12	200A-0Dh	Runaway protection	0: Disabled 1: Enabled	1	-	Real-time	<a href="#">"H0A_en.12" on page 233</a>
H0A.17	200A-12h	Reference unit	0: Pulse unit 1: Reference unit	0	-	At stop	<a href="#">"H0A_en.17" on page 234</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0A.18	200A-13h	IGBT over-temperature threshold	120°C to 175°C	140	°C	Real-time	<a href="#">"H0A_en.18" on page 234</a>
H0A.19	200A-14h	Filter time constant of touch probe 1	0.00 us–6.30 us	2.00	us	Real-time	<a href="#">"H0A_en.19" on page 234</a>
H0A.20	200A-15h	Filter time constant of touch probe 2	0.00 us–6.30 us	2.00	us	Real-time	<a href="#">"H0A_en.20" on page 235</a>
H0A.23	200A-18h	TZ signal filter time	0 ns to 31 ns	15	25ns	At stop	<a href="#">"H0A_en.23" on page 235</a>
H0A.26	200A-1Bh	Motor overload detection	0: Show motor overload warning (E909.0) and fault (E620.0) 1: Hide motor overload warning (E909.0) and fault (E620.0)	0	-	Real-time	<a href="#">"H0A_en.26" on page 235</a>
H0A.27	200A-1Ch	Motor rotation DO speed filter time	0 ms to 100 ms	50	ms	At stop	<a href="#">"H0A_en.27" on page 236</a>
H0A.32	200A-21h	Time threshold for locked motor overheat protection	10 ms to 65535 ms	200	ms	Real-time	<a href="#">"H0A_en.32" on page 237</a>
H0A.33	200A-22h	Locked rotor over-temperature protection	0: Disabled 1: Enabled	1	-	Real-time	<a href="#">"H0A_en.33" on page 237</a>
H0A.36	200A-25h	Encoder multi-turn overflow fault selection	0: Not hide 1: Hide	0	-	Real-time	<a href="#">"H0A_en.36" on page 237</a>
H0A.39	200A-28h	Current sampling clock signal tolerance count	0 to 3	0	-	At stop	<a href="#">"H0A_en.39" on page 237</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0A.40	200A-29h	Compensation function selection	bit0: Overtravel compensation 0: Enabled 1: Disabled bit1: Touch probe rising edge compensation 0: Disabled 1: Enabled bit2: Touch probe falling edge compensation 0: Disabled 1: Enabled bit3: Touch probe edge solution 0: New solution 1: Old solution (same as SV660N)	6	-	At stop	<a href="#">"H0A_en.40" on page 238</a>
H0A.41	200A-2Ah	Forward position of software position limit	-2147483648 to 2147483647	2147483647	Encoder unit	At stop	<a href="#">"H0A_en.41" on page 238</a>
H0A.43	200A-2Ch	Reverse position of software position limit	-2147483648 to 2147483647	-2147483648	Encoder unit	At stop	<a href="#">"H0A_en.43" on page 239</a>
H0A.49	200A-32h	Regenerative resistor overtemperature threshold	100°C to 175°C	115	°C	Real-time	<a href="#">"H0A_en.49" on page 239</a>
H0A.50	200A-33h	Encoder communication fault tolerance threshold	0 to 31	3	-	Real-time	<a href="#">"H0A_en.50" on page 239</a>
H0A.51	200A-34h	Phase loss detection filter times	3 ms to 36 ms	20	55ms	Real-time	<a href="#">"H0A_en.51" on page 239</a>
H0A.52	200A-35h	Encoder temperature protection threshold	0°C to 175°C	105	°C	Real-time	<a href="#">"H0A_en.52" on page 240</a>
H0A.53	200A-36h	Probe DI ON compensation time	-3000 ns to 3000 ns	128	25ns	Real-time	<a href="#">"H0A_en.53" on page 240</a>
H0A.54	200A-37h	Probe DI OFF compensation time	-3000 ns to 3000 ns	1512	25ns	Real-time	<a href="#">"H0A_en.54" on page 240</a>
H0A.55	200A-38h	Runaway current threshold	100.0%–400.0%	200.0	%	Real-time	<a href="#">"H0A_en.55" on page 241</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0A.56	200A-39h	Fault reset delay	0 ms to 60000 ms	10000	ms	Real-time	<a href="#">"H0A_en.56" on page 241</a>
H0A.57	200A-3Ah	Runaway speed threshold	1 rpm to 1000 rpm	50	RPM	Real-time	<a href="#">"H0A_en.57" on page 241</a>
H0A.58	200A-3Bh	Runaway speed filter time	0.1 ms to 100.0 ms	2.0	ms	Real-time	<a href="#">"H0A_en.58" on page 241</a>
H0A.59	200A-3Ch	Runaway protection detection time	10 ms to 1000 ms	30	ms	Real-time	<a href="#">"H0A_en.59" on page 242</a>
H0A.60	200A-3Dh	Black box function mode	0: Disable 1: Any fault 2: Designated fault 3: Triggered based on designated condition	1	-	Real-time	<a href="#">"H0A_en.60" on page 242</a>
H0A.61	200A-3Eh	Designated fault code	0.0 to 6553.5	0.0	-	Real-time	<a href="#">"H0A_en.61" on page 242</a>
H0A.62	200A-3Fh	Trigger source	0 to 25	0	-	Real-time	<a href="#">"H0A_en.62" on page 242</a>
H0A.63	200A-40h	Trigger level	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H0A_en.63" on page 243</a>
H0A.65	200A-42h	Trigger level	0: Rising edge 1: Equal 2: Falling edge 3: Edge-triggered	0	-	Real-time	<a href="#">"H0A_en.65" on page 243</a>
H0A.66	200A-43h	Trigger position	0%–100%	75	%	Real-time	<a href="#">"H0A_en.66" on page 243</a>
H0A.67	200A-44h	Sampling frequency	0: Current loop 1: Position loop 2: Main cycle	0	-	Real-time	<a href="#">"H0A_en.67" on page 244</a>
H0A.70	200A-47h	Overspeed threshold 2	0 rpm to 20000 rpm	0	RPM	Real-time	<a href="#">"H0A_en.70" on page 244</a>
H0A.71	200A-48h	MS1 motor overload curve switchover	0 to 3	2	-	Real-time	<a href="#">"H0A_en.71" on page 244</a>
H0A.72	200A-49h	Maximum stop time in ramp-to-stop	0 ms to 65535 ms	10000	ms	At stop	<a href="#">"H0A_en.72" on page 244</a>
H0A.73	200A-4Ah	STO 24 V disconnection filter time	1 ms to 5 ms	5	ms	Real-time	<a href="#">"H0A_en.73" on page 245</a>
H0A.74	200A-4Bh	Filter time for two inconsistent STO channels	0 ms to 1000 ms	100	ms	Real-time	<a href="#">"H0A_en.74" on page 245</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0A.75	200A-4Ch	Servo OFF delay after STO triggered	0 ms to 25 ms	10	ms	Real-time	<a href="#">"H0A_en.75" on page 245</a>
H0A.90	200A-5Bh	Average filter time constant for speed display	0 ms to 100 ms	0	ms	At stop	<a href="#">"H0A_en.90" on page 246</a>
H0A.91	200A-5Ch	Average filter time constant for torque display	0 ms to 100 ms	0	ms	At stop	<a href="#">"H0A_en.91" on page 246</a>
H0A.92	200A-5Dh	Average filter time constant for position display	0 ms to 100 ms	0	ms	At stop	<a href="#">"H0A_en.92" on page 246</a>
H0A.93	200A-5Eh	Low-pass filter time constant for voltage display	0 ms to 250 ms	0	ms	Real-time	<a href="#">"H0A_en.93" on page 246</a>
H0A.94	200A-5Fh	Low-pass filter time constant for thermal display	0 ms to 250 ms	0	ms	Real-time	<a href="#">"H0A_en.94" on page 247</a>

## 5.12 Parameter Group H0b

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.00	200b-01h	Motor speed actual value	-32767 RPM to +32767 RPM	0	RPM	Unchangeable	<a href="#">"H0b_en.00" on page 247</a>
H0b.01	200b-02h	Speed reference	-32767 RPM to +32767 RPM	0	RPM	Unchangeable	<a href="#">"H0b_en.01" on page 247</a>
H0b.02	200b-03h	Internal torque reference	-500.0%–500.0%	0.0	%	Unchangeable	<a href="#">"H0b_en.02" on page 248</a>
H0b.03	200b-04h	Input (DI) signal monitoring	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.03" on page 248</a>
H0b.05	200b-06h	Output (DO) signal monitoring	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.05" on page 248</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.07	200b-08h	Absolute position counter	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.07" on page 249</a>
H0b.09	200b-0Ah	Mechanical angle	0.0° to 360.0°	0.0	°	Unchangeable	<a href="#">"H0b_en.09" on page 249</a>
H0b.10	200b-0Bh	Electrical angle	0.0° to 360.0°	0.0	°	Unchangeable	<a href="#">"H0b_en.10" on page 250</a>
H0b.12	200b-0Dh	Average load ratio	0.0%–800.0%	0.0	%	Unchangeable	<a href="#">"H0b_en.12" on page 250</a>
H0b.13	200b-0Eh	Input reference counter	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.13" on page 250</a>
H0b.15	200b-10h	Position following error (encoder unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.15" on page 251</a>
H0b.17	200b-12h	Feedback pulse counter	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.17" on page 251</a>
H0b.19	200b-14h	Total power-on time	0.0s–429496729.5s	0.0	s	Unchangeable	<a href="#">"H0b_en.19" on page 251</a>
H0b.24	200b-19h	Phase current RMS value	0.0 A to 6553.5 A	0.0	A	Unchangeable	<a href="#">"H0b_en.24" on page 251</a>
H0b.25	200b-1Ah	Angle obtained upon voltage injection auto-tuning	0.0° to 360.0°	0.0	°	Unchangeable	<a href="#">"H0b_en.25" on page 252</a>
H0b.26	200b-1Bh	Bus voltage	0.0V to 6553.5V	0.0	V	Unchangeable	<a href="#">"H0b_en.26" on page 252</a>
H0b.27	200b-1Ch	Module temperature	-20°C to 200°C	0	°C	Unchangeable	<a href="#">"H0b_en.27" on page 252</a>
H0b.28	200b-1Dh	Absolute encoder fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.28" on page 253</a>
H0b.29	200b-1Eh	Axis status information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.29" on page 253</a>
H0b.30	200b-1Fh	Axis fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.30" on page 253</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.31	200b-20h	Encoder fault information	0 to 65535	0	-	Real-time	<a href="#">"H0b_en.31" on page 253</a>
H0b.33	200b-22h	Fault log	0: Present fault 1: Last fault 2: 2nd to last fault 3: 3rd to last fault 4: 4th to last fault 5: 5th to last fault 6: 6th to last fault 7: 7th to last fault 8: 8th to last fault 9: 9th to last fault 10: 10th to last fault 11: 11th to last fault 12: 12th to last fault 13: 13th to last fault 14: 14th to last fault 15: 15th to last fault 16: 16th to last fault 17: 17th to last fault 18: 18th to last fault 19: 19th to last fault	0	-	Real-time	<a href="#">"H0b_en.33" on page 254</a>
H0b.34	200b-23h	Code of selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.34" on page 254</a>
H0b.35	200b-24h	Timestamp of selected fault	0.0s–429496729.5s	0.0	s	Unchangeable	<a href="#">"H0b_en.35" on page 255</a>
H0b.37	200b-26h	Motor speed on selected fault	-32767 RPM to +32767 RPM	0	RPM	Unchangeable	<a href="#">"H0b_en.37" on page 255</a>
H0b.38	200b-27h	Motor phase U current upon occurrence of the selected fault	-3276.7A to 3276.7A	0.0	A	Unchangeable	<a href="#">"H0b_en.38" on page 255</a>
H0b.39	200b-28h	Motor phase V current upon occurrence of the selected fault	-3276.7A to 3276.7A	0.0	A	Unchangeable	<a href="#">"H0b_en.39" on page 255</a>
H0b.40	200b-29h	Bus voltage on selected fault	0.0 to 6553.5 V	0.0	V	Unchangeable	<a href="#">"H0b_en.40" on page 256</a>
H0b.41	200b-2Ah	Input terminal state on selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.41" on page 256</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.43	200b-2Ch	Output terminal state on selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.43" on page 256</a>
H0b.45	200b-2Eh	Internal fault code	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.45" on page 256</a>
H0b.46	200b-2Fh	Absolute encoder fault information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.46" on page 257</a>
H0b.47	200b-30h	System status information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.47" on page 257</a>
H0b.48	200b-31h	System fault information given by FPGA upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.48" on page 257</a>
H0b.49	200b-32h	Encoder fault information upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.49" on page 258</a>
H0b.51	200b-34h	Internal fault code upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.51" on page 258</a>
H0b.52	200b-35h	FPGA timeout fault standard bit upon occurrence of the selected fault	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.52" on page 258</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.53	200b-36h	Position following error (reference unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.53" on page 258</a>
H0b.55	200b-38h	Motor speed actual value	-2147483648.0rpm to 2147483647.0rpm	0.0	RPM	Unchangeable	<a href="#">"H0b_en.55" on page 259</a>
H0b.57	200b-3Ah	Control circuit bus voltage	0.0 to 6553.5 V	0.0	V	Unchangeable	<a href="#">"H0b_en.57" on page 259</a>
H0b.58	200b-3Bh	Mechanical absolute position (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.58" on page 259</a>
H0b.60	200b-3Dh	Mechanical absolute position (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.60" on page 260</a>
H0b.63	200b-40h	NotRdy state	1: Control power error 2: Main circuit power input error 3: Undervoltage 4: Soft start failed 5: Encoder initialization not completed 6: Short circuit to ground failed 7: Others	0	-	Unchangeable	<a href="#">"H0b_en.63" on page 260</a>
H0b.64	200b-41h	Real-time input position reference counter	-2147483648 to 2147483647	0	Reference unit	Unchangeable	<a href="#">"H0b_en.64" on page 260</a>
H0b.66	200b-43h	Encoder temperature	-32768°C to 32767°C	0	°C	Unchangeable	<a href="#">"H0b_en.66" on page 260</a>
H0b.67	200b-44h	Load rate of regenerative resistor	0.0%–200.0%	0.0	%	Unchangeable	<a href="#">"H0b_en.67" on page 261</a>
H0b.70	200b-47h	Number of absolute encoder revolutions	0 Rev to 65535 Rev	0	Rev	Unchangeable	<a href="#">"H0b_en.70" on page 261</a>
H0b.71	200b-48h	Single-turn position fed back by the absolute encoder	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.71" on page 261</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0b.74	200b-4Bh	System fault information given by FPGA	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.74" on page 262</a>
H0b.77	200b-4Eh	Encoder position (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.77" on page 262</a>
H0b.79	200b-50h	Encoder position (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.79" on page 262</a>
H0b.81	200b-52h	Single-turn position of the rotary load (low 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.81" on page 262</a>
H0b.83	200b-54h	Single-turn position of the rotary load (high 32 bits)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.83" on page 263</a>
H0b.85	200b-56h	Single-turn position of the rotary load (reference unit)	-2147483648 p to +2147483647 p	0	p	Unchangeable	<a href="#">"H0b_en.85" on page 263</a>
H0b.87	200b-58h	IGBT junction temperature	0 to 200	0	-	Unchangeable	<a href="#">"H0b_en.87" on page 263</a>
H0b.90	200b-5Bh	Group No. of the abnormal parameter	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.90" on page 263</a>
H0b.91	200b-5Ch	Offset within the group of the abnormal parameter	0 to 65535	0	-	Unchangeable	<a href="#">"H0b_en.91" on page 264</a>
H0b.94	200b-5Fh	Individual power-on time	0.0s–429496729.5s	0.0	s	Unchangeable	<a href="#">"H0b_en.94" on page 264</a>
H0b.96	200b-61h	Individual power-on time upon occurrence of the selected fault	0.0s–429496729.5s	0.0	s	Unchangeable	<a href="#">"H0b_en.96" on page 264</a>

## 5.13 Parameter Group H0d

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0d.00	200d-01h	Software reset	0: No operation 1: Enable	0	-	At stop	<a href="#">"H0d_en.00" on page 265</a>
H0d.01	200d-02h	Fault reset	0: No operation 1: Enable	0	-	At stop	<a href="#">"H0d_en.01" on page 265</a>
H0d.02	200d-03h	Inertia auto-tuning selection	0 to 65	0	-	Real-time	<a href="#">"H0d_en.02" on page 265</a>
H0d.04	200d-05h	Read/write in encoder ROM	0: No operation 1: Write ROM 2: Read ROM 3: ROM failure	0	-	At stop	<a href="#">"H0d_en.04" on page 266</a>
H0d.05	200d-06h	Emergency stop	0: No operation 1: Emergency stop	0	-	Real-time	<a href="#">"H0d_en.05" on page 266</a>
H0d.12	200d-0Dh	Phase U/V current balance correction	0: Disabled 1: Enabled	0	-	At stop	<a href="#">"H0d_en.12" on page 266</a>
H0d.17	200d-12h	Forced DI/DO enable switch	bit0: Forced DI enable switch 0: Disabled 1: Enabled bit1: Forced DO enable switch 0: Disabled 1: Enabled	0	-	Real-time	<a href="#">"H0d_en.17" on page 267</a>
H0d.18	200d-13h	Forced DI value	0 to 255	255	-	Real-time	<a href="#">"H0d_en.18" on page 267</a>
H0d.19	200d-14h	Forced DO value	0 to 31	0	-	Real-time	<a href="#">"H0d_en.19" on page 267</a>
H0d.20	200d-15h	Absolute encoder reset	0: No operation 1: Reset 2: Reset the fault and multi-turn data	0	-	At stop	<a href="#">"H0d_en.20" on page 268</a>
H0d.23	200d-18h	Torque fluctuation auto-tuning	0 to 1	0	-	At stop	<a href="#">"H0d_en.23" on page 268</a>
H0d.26	200d-1Bh	Brake and dynamic brake started forcibly	0: No forcible operations 1: Dynamic brake deactivated forcibly 2: Brake released forcibly 3: Dynamic brake deactivated and brake released forcibly	0	-	At stop	<a href="#">"H0d_en.26" on page 268</a>

## 5.14 Parameter Group H0E

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H0E.00	200E-01h	Node address	1 to 127	1	-	At stop	<a href="#">"H0E_en.00" on page 269</a>
H0E.01	200E-02h	Save objects written through communication to EEPROM	0: Not save 1: Save parameters written through communication to EEPROM 2: Save object dictionaries written through communication to EEPROM 3: Save parameters and object dictionaries written through communication to EEPROM 4: Save object dictionaries written before communication (OP) to EEPROM	1	-	Real-time	<a href="#">"H0E_en.01" on page 269</a>
H0E.07	200E-08h	Object dictionary unit selection	0: Reference unit system (p/s, p/s <sup>2</sup> ) 1: User unit system (0.01 rpm, ms)	0	-	At stop	<a href="#">"H0E_en.07" on page 270</a>
H0E.80	200E-51h	Modbus baud rate	4: 4800 bps 5: 9600 bps 6: 19200 bps 7: 38400 bps 8: 57600 bps 9: 115200 bps	9	-	Real-time	<a href="#">"H0E_en.80" on page 272</a>
H0E.81	200E-52h	Modbus data format	3: No parity, 1 stop bit (N-1)	3	-	Real-time	<a href="#">"H0E_en.81" on page 273</a>
H0E.82	200E-53h	Modbus response delay	0 ms to 20 ms	0	ms	Real-time	<a href="#">"H0E_en.82" on page 273</a>
H0E.83	200E-54h	Modbus communication timeout	0 ms to 600 ms	0	ms	Real-time	<a href="#">"H0E_en.83" on page 273</a>
H0E.84	200E-55h	Sequence of Modbus communication data bits	0: High bits before low bits 1: Low bits before high bits	1	-	Real-time	<a href="#">"H0E_en.84" on page 273</a>
H0E.90	200E-5Bh	Modbus version	0.00 to 655.35	0.00	-	Unchangeable	<a href="#">"H0E_en.90" on page 274</a>



## 5.15 Parameter Group H12

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H12.00	2012-01h	Multi-speed operation mode	0: Individual operation (number of speeds selected in H12.01) 1: Cyclic operation (number of speeds selected in H12.01) 2: DI-based operation	1	-	At stop	<a href="#">"H12_en.00" on page 275</a>
H12.01	2012-02h	Number of speed references in multi-speed mode	1 to 16	16	-	At stop	<a href="#">"H12_en.01" on page 275</a>
H12.02	2012-03h	Operating time unit	0: s 1: min	0	-	At stop	<a href="#">"H12_en.02" on page 276</a>
H12.03	2012-04h	Acceleration time 1	0 ms to 65535 ms	10	ms	Real-time	<a href="#">"H12_en.03" on page 276</a>
H12.04	2012-05h	Deceleration time 1	0 ms to 65535 ms	10	ms	Real-time	<a href="#">"H12_en.04" on page 276</a>
H12.05	2012-06h	Acceleration time 2	0 ms to 65535 ms	50	ms	Real-time	<a href="#">"H12_en.05" on page 277</a>
H12.06	2012-07h	Deceleration time 2	0 ms to 65535 ms	50	ms	Real-time	<a href="#">"H12_en.06" on page 277</a>
H12.07	2012-08h	Acceleration time 3	0 ms to 65535 ms	100	ms	Real-time	<a href="#">"H12_en.07" on page 277</a>
H12.08	2012-09h	Deceleration time 3	0 ms to 65535 ms	100	ms	Real-time	<a href="#">"H12_en.08" on page 277</a>
H12.09	2012-0Ah	Acceleration time 4	0 ms to 65535 ms	150	ms	Real-time	<a href="#">"H12_en.09" on page 278</a>
H12.10	2012-0Bh	Deceleration time 4	0 ms to 65535 ms	150	ms	Real-time	<a href="#">"H12_en.10" on page 278</a>
H12.20	2012-15h	Speed reference 1	-10000 RPM to +10000 RPM	0	RPM	Real-time	<a href="#">"H12_en.20" on page 278</a>
H12.21	2012-16h	Operating time of speed 1	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.21" on page 278</a>
H12.22	2012-17h	Acc./dec. time of speed 1	0: Zero acceleration/ deceleration time 1: Acceleration/Deceleration time 1 2: Acceleration/Deceleration time 2 3: Acceleration/Deceleration time 3 4: Acceleration/Deceleration time 4	0	-	Real-time	<a href="#">"H12_en.22" on page 279</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H12.23	2012-18h	Reference 2	-10000 RPM to +10000 RPM	100	RPM	Real-time	<a href="#">"H12_en.23" on page 279</a>
H12.24	2012-19h	Operating time of speed reference 2	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.24" on page 279</a>
H12.25	2012-1Ah	Acc./dec. time of speed 2	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.25" on page 280</a>
H12.26	2012-1Bh	Reference 3	-10000 RPM to +10000 RPM	300	RPM	Real-time	<a href="#">"H12_en.26" on page 280</a>
H12.27	2012-1Ch	Operating time of speed reference 3	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.27" on page 280</a>
H12.28	2012-1Dh	Acc./dec. time of speed 3	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.28" on page 280</a>
H12.29	2012-1Eh	Reference 4	-10000 RPM to +10000 RPM	500	RPM	Real-time	<a href="#">"H12_en.29" on page 281</a>
H12.30	2012-1Fh	Operating time of speed reference 4	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.30" on page 281</a>
H12.31	2012-20h	Acc./dec. time of speed 4	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.31" on page 281</a>
H12.32	2012-21h	Reference 5	-10000 RPM to +10000 RPM	700	RPM	Real-time	<a href="#">"H12_en.32" on page 281</a>
H12.33	2012-22h	Operating time of speed reference 5	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.33" on page 282</a>
H12.34	2012-23h	Acc./dec. time of speed 5	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.34" on page 282</a>
H12.35	2012-24h	Reference 6	-10000 RPM to +10000 RPM	900	RPM	Real-time	<a href="#">"H12_en.35" on page 282</a>
H12.36	2012-25h	Operating time of speed reference 6	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.36" on page 283</a>
H12.37	2012-26h	Acc./dec. time of speed 6	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.37" on page 283</a>
H12.38	2012-27h	Reference 7	-10000 RPM to +10000 RPM	600	RPM	Real-time	<a href="#">"H12_en.38" on page 283</a>
H12.39	2012-28h	Operating time of speed reference 7	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.39" on page 283</a>
H12.40	2012-29h	Acc./dec. time of speed 7	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.40" on page 284</a>
H12.41	2012-2Ah	Reference 8	-10000 RPM to +10000 RPM	300	RPM	Real-time	<a href="#">"H12_en.41" on page 284</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H12.42	2012-2Bh	Operating time of speed reference 8	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.42" on page 284</a>
H12.43	2012-2Ch	Acc./dec. time of speed 8	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.43" on page 284</a>
H12.44	2012-2Dh	Reference 9	-10000 RPM to +10000 RPM	100	RPM	Real-time	<a href="#">"H12_en.44" on page 285</a>
H12.45	2012-2Eh	Operating time of speed reference 9	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.45" on page 285</a>
H12.46	2012-2Fh	Acc./dec. time of speed 9	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.46" on page 285</a>
H12.47	2012-30h	Reference 10	-10000 RPM to +10000 RPM	-100	RPM	Real-time	<a href="#">"H12_en.47" on page 285</a>
H12.48	2012-31h	Operating time of speed reference 10	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.48" on page 286</a>
H12.49	2012-32h	Acc./dec. time of speed 10	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.49" on page 286</a>
H12.50	2012-33h	Reference 11	-10000 RPM to +10000 RPM	-300	RPM	Real-time	<a href="#">"H12_en.50" on page 286</a>
H12.51	2012-34h	Operating time of speed reference 11	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.51" on page 287</a>
H12.52	2012-35h	Acc./dec. time of speed 11	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.52" on page 287</a>
H12.53	2012-36h	Reference 12	-10000 RPM to +10000 RPM	-500	RPM	Real-time	<a href="#">"H12_en.53" on page 287</a>
H12.54	2012-37h	Operating time of speed reference 12	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.54" on page 287</a>
H12.55	2012-38h	Acc./dec. time of speed 12	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.55" on page 288</a>
H12.56	2012-39h	Reference 13	-10000 RPM to +10000 RPM	-700	RPM	Real-time	<a href="#">"H12_en.56" on page 288</a>
H12.57	2012-3Ah	Operating time of speed reference 13	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.57" on page 288</a>
H12.58	2012-3Bh	Acc./dec. time of speed 13	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.58" on page 288</a>
H12.59	2012-3Ch	Reference 14	-10000 RPM to +10000 RPM	-900	RPM	Real-time	<a href="#">"H12_en.59" on page 289</a>
H12.60	2012-3Dh	Operating time of speed reference 14	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.60" on page 289</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H12.61	2012-3Eh	Acc./dec. time of speed 14	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.61" on page 289</a>
H12.62	2012-3Fh	Reference 15	-10000 RPM to +10000 RPM	-600	RPM	Real-time	<a href="#">"H12_en.62" on page 289</a>
H12.63	2012-40h	Operating time of speed reference 15	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.63" on page 290</a>
H12.64	2012-41h	Acc./dec. time of speed 15	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.64" on page 290</a>
H12.65	2012-42h	Reference 16	-10000 RPM to +10000 RPM	-300	RPM	Real-time	<a href="#">"H12_en.65" on page 290</a>
H12.66	2012-43h	Operating time of speed reference 16	0.0s(m) to 6553.5s(m)	5.0	s (m)	Real-time	<a href="#">"H12_en.66" on page 291</a>
H12.67	2012-44h	Acc./dec. time of speed 16	Same as H12.22.	0	-	Real-time	<a href="#">"H12_en.67" on page 291</a>

## 5.16 Parameter Group H17

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.90	2017-5Bh	Communication VDI enable	0: Disabled 1: Enabled	0	-	At stop	<a href="#">"H17_en.90" on page 291</a>
H17.91	2017-5Ch	VDI default value upon power-on	0: No default 1: VDI1 default value 2: VDI2 default value 4: VDI3 default value 8: VDI4 default value 16: VDI5 default value 32: VDI6 default value 64: VDI7 default value 128: VDI8 default value 256: VDI9 default value 512: VDI10 default value 1024: VDI11 default value 2048: VDI12 default value 4096: VDI13 default value 8092: VDI14 default value 16384: VDI15 default value 32768: VDI16 default value	0	-	Real-time	<a href="#">"H17_en.91" on page 291</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.00	2017-01h	VDI1 function selection	0: No assignment 1: Servo ON 3: Gain switchover 14: Positive limit switch 15: Negative limit switch 16: Positive external torque limit 17: Negative external torque limit 18: Forward jog 19: Reverse jog 31: Home switch 34: Emergency stop 41: Current position as home 56: External switchover switch of EPOS program segment	0	-	Real-time	<a href="#">"H17_en.00" on page 292</a>
H17.01	2017-02h	VDI1 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.01" on page 293</a>
H17.02	2017-03h	VDI2 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.02" on page 293</a>
H17.03	2017-04h	VDI2 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.03" on page 294</a>
H17.04	2017-05h	VDI3 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.04" on page 294</a>
H17.05	2017-06h	VDI3 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.05" on page 294</a>
H17.06	2017-07h	VDI4 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.06" on page 294</a>
H17.07	2017-08h	VDI4 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.07" on page 295</a>
H17.08	2017-09h	VDI5 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.08" on page 295</a>
H17.09	2017-0Ah	VDI5 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.09" on page 295</a>
H17.10	2017-0Bh	VDI6 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.10" on page 295</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.11	2017-0Ch	VDI6 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.11" on page 296</a>
H17.12	2017-0Dh	VDI7 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.12" on page 296</a>
H17.13	2017-0Eh	VDI7 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.13" on page 296</a>
H17.14	2017-0Fh	VDI8 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.14" on page 297</a>
H17.15	2017-10h	VDI8 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.15" on page 297</a>
H17.16	2017-11h	VDI9 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.16" on page 297</a>
H17.17	2017-12h	VDI9 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.17" on page 297</a>
H17.18	2017-13h	VDI10 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.18" on page 298</a>
H17.19	2017-14h	VDI10 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.19" on page 298</a>
H17.20	2017-15h	VDI11 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.20" on page 298</a>
H17.21	2017-16h	VDI11 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.21" on page 298</a>
H17.22	2017-17h	VDI12 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.22" on page 299</a>
H17.23	2017-18h	VDI12 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.23" on page 299</a>
H17.24	2017-19h	VDI13 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.24" on page 299</a>

# Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.25	2017-1Ah	VDI13 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.25" on page 300</a>
H17.26	2017-1Bh	VDI14 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.26" on page 300</a>
H17.27	2017-1Ch	VDI14 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.27" on page 300</a>
H17.28	2017-1Dh	VDI15 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.28" on page 300</a>
H17.29	2017-1Eh	VDI15 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.29" on page 301</a>
H17.30	2017-1Fh	VDI16 function selection	Same as H17.00.	0	-	Real-time	<a href="#">"H17_en.30" on page 301</a>
H17.31	2017-20h	VDI16 logic level selection	0: Active when the written value is 1 1: Active when the written value changes from 0 to 1	0	-	At stop	<a href="#">"H17_en.31" on page 301</a>
H17.92	2017-5Dh	Communication VDO enable	0: Disabled 1: Enabled	0	-	At stop	<a href="#">"H17_en.92" on page 301</a>
H17.93	2017-5Eh	VDO default value after power-on	0: No default 1: VDI1 default value 2: VDI2 default value 4: VDI3 default value 8: VDI4 default value 16: VDI5 default value 32: VDI6 default value 64: VDI7 default value 128: VDI8 default value 256: VDI9 default value 512: VDI10 default value 1024: VDI11 default value 2048: VDI12 default value 4096: VDI13 default value 8192: VDI14 default value 16384: VDI15 default value 32768: VDI16 default value	0	-	At stop	<a href="#">"H17_en.93" on page 302</a>
H17.32	2017-21h	VDO virtual level	0 to 65535	0	-	Unchangeable	<a href="#">"H17_en.32" on page 302</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.33	2017-22h	VDO1 function selection	0: No assignment 1: Servo ready 2: Motor rotating 3: Zero speed 4: Speed matching 5: Positioning completed 6: Proximity 7: Torque limited 8: Speed limited 9: Brake 10: Warning 11: Fault 16: Homing completed 18: Torque reach 19: Speed reach 25: Comparison output 30: Warning or fault output 32: EDM output	0	-	Real-time	<a href="#">"H17_en.33" on page 303</a>
H17.34	2017-23h	VDO1 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.34" on page 303</a>
H17.35	2017-24h	VDO2 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.35" on page 304</a>
H17.36	2017-25h	VDO2 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.36" on page 304</a>
H17.37	2017-26h	VDO3 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.37" on page 304</a>
H17.38	2017-27h	VDO3 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.38" on page 304</a>
H17.39	2017-28h	VDO4 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.39" on page 305</a>
H17.40	2017-29h	VDO4 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.40" on page 305</a>
H17.41	2017-2Ah	VDO5 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.41" on page 305</a>
H17.42	2017-2Bh	VDO5 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.42" on page 306</a>
H17.43	2017-2Ch	VDO6 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.43" on page 306</a>
H17.44	2017-2Dh	VDO6 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.44" on page 306</a>
H17.45	2017-2Eh	VDO7 function selection	Same as H17.33.	0	-	Real-time	<a href="#">"H17_en.45" on page 306</a>
H17.46	2017-2Fh	VDO7 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	<a href="#">"H17_en.46" on page 307</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H17.47	2017-30h	VDO8 function selection	Same as H17.33.	0	-	Real-time	"H17_en.47" on page 307
H17.48	2017-31h	VDO8 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.48" on page 307
H17.49	2017-32h	VDO9 function selection	Same as H17.33.	0	-	Real-time	"H17_en.49" on page 307
H17.50	2017-33h	VDO9 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.50" on page 308
H17.51	2017-34h	VDO10 function selection	Same as H17.33.	0	-	Real-time	"H17_en.51" on page 308
H17.52	2017-35h	VDO10 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.52" on page 308
H17.53	2017-36h	VDO11 function selection	Same as H17.33.	0	-	Real-time	"H17_en.53" on page 309
H17.54	2017-37h	VDO11 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.54" on page 309
H17.55	2017-38h	VDO12 function selection	Same as H17.33.	0	-	Real-time	"H17_en.55" on page 309
H17.56	2017-39h	VDO12 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.56" on page 309
H17.57	2017-3Ah	VDO13 function selection	Same as H17.33.	0	-	Real-time	"H17_en.57" on page 310
H17.58	2017-3Bh	VDO13 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.58" on page 310
H17.59	2017-3Ch	VDO14 function selection	Same as H17.33.	0	-	Real-time	"H17_en.59" on page 310
H17.60	2017-3Dh	VDO14 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.60" on page 310
H17.61	2017-3Eh	VDO15 function selection	Same as H17.33.	0	-	Real-time	"H17_en.61" on page 311
H17.62	2017-3Fh	VDO15 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.62" on page 311
H17.63	2017-40h	VDO16 function selection	Same as H17.33.	0	-	Real-time	"H17_en.63" on page 311
H17.64	2017-41h	VDO16 logic level selection	0: Output 1 upon active logic 1: Output 0 upon active logic	0	-	Real-time	"H17_en.64" on page 312

## 5.17 Parameter Group H18

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H18.00	2018-01h	Position comparison output selection	0: Disable 1: Enable (rising edge-triggered)	0	-	Real-time	<a href="#">"H18_en.00" on page 312</a>
H18.01	2018-02h	Position comparison output feedback source	0: Motor encoder feedback 1: Fully closed-loop position feedback	0	-	Real-time	<a href="#">"H18_en.01" on page 312</a>
H18.02	2018-03h	Position comparison resolution	0: 24-bit 1: 23-bit 2: 22-bit 3: 21-bit 4: 20-bit 5: 19-bit 6: 18-bit 7: 17-bit	0	-	Real-time	<a href="#">"H18_en.02" on page 312</a>
H18.03	2018-04h	Position comparison mode	0: Individual comparison mode 1: Cyclic comparison mode 2: Fixed cyclic comparison mode	0	-	Real-time	<a href="#">"H18_en.03" on page 313</a>
H18.04	2018-05h	Current position as zero	0: Disable 1: Enable (rising edge-triggered)	0	-	Real-time	<a href="#">"H18_en.04" on page 313</a>
H18.05	2018-06h	Position comparison output width	0.1 ms to 204.7 ms	0.1	ms	Real-time	<a href="#">"H18_en.05" on page 314</a>
H18.06	2018-07h	Position comparison output ABZ port polarity	bit0: OCZ output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic bit1: Z port output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic bit2: A/B output logic 0: Positive, output high level upon active logic 1: Negative, output low level upon active logic	0	-	Real-time	<a href="#">"H18_en.06" on page 314</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H18.07	2018-08h	Position comparison start point	0 to 40	0	-	Real-time	<a href="#">"H18_en.07" on page 314</a>
H18.08	2018-09h	Position comparison end point	0 to 40	0	-	Real-time	<a href="#">"H18_en.08" on page 315</a>
H18.09	2018-0Ah	Current state of position comparison	0 to 1024	0	-	Unchangeable	<a href="#">"H18_en.09" on page 315</a>
H18.10	2018-0Bh	Real-time position of position comparison	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H18_en.10" on page 315</a>
H18.12	2018-0Dh	Zero offset of position comparison	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H18_en.12" on page 315</a>
H18.14	2018-0Fh	Position comparison output delay compensation	-30.00us to 30.00us	0.00	us	Real-time	<a href="#">"H18_en.14" on page 316</a>
H18.15	2018-10h	Fixed cyclic comparison	1 to 65535	1	-	Real-time	<a href="#">"H18_en.15" on page 316</a>
H18.16	2018-11h	ABZ output function setting	bit0: OCZ port function 0: Frequency-division output 1: Position comparison bit1: Z port function 0: Frequency-division output 1: Position comparison bit2: A/B port function 0: Frequency-division output 1: Position comparison	0	-	Real-time	<a href="#">"H18_en.16" on page 316</a>
H18.17	2018-12h	Number of fixed mode cycles	1 to 65535	1	-	Unchangeable	<a href="#">"H18_en.17" on page 317</a>

## 5.18 Parameter Group H19

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.00	2019-01h	Target value of position comparison 1	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.00" on page 317</a>
H19.02	2019-03h	Attribute value of position comparison 1	bit0: Current position changes from "less than" to "more than" the comparison point bit1: Current position changes from "more than" to "less than" the comparison point bit2: Reserved bit3: Reserved bit4: Reserved bit5: Reserved bit6: Status unchanged bit7: DO1 output bit8: DO2 output bit9: DO3 output bit10: DO4 output bit12: Frequency-division A output bit13: Frequency-division B output bit14: Frequency-division Z output bit15: Frequency-division OCZ output	0	-	Real-time	<a href="#">"H19_en.02" on page 318</a>
H19.03	2019-04h	Target value of position comparison 2	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.03" on page 318</a>
H19.05	2019-06h	Attribute value of position comparison 2	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.05" on page 318</a>
H19.06	2019-07h	Target value of position comparison 3	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.06" on page 319</a>
H19.08	2019-09h	Attribute value of position comparison 3	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.08" on page 319</a>
H19.09	2019-0Ah	Target value of position comparison 4	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.09" on page 319</a>
H19.11	2019-0Ch	Attribute value of position comparison 4	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.11" on page 320</a>

## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.12	2019-0Dh	Target value of position comparison 5	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.12" on page 320</a>
H19.14	2019-0Fh	Attribute value of position comparison 5	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.14" on page 320</a>
H19.15	2019-10h	Target value of position comparison 6	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.15" on page 320</a>
H19.17	2019-12h	Attribute value of position comparison 6	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.17" on page 321</a>
H19.18	2019-13h	Target value of position comparison 7	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.18" on page 321</a>
H19.20	2019-15h	Attribute value of position comparison 7	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.20" on page 321</a>
H19.21	2019-16h	Target value of position comparison 8	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.21" on page 321</a>
H19.23	2019-18h	Attribute value of position comparison 8	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.23" on page 322</a>
H19.24	2019-19h	Target value of position comparison 9	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.24" on page 322</a>
H19.26	2019-1Bh	Attribute value of position comparison 9	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.26" on page 322</a>
H19.27	2019-1Ch	Target value of position comparison 10	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.27" on page 322</a>
H19.29	2019-1Eh	Attribute value of position comparison 10	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.29" on page 323</a>
H19.30	2019-1Fh	Target value of position comparison 11	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.30" on page 323</a>
H19.32	2019-21h	Attribute value of position comparison 11	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.32" on page 323</a>
H19.33	2019-22h	Target value of position comparison 12	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.33" on page 324</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.35	2019-24h	Attribute value of position comparison 12	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.35" on page 324</a>
H19.36	2019-25h	Target value of position comparison 13	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.36" on page 324</a>
H19.38	2019-27h	Attribute value of position comparison 13	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.38" on page 324</a>
H19.39	2019-28h	Target value of position comparison 14	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.39" on page 325</a>
H19.41	2019-2Ah	Attribute value of position comparison 14	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.41" on page 325</a>
H19.42	2019-2Bh	Target value of position comparison 15	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.42" on page 325</a>
H19.44	2019-2Dh	Attribute value of position comparison 15	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.44" on page 325</a>
H19.45	2019-2Eh	Target value of position comparison 16	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.45" on page 326</a>
H19.47	2019-30h	Attribute value of position comparison 16	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.47" on page 326</a>
H19.48	2019-31h	Target value of position comparison 17	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.48" on page 326</a>
H19.50	2019-33h	Attribute value of position comparison 17	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.50" on page 326</a>
H19.51	2019-34h	Target value of position comparison 18	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.51" on page 327</a>
H19.53	2019-36h	Attribute value of position comparison 18	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.53" on page 327</a>
H19.54	2019-37h	Target value of position comparison 19	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.54" on page 327</a>
H19.56	2019-39h	Attribute value of position comparison 19	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.56" on page 328</a>

## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.57	2019-3Ah	Target value of position comparison 20	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.57" on page 328</a>
H19.59	2019-3Ch	Attribute value of position comparison 20	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.59" on page 328</a>
H19.60	2019-3Dh	Target value of position comparison 21	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.60" on page 328</a>
H19.62	2019-3Fh	Attribute value of position comparison 21	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.62" on page 329</a>
H19.63	2019-40h	Target value of position comparison 22	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.63" on page 329</a>
H19.65	2019-42h	Attribute value of position comparison 22	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.65" on page 329</a>
H19.66	2019-43h	Target value of position comparison 23	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.66" on page 329</a>
H19.68	2019-45h	Attribute value of position comparison 23	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.68" on page 330</a>
H19.69	2019-46h	Target value of position comparison 24	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.69" on page 330</a>
H19.71	2019-48h	Attribute value of position comparison 24	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.71" on page 330</a>
H19.72	2019-49h	Target value of position comparison 25	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.72" on page 330</a>
H19.74	2019-4Bh	Attribute value of position comparison 25	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.74" on page 331</a>
H19.75	2019-4Ch	Target value of position comparison 26	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.75" on page 331</a>
H19.77	2019-4Eh	Attribute value of position comparison 26	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.77" on page 331</a>
H19.78	2019-4Fh	Target value of position comparison 27	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.78" on page 332</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.80	2019-51h	Attribute value of position comparison 27	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.80" on page 332</a>
H19.81	2019-52h	Target value of position comparison 28	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.81" on page 332</a>
H19.83	2019-54h	Attribute value of position comparison 28	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.83" on page 332</a>
H19.84	2019-55h	Target value of position comparison 29	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.84" on page 333</a>
H19.86	2019-57h	Attribute value of position comparison 29	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.86" on page 333</a>
H19.87	2019-58h	Target value of position comparison 30	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.87" on page 333</a>
H19.89	2019-5Ah	Attribute value of position comparison 30	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.89" on page 333</a>
H19.90	2019-5Bh	Target value of position comparison 31	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.90" on page 334</a>
H19.92	2019-5Dh	Attribute value of position comparison 31	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.92" on page 334</a>
H19.93	2019-5Eh	Target value of position comparison 32	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.93" on page 334</a>
H19.95	2019-60h	Attribute value of position comparison 32	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.95" on page 334</a>
H19.96	2019-61h	Target value of position comparison 33	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.96" on page 335</a>
H19.98	2019-63h	Attribute value of position comparison 33	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.98" on page 335</a>
H19.99	2019-64h	Target value of position comparison 34	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.99" on page 335</a>
H19.101	2019-66h	Attribute value of position comparison 34	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.101" on page 336</a>



## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H19.102	2019-67h	Target value of position comparison 35	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.102" on page 336</a>
H19.104	2019-69h	Attribute value of position comparison 35	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.104" on page 336</a>
H19.105	2019-6Ah	Target value of position comparison 36	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.105" on page 336</a>
H19.107	2019-6Ch	Attribute value of position comparison 36	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.107" on page 337</a>
H19.108	2019-6Dh	Target value of position comparison 37	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.108" on page 337</a>
H19.110	2019-6Fh	Attribute value of position comparison 37	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.110" on page 337</a>
H19.111	2019-70h	Target value of position comparison 38	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.111" on page 337</a>
H19.113	2019-72h	Attribute value of position comparison 38	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.113" on page 338</a>
H19.114	2019-73h	Target value of position comparison 39	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.114" on page 338</a>
H19.116	2019-75h	Attribute value of position comparison 39	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.116" on page 338</a>
H19.117	2019-76h	Target value of position comparison 40	-2147483648 to 2147483647	0	-	Real-time	<a href="#">"H19_en.117" on page 338</a>
H19.119	2019-78h	Attribute value of position comparison 40	Same as H19.02.	0	-	Real-time	<a href="#">"H19_en.119" on page 339</a>

## 5.19 Parameter Group H24

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H24.00	2024-01h	Message number selection [PN922]	0 to 65535	3	-	Unchangeable	<a href="#">"H24_en.00" on page 339</a>
H24.01	2024-02h	Heartbeat warning threshold [PN925]	0 to 65535	5	-	At stop	<a href="#">"H24_en.01" on page 339</a>
H24.02	2024-03h	Fault message counter [PN944]	0 to 65535	0	-	Unchangeable	<a href="#">"H24_en.02" on page 340</a>
H24.03	2024-04h	Fault code [PN947]	0 to 65535	0	-	Unchangeable	<a href="#">"H24_en.03" on page 340</a>
H24.04	2024-05h	Fault No.	0 to 63	0	-	At stop	<a href="#">"H24_en.04" on page 340</a>
H24.05	2024-06h	Fault condition counter [PN952]	0 to 65535	0	-	At stop	<a href="#">"H24_en.05" on page 340</a>
H24.06	2024-07h	Sensor header [PN979[0]]	0 to 4294967295	20754	-	At stop	<a href="#">"H24_en.06" on page 341</a>
H24.08	2024-09h	Sensor type [PN979[1]]	0 to 4294967295	2147483650	-	At stop	<a href="#">"H24_en.08" on page 341</a>
H24.10	2024-0Bh	Sensor resolution [PN979[2]]	0 to 4294967295	256	-	At stop	<a href="#">"H24_en.10" on page 341</a>
H24.12	2024-0Dh	Sensor G1_X1ST1 displacement factor [PN979[3]]	0 to 24	15	-	At stop	<a href="#">"H24_en.12" on page 341</a>
H24.14	2024-0Fh	Sensor G1_X1ST2 displacement factor [PN979[4]]	0 to 24	15	-	At stop	<a href="#">"H24_en.14" on page 342</a>
H24.16	2024-11h	Sensor multi-turn number [PN979[5]]	0 to 4294967295	512	-	At stop	<a href="#">"H24_en.16" on page 342</a>
H24.19	2024-14h	Synchronization cycle	0 to 65535	999	-	Unchangeable	<a href="#">"H24_en.19" on page 342</a>

## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H24.20	2024-15h	Network parameter write flag	0 to 3	0	-	At stop	<a href="#">"H24_en.20" on page 343</a>
H24.22	2024-17h	IP Address	0 to 0	0	-	Real-time	<a href="#">"H24_en.22" on page 343</a>
H24.24	2024-19h	Subnet mask	0 to 0	0	-	Real-time	<a href="#">"H24_en.24" on page 343</a>
H24.26	2024-1Bh	Default gateway	0 to 0	0	-	Real-time	<a href="#">"H24_en.26" on page 343</a>
H24.28	2024-1Dh	AC1 speed feedback selection	0: Normal 1: High precision	0	-	At stop	<a href="#">"H24_en.28" on page 344</a>
H24.32	2024-21h	DSC position loop gain selection	0: Local position loop gain 1: PLC position loop gain 3: DSC manual tuning	0	-	At stop	<a href="#">"H24_en.32" on page 344</a>
H24.33	2024-22h	Number of Sync with advanced DSC position feedback	0 to 16	1	-	Real-time	<a href="#">"H24_en.33" on page 348</a>
H24.34	2024-23h	Loop gain selection switch	0: Stiffness level adapted based on DSC gain 1: Stiffness level adapted based on H09.01	0	-	At stop	<a href="#">"H24_en.34" on page 348</a>
H24.35	2024-24h	Customized telegram 850 transmission	0: No assignment 1: VDO 2: External DI state	0	-	Real-time	<a href="#">"H24_en.35" on page 344</a>
H24.36	2024-25h	User-defined 850 reception	0: No assignment 1: VDI 2: External DO state	0	-	Real-time	<a href="#">"H24_en.36" on page 345</a>
H24.37	2024-26h	Extra telegram	0 to 65535	0	-	At stop	<a href="#">"H24_en.37" on page 345</a>
H24.38	2024-27h	Customized receive word	0: No function 1: Additive torque 2: Forced DO	0	-	Real-time	<a href="#">"H24_en.38" on page 345</a>
H24.39	2024-28h	Customized transmission word	0: No function 1: Actual torque 2: Actual current 3: DI state	0	-	Real-time	<a href="#">"H24_en.39" on page 345</a>
H24.41	2024-2Ah	Device name loss warning selection	0 to 1	0	-	Real-time	<a href="#">"H24_en.41" on page 346</a>
H24.42	2024-2Bh	Number of consecutive loss detections	0 to 65535	8	-	Real-time	<a href="#">"H24_en.42" on page 346</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H24.43	2024-2Ch	Communication timeout time	1 to 65535	1000	-	Real-time	"H24_en.43" on page 346
H24.44	2024-2Dh	FPGA synchronous detection deviation threshold	0 ns to 65535 ns	3000	ns	At stop	"H24_en.44" on page 347
H24.45	2024-2Eh	MAC address	0 to 65535	0	-	Real-time	"H24_en.45" on page 347
H24.46	2024-2Fh	MAC address	0 to 65535	0	-	Real-time	"H24_en.46" on page 347
H24.47	2024-30h	MAC address	0 to 65535	0	-	Real-time	"H24_en.47" on page 347
H24.48	2024-31h	DSC position loop gain coefficient	1 to 31	10	-	At stop	"H24_en.48" on page 348

## 5.20 Parameter Group H25

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H25.00	2025-01h	EPOS max. speed	1 LU/min–40000000 LU/min	30000	1000 LU/min	Real-time	"H25_en.00" on page 349
H25.02	2025-03h	EPOS max. acceleration	1 LU/s/s–2000000 LU/s/s	100	1000 LU/s/s	Real-time	"H25_en.02" on page 349
H25.04	2025-05h	EPOS max. deceleration	1 LU/s/s–2000000 LU/s/s	100	1000 LU/s/s	Real-time	"H25_en.04" on page 349
H25.06	2025-07h	EPOS ramp deceleration	1 LU/s/s–2000000 LU/s/s	100	1000 LU/s/s	Real-time	"H25_en.06" on page 350
H25.10	2025-0Bh	EPOS positioning reached threshold	0LU–2147483647LU	7	1LU	Real-time	"H25_en.10" on page 350
H25.12	2025-0Dh	EPOS positioning reached window time	0 ms to 2147483647 ms	0	ms	Real-time	"H25_en.12" on page 350
H25.14	2025-0Fh	Jog1	-40000000 LU/min–40000000 LU/min	-300	1000 LU/min	Real-time	"H25_en.14" on page 350
H25.16	2025-11h	Jog2	-40000000 LU/min–40000000 LU/min	300	1000 LU/min	Real-time	"H25_en.16" on page 351

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H25.18	2025-13h	EPOS-JOG1 position increment	0 LU–2147483648 LU	1000	LU	Real-time	<a href="#">"H25_en.18" on page 351</a>
H25.20	2025-15h	EPOS-JOG2 position increment	0 LU–2147483648 LU	1000	LU	Real-time	<a href="#">"H25_en.20" on page 351</a>
H25.22	2025-17h	Homing type	-2 to 35	0	-	Real-time	<a href="#">"H25_en.22" on page 351</a>
H25.23	2025-18h	Homing high speed	0 LU/min.–40000000 LU/min.	5000	1000 LU/min	Real-time	<a href="#">"H25_en.23" on page 352</a>
H25.25	2025-1Ah	Homing low speed	0 LU/min.–40000000 LU/min.	300	1000 LU/min	Real-time	<a href="#">"H25_en.25" on page 352</a>
H25.27	2025-1Ch	Homing acceleration/ deceleration override	0.00%–100.00%	100.00	%	Real-time	<a href="#">"H25_en.27" on page 352</a>

## 5.21 Parameter Group H27

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H27.00	2027-01h	Current block	0 to 15	0	-	Unchangeable	<a href="#">"H27_en.00" on page 353</a>
H27.01	2027-02h	Block 0 task	1: Positioning 2: Fixed stopper 3: Forward cycle 4: Reverse cycle 5: Waiting 6: Switching 7: Setting I/O 8: Resetting I/O	1	-	Real-time	<a href="#">"H27_en.01" on page 353</a>
H27.02	2027-03h	Block 1 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.02" on page 353</a>
H27.03	2027-04h	Block 2 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.03" on page 354</a>
H27.04	2027-05h	Block 3 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.04" on page 354</a>
H27.05	2027-06h	Block 4 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.05" on page 354</a>
H27.06	2027-07h	Block 5 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.06" on page 354</a>
H27.07	2027-08h	Block 6 task	Same as H27.01.	1	-	Real-time	<a href="#">"H27_en.07" on page 355</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H27.08	2027-09h	Block 7 task	Same as H27.01.	1	-	Real-time	"H27_en.08" on page 355
H27.09	2027-0Ah	Block 8 task	Same as H27.01.	1	-	Real-time	"H27_en.09" on page 355
H27.10	2027-0Bh	Block 9 task	Same as H27.01.	1	-	Real-time	"H27_en.10" on page 355
H27.11	2027-0Ch	Block 10 task	Same as H27.01.	1	-	Real-time	"H27_en.11" on page 356
H27.12	2027-0Dh	Block 11 task	Same as H27.01.	1	-	Real-time	"H27_en.12" on page 356
H27.13	2027-0Eh	Block 12 task	Same as H27.01.	1	-	Real-time	"H27_en.13" on page 356
H27.14	2027-0Fh	Block 13 task	Same as H27.01.	1	-	Real-time	"H27_en.14" on page 356
H27.15	2027-10h	Block 14 task	Same as H27.01.	1	-	Real-time	"H27_en.15" on page 357
H27.16	2027-11h	Block 15 task	Same as H27.01.	1	-	Real-time	"H27_en.16" on page 357
H27.17	2027-12h	Block 0 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.17" on page 357
H27.19	2027-14h	Block 1 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.19" on page 358
H27.21	2027-16h	Block 2 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.21" on page 358
H27.23	2027-18h	Block 3 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.23" on page 358
H27.25	2027-1Ah	Block 4 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.25" on page 358
H27.27	2027-1Ch	Block 5 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.27" on page 359
H27.29	2027-1Eh	Block 6 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.29" on page 359
H27.31	2027-20h	Block 7 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.31" on page 359
H27.33	2027-22h	Block 8 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.33" on page 359
H27.35	2027-24h	Block 9 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.35" on page 360
H27.37	2027-26h	Block 10 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.37" on page 360
H27.39	2027-28h	Block 11 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.39" on page 360
H27.41	2027-2Ah	Block 12 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.41" on page 360

# Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H27.43	2027-2Ch	Block 13 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.43" on page 361
H27.45	2027-2Eh	Block 14 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.45" on page 361
H27.47	2027-30h	Block 15 position	-2147483648LU to 2147483647LU	0	1LU	Real-time	"H27_en.47" on page 361
H27.49	2027-32h	Block 0 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.49" on page 362
H27.51	2027-34h	Block 1 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.51" on page 362
H27.53	2027-36h	Block 2 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.53" on page 362
H27.55	2027-38h	Block 3 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.55" on page 362
H27.57	2027-3Ah	Block 4 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.57" on page 363
H27.59	2027-3Ch	Block 5 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.59" on page 363
H27.61	2027-3Eh	Block 6 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.61" on page 363
H27.63	2027-40h	Block 7 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.63" on page 363
H27.65	2027-42h	Block 8 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.65" on page 364
H27.67	2027-44h	Block 9 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.67" on page 364
H27.69	2027-46h	Block 10 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.69" on page 364
H27.71	2027-48h	Block 11 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.71" on page 365
H27.73	2027-4Ah	Block 12 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.73" on page 365
H27.75	2027-4Ch	Block 13 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.75" on page 365
H27.77	2027-4Eh	Block 14 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.77" on page 365
H27.79	2027-50h	Block 15 speed	0 LU/min–4294967295 LU/min.	600	1000 LU/min	Real-time	"H27_en.79" on page 366
H27.81	2027-52h	Block 0 acc. override	1.00%–100.00%	100.00	%	Real-time	"H27_en.81" on page 366
H27.82	2027-53h	Block 1 acc. override	1.00%–100.00%	100.00	%	Real-time	"H27_en.82" on page 366
H27.83	2027-54h	Block 2 acc. override	1.00%–100.00%	100.00	%	Real-time	"H27_en.83" on page 366

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H27.84	2027-55h	Block 3 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.84" on page 367</a>
H27.85	2027-56h	Block 4 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.85" on page 367</a>
H27.86	2027-57h	Block 5 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.86" on page 367</a>
H27.87	2027-58h	Block 6 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.87" on page 367</a>
H27.88	2027-59h	Block 7 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.88" on page 368</a>
H27.89	2027-5Ah	Block 8 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.89" on page 368</a>
H27.90	2027-5Bh	Block 9 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.90" on page 368</a>
H27.91	2027-5Ch	Block 10 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.91" on page 369</a>
H27.92	2027-5Dh	Block 11 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.92" on page 369</a>
H27.93	2027-5Eh	Block 12 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.93" on page 369</a>
H27.94	2027-5Fh	Block 13 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.94" on page 369</a>
H27.95	2027-60h	Block 14 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.95" on page 370</a>
H27.96	2027-61h	Block 15 acc. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H27_en.96" on page 370</a>

## 5.22 Parameter Group H28

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H28.00	2028-01h	Block 0 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.00" on page 370</a>
H28.01	2028-02h	Block 1 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.01" on page 370</a>
H28.02	2028-03h	Block 2 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.02" on page 371</a>
H28.03	2028-04h	Block 3 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.03" on page 371</a>
H28.04	2028-05h	Block 4 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.04" on page 371</a>



## Parameter List

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H28.05	2028-06h	Block 5 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.05" on page 372</a>
H28.06	2028-07h	Block 6 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.06" on page 372</a>
H28.07	2028-08h	Block 7 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.07" on page 372</a>
H28.08	2028-09h	Block 8 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.08" on page 372</a>
H28.09	2028-0Ah	Block 9 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.09" on page 373</a>
H28.10	2028-0Bh	Block 10 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.10" on page 373</a>
H28.11	2028-0Ch	Block 11 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.11" on page 373</a>
H28.12	2028-0Dh	Block 12 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.12" on page 373</a>
H28.13	2028-0Eh	Block 13 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.13" on page 374</a>
H28.14	2028-0Fh	Block 14 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.14" on page 374</a>
H28.15	2028-10h	Block 15 dec. override	1.00%–100.00%	100.00	%	Real-time	<a href="#">"H28_en.15" on page 374</a>
H28.16	2028-11h	Block 0 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.16" on page 374</a>
H28.17	2028-12h	Block 1 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.17" on page 375</a>
H28.18	2028-13h	Block 2 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.18" on page 375</a>
H28.19	2028-14h	Block 3 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.19" on page 375</a>
H28.20	2028-15h	Block 4 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.20" on page 376</a>
H28.21	2028-16h	Block 5 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.21" on page 376</a>
H28.22	2028-17h	Block 6 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.22" on page 376</a>
H28.23	2028-18h	Block 7 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.23" on page 376</a>
H28.24	2028-19h	Block 8 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.24" on page 377</a>
H28.25	2028-1Ah	Block 9 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.25" on page 377</a>
H28.26	2028-1Bh	Block 10 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.26" on page 377</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H28.27	2028-1Ch	Block 11 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.27" on page 377</a>
H28.28	2028-1Dh	Block 12 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.28" on page 378</a>
H28.29	2028-1Eh	Block 13 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.29" on page 378</a>
H28.30	2028-1Fh	Block 14 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.30" on page 378</a>
H28.31	2028-20h	Block 15 task mode	0 to 65535	0	-	Real-time	<a href="#">"H28_en.31" on page 378</a>
H28.32	2028-21h	Block 0 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.32" on page 379</a>
H28.34	2028-23h	Block 1 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.34" on page 379</a>
H28.36	2028-25h	Block 2 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.36" on page 379</a>
H28.38	2028-27h	Block 3 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.38" on page 380</a>
H28.40	2028-29h	Block 4 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.40" on page 380</a>
H28.42	2028-2Bh	Block 5 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.42" on page 380</a>
H28.44	2028-2Dh	Block 6 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.44" on page 380</a>
H28.46	2028-2Fh	Block 7 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.46" on page 381</a>
H28.48	2028-31h	Block 8 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.48" on page 381</a>
H28.50	2028-33h	Block 9 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.50" on page 381</a>
H28.52	2028-35h	Block 10 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.52" on page 381</a>
H28.54	2028-37h	Block 11 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.54" on page 382</a>
H28.56	2028-39h	Block 12 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.56" on page 382</a>
H28.58	2028-3Bh	Block 13 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.58" on page 382</a>
H28.60	2028-3Dh	Block 14 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.60" on page 382</a>
H28.62	2028-3Fh	Block 15 task parameter	0 to 2147483647	0	-	Real-time	<a href="#">"H28_en.62" on page 383</a>

## Parameter List

---

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H28.64	2028-41h	Fixed stopper monitoring window	0 to 4294967295	0	-	Real-time	<a href="#">"H28_en.64" on page 383</a>
H28.66	2028-43h	Max. following error of fixed stopper	0 to 4294967295	0	-	Real-time	<a href="#">"H28_en.66" on page 383</a>
H28.68	2028-45h	External trigger source	0: Triggered by STW1.bit13 1: Triggered by DI	0	-	At stop	<a href="#">"H28_en.68" on page 384</a>

## 5.23 Parameter Group H29

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.00	2029-01h	Control word 1 (STW1)	Bit0: 1 = Pulse enable allowed; 0 = OFF1, ramp to stop, pulse cleared, ready to switch on bit1: 1 = No OFF2 (pulse enable allowed); 0 = OFF2, coast to stop, pulse cleared immediately, switch-on inhibited bit2: 1 = No OFF3 (pulse enable allowed); 0 = OFF3 quick stop, P1135 brake, pulse cleared, switch-on inhibited bit3: 1 = Enable allowed; 0 = Operation inhibited (pulse cleared) bit4: 1 = Ramp function generator available; 0 = Ramp function generator inhibited bit5: 1 = Ramp function generator continued; 0 = Ramp function generator output frozen bit6: 1 = Setpoint enabled; 0 = Setpoint inhibited (ramp function generator input being zero) bit7: Rising edge-triggered, response fault bit8: JOG1 bit9: JOG2 bit10: 1 = PLC controlled bit11: Reserved bit12: Reserved bit13: Reserved bit14: Reserved bit15: Reserved	0	-	Unchangeable	<a href="#">"H29_en.00" on page 384</a>
H29.01	2029-02h	Control word 2 (STW2)	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.01" on page 385</a>
H29.02	2029-03h	Speed setpoint A (VEL_NSOLL_A)	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.02" on page 385</a>
H29.04	2029-05h	Speed setpoint B (VEL_NSOLL_B)	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.04" on page 386</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.06	2029-07h	Encoder control word (G1_STW)	bit0: bit7 = 0, searching for reference point 1; bit7 = 1, measure the pointer 1 bit1: bit7 = 0, searching for reference point 2; bit7 = 1, measure the pointer 2 bit2: bit7 = 0, searching for reference point 3; bit7 = 1, measure the pointer 3 bit3: bit7 = 0, searching for reference point 4; bit7 = 1, measuring pointer 4 bit4: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel bit5: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel bit6: bit4–bit6 000b = Not activated; 001b = Selected functions activated; 010b = Read value; 011b = Cancel bit7: Mode selection; 1 = Real-time measurement; 0 = Searching for the reference point bit8: Reserved bit9: Reserved bit10: Reserved bit11: Zero setting mode; 0 = Absolute position; 1 = Relative position bit12: Rising edge-triggered; request for setting the zero bit bit13: Rising edge-triggered; request for cyclic transmission of absolute position in G1_XIST2 bit14: Parking encoder bit15: Rising-edge triggered Response encoder fault	0	-	Unchangeable	<a href="#">"H29_en.06" on page 386</a>
H29.07	2029-08h	Position deviation (XERR)	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.07" on page 387</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.09	2029-0Ah	Position loop gain (KPC)	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.09" on page 387</a>
H29.11	2029-0Ch	Position control word 1 (POS_STW1)	bit0: bit0–bit5 block selection IS620F supports up to 16 blocks bit1: bit0–bit5 block selection IS620F supports up to 16 blocks bit2: bit0–bit5 block selection IS620F supports up to 16 blocks bit3: bit0–bit5 block selection IS620F supports up to 16 blocks bit4: bit0–bit5 block selection IS620F supports up to 16 blocks bit5: bit0–bit5 block selection IS620F supports up to 16 blocks bit6: Reserved bit7: Reserved bit8: 1 = Absolute positioning 0 = Relative positioning bit9: 1 = Forward bit10: 1 = Reverse bit11: Reserved bit12: 1 = Continuous transmission 0 = MDI block modification activated by running the rising edge of the program segment (STW1.6) bit13: Reserved bit14: 1 = Setting signal selected 0 = Positioning signal selected bit15: 1 = MDI sub-mode 0 = Program segment sub-mode	0	-	Unchangeable	<a href="#">"H29_en.11" on page 388</a>
H29.12	2029-0Dh	MDI position setting (EPOS)	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.12" on page 388</a>
H29.14	2029-0Fh	MDI speed setting (EPOS)	0 to 4294967295	0	-	Unchangeable	<a href="#">"H29_en.14" on page 389</a>
H29.16	2029-11h	MDI acceleration override (EPOS)	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.16" on page 389</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.17	2029-12h	MDI deceleration override (EPOS)	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.17" on page 389</a>
H29.18	2029-13h	MDI mode (EPOS)	bit0: 1 = Absolute positioning 0 = Relative positioning bit1: 1 = Forward bit2: 1 = Reverse bit3: Reserved bit4: Reserved bit5: Reserved bit6: Reserved bit7: Reserved bit8: Reserved bit9: Reserved bit10: Reserved bit11: Reserved bit12: Reserved bit13: Reserved bit14: Reserved bit15: Reserved	0	-	Unchangeable	<a href="#">"H29_en.18" on page 389</a>
H29.19	2029-14h	Position control word 2 (POS_STW2)	bit0: 1 = Tracking mode activated bit1: 1 = Set reference point bit2: 1 = Reference point stopper activated bit3: Reserved bit4: Reserved bit5: 1 = JOG incremental positioning activated 0 = Speed activated bit6: Reserved bit7: Reserved bit8: Reserved bit9: 1 = Searching for the reference point in the reverse direction 0 = Start searching for the reference point in the forward direction bit10: Reserved bit11: Reserved bit12: Reserved bit13: Reserved bit14: 1 = Software limit switch activated bit15: 1 = Stopper activated	0	-	Unchangeable	<a href="#">"H29_en.19" on page 390</a>
H29.20	2029-15h	Position speed override (EPOS)	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.20" on page 391</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.21	2029-16h	Customized receive word for telegram 111	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.21" on page 391</a>
H29.22	2029-17h	Torque reduction (MOMRED)	0 to 16363	0	-	Unchangeable	<a href="#">"H29_en.22" on page 392</a>
H29.23	2029-18h	Torque reference (AdditiveTorque)	-32768 to 32767	0	-	Unchangeable	<a href="#">"H29_en.23" on page 392</a>
H29.24	2029-19h	Torque upper limit (UpperLimit)	-32768 to 32767	0	-	Unchangeable	<a href="#">"H29_en.24" on page 392</a>
H29.25	2029-1Ah	Torque lower limit	-32768 to 32767	0	-	Unchangeable	<a href="#">"H29_en.25" on page 392</a>
H29.26	2029-1Bh	Customized receive word for 850 additive telegram	0 to -1	0	-	Unchangeable	<a href="#">"H29_en.26" on page 393</a>
H29.27	2029-1Ch	Message word (EPOS_MELDW)	0 to -1	0	-	Unchangeable	<a href="#">"H29_en.27" on page 393</a>



Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.50	2029-33h	Status word 1 (ZSW1)	bit0: 1 = Ready to switch on, control circuit switched on, initialization done bit1: 1 = Ready to run, main circuit switched on bit2: 1 = Run enable bit3: 1 = Fault bit4: 1 = Coast to stop deactivated (OFF2 deactivated) 0 = Coast to stop activated (OFF2 activated) bit5: 1 = Quick stop deactivated (OFF2 deactivated) 0 = Quick stop activated (OFF2 activated) bit6: 1 = Switch-on inhibited bit7: 1 = Warning existed bit8: Reserved bit9: 1 = PLC control request bit10: Reserved bit11: Reserved bit12: Reserved bit13: Reserved bit14: Reserved bit15: Reserved	0	-	Unchangeable	<a href="#">"H29_en.50" on page 393</a>
H29.51	2029-34h	Status word 2 (ZSW2)	bit0: Reserved bit1: Reserved bit2: Reserved bit3: Reserved bit4: Reserved bit5: Reserved bit6: Reserved bit7: Reserved bit8: Reserved bit9: Reserved bit10: Reserved bit11: Reserved bit12: bit12–bit15 drive heartbeat count value, uploaded to PLC bit13: bit12–bit15 drive heartbeat count value, uploaded to PLC bit14: bit12–bit15 drive heartbeat count value, uploaded to PLC bit15: bit12–bit15 drive heartbeat count value, uploaded to PLC	0	-	Unchangeable	<a href="#">"H29_en.51" on page 394</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.52	2029-35h	Speed actual value A (VEL_NIST_A)	-32768 to 32767	0	-	Unchangeable	<a href="#">"H29_en.52" on page 395</a>
H29.53	2029-36h	Speed actual B (VEL_NSOLL_B)	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.53" on page 395</a>
H29.55	2029-38h	Encoder status word (G1_ZSW)	bit0: 1 = Function 1 activated bit1: 1 = Function 2 activated bit2: 1 = Function 3 activated bit3: 1 = Function 4 activated bit4: 1 = Actual value 1 readable bit5: 1 = Actual value 2 readable bit6: 1 = Actual value 3 readable bit7: 1 = Actual value 4 readable bit8: Touch probe 1 bit9: Touch probe 2 bit10: Reserved bit11: Response encoder fault bit12: Set zero response bit13: Cyclic transmission of the absolute position in G1_XIST2 bit14: Parking encoder activated bit15: The encoder is faulty.	0	-	Unchangeable	<a href="#">"H29_en.55" on page 396</a>
H29.56	2029-39h	Encoder 1 position actual value 1 (G1_XIST1)	0 to 0	0	-	Unchangeable	<a href="#">"H29_en.56" on page 396</a>
H29.58	2029-3Bh	Encoder 1 position actual value 2 (G1_XIST2)	0 to 0	0	-	Unchangeable	<a href="#">"H29_en.58" on page 396</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.60	2029-3Dh	Position status word 1 (POS_ZSW1)	bit0: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit1: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit2: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit3: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit4: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit5: bit0–bit5 effective traversing block IS620F supports up to 16 blocks bit6: Reserved bit7: Reserved bit8: 1 = Reverse stopper activated bit9: 1 = Forward stopper activated bit10: 1 = JOG activated bit11: 1 = Proactive reference point approach activated bit12: Reserved bit13: 1 = Running block activated bit14: 1 = Setting activated bit15: 1 = MDI activated 0 = MDI deactivated	0	-	Unchangeable	<a href="#">"H29_en.60" on page 397</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.61	2029-3Eh	Position status word 2 (POS_ZSW2)	bit0:1 = Tracking mode activated bit1:1 = Speed limit activated bit2:1 = Setpoint available bit3: Reserved bit4:1 = Axis moving forwardly bit5:1 = Axis moving reversely bit6:1 = Negative software limit switch reached bit7:1 = Positive software limit switch reached bit8: 1 = Position actual value bit9:1 = Position actual value < = Limit switch position 1 bit10:1 = Direct output 1 through running block setting bit11:1 = Direct output 2 through running block setting bit12:1 = Fixed stop point reached bit13: 1 = Fixed stop point fastening torque reached bit14: 1 = Running to the fixed stop point activated bit15: 1 = RUN command activated	0	-	Unchangeable	<a href="#">"H29_en.61" on page 397</a>
H29.63	2029-40h	Customized send word for telegram 111	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.63" on page 398</a>
H29.65	2029-42h	Fault code	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.65" on page 398</a>
H29.66	2029-43h	Warning code	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.66" on page 399</a>
H29.67	2029-44h	Actual torque	32768 to 32767	0	-	Unchangeable	<a href="#">"H29_en.67" on page 399</a>
H29.68	2029-45h	User-defined send word for 850 additive telegram	0 to 65535	0	-	Unchangeable	<a href="#">"H29_en.68" on page 399</a>

Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H29.69	2029-46h	XIST_A position feedback	-2147483648 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.69" on page 399</a>
H29.90	2029-5Bh	Modulo axis modulus	0 to 2147483647	0	-	Unchangeable	<a href="#">"H29_en.90" on page 400</a>

## 5.24 Parameter Group H30

Parameter	Hex	Name	Setpoint	Default	Unit	Change mode:	Page
H30.01	2030-02h	DO function state 1 read through communication	0 to 65535	0	-	Unchangeable	<a href="#">"H30_en.01" on page 400</a>
H30.02	2030-03h	DO function state 2 read through communication	0-65535+H941	0	-	Unchangeable	<a href="#">"H30_en.02" on page 400</a>

## 5.25 Parameter Group H31







Parameter	Hex	Name	Setpoint	Default	Unit	Change Mode	Page
H31.00	2031-01h	VDI virtual level set through communication	0 to 65535	0	-	Real-time	<a href="#">"H31_en.00" on page 401</a>
H31.04	2031-05h	DO state set through communication	0 to 65535	0	-	Real-time	<a href="#">"H31_en.04" on page 401</a>
H31.09	2031-0Ah	Speed reference set via communication	-6000.000rpm to 6000.000rpm	0.000	RPM	Real-time	<a href="#">"H31_en.09" on page 402</a>
H31.11	2031-0Ch	Torque reference set via communication	-100.000%-100.000%	0.000	%	Real-time	<a href="#">"H31_en.11" on page 402</a>




## 6 Appendix






### 6.1 Display of Monitoring Parameters

- Group H0b: Displays parameters used to monitor the operating state of the servo drive.
- Set H02.32 (Default keypad display) properly. After the motor operates normally, the keypad switches from status display to parameter display. The parameter group number is H0b and the offset within the group is the setpoint of H02.32.
- For example, if H02.32 is set to 00 and the motor speed is not 0 rpm, the keypad displays the value of H0b.00.





The following table describes the monitoring parameters in group H0b.







Parameter	Name	Unit	Meaning	Example of Display
H0b.00	Motor speed actual value	rpm	Displays the actual value of the motor speed after round-off, which can be accurate to 1 rpm.	Display of 3000 rpm:  -3000 rpm: 
H0b.01	Speed reference	rpm	Displays the present speed reference of the servo drive.	Display of 3000 rpm:  -3000 rpm: 
H0b.02	Internal torque reference	0.10%	Displays the ratio of actual torque output of the motor to the rated torque of the motor.	Display of 100.0%:  Display of -100.0%: 






Parameter	Name	Unit	Meaning	Example of Display
H0b.03	Monitored DI status	-	Displays the optocoupler status of DI1 to DI9: Upper LED segments turned on: The optocoupler is switched off (indicated by "1"). Lower LED segments turned on: The optocoupler is switched on (indicated by "0"). The value of H0b.03 read in the software tool is a decimal.	For example, if DI1 is low level and DI2 to DI9 are high level, The corresponding binary value is "110011110", and the value of H0b.03 read in the software tool is 414. The keypad displays as follows: 
H0b.05	Monitored DO status	-	Displays the optocoupler status of DO1 to DO5: Upper LED segments turned on: The optocoupler is switched off (indicated by "1"). Lower LED segments turned on: The optocoupler is switched on (indicated by "0"). The value of H0b.05 read in the software tool is a decimal.	For example, if DO1 is low level and DO2 to DO5 are high level: then, the binary value is "11110". and the value of H0b.05 read in the software tool is 30. The keypad displays as follows: 
H0b.07	Absolute position counter (32-bit decimal)	Reference unit	Displays current absolute position of the motor (reference unit).	Display of 1073741824 in reference unit: 






Parameter	Name	Unit	Meaning	Example of Display
H0b.09	Mechanical angle (pulses starting from the home)	p	<p>Indicates the current mechanical angle (p) of the motor. The value 0 indicates that the mechanical angle is 0°.</p> <p>Maximum value of H0b.09 for an incremental encoder: Number of encoder pulses per revolution x 4 - 1. For example, the maximum value of H0b.09 for a 2500-PPR incremental encoder is 9999.</p> <p>Maximum value of H0b.09 for an absolute encoder is 65535. The actual mechanical angle is calculated using the following formula:</p> $\text{Actual mechanical angle} = \frac{\text{H0b.09}}{\text{Max. H0b.09}+1} \times 360.0^\circ$	<p>Display of 10000 p:</p> 
H0b.10	Rotation angle (electrical angle)	0.1°	Displays current electrical angle of the motor.	<p>Display of 360.0°:</p> 
H0b.11	Speed corresponding to the input position reference	rpm	Displays the speed corresponding to the position reference per control cycle of the servo drive.	<p>Display of 3000 rpm:</p>  <p>-3000 rpm:</p> 
H0b.12	Average load rate	0.10%	Displays the ratio of the average load torque to the rated torque of the motor.	<p>Display of 100.0%:</p> 






Parameter	Name	Unit	Meaning	Example of Display
H0b.13	Input position reference counter (32-bit decimal)	Reference unit	Counts and displays the number of input position references.	<p>Display of 1073741824 in reference unit:</p> 
H0b.15	Encoder position deviation counter (32-bit decimal)	Encoder unit	Encoder position deviation = Sum of input position references (encoder unit) – Sum of pulses fed back by the encoder (encoder unit)	<p>Display of 10000 in encoder unit:</p> 
H0b.17	Feedback pulse counter (32-bit decimal)	Encoder unit	Counts and displays the number of pulses fed back by the encoder (encoder unit).	<p>Display of 1073741824 in encoder unit:</p> 
H0b.19	Total power-on time (32-bit decimal)	0.1s	Counts and displays the total power-on time of the servo drive.	<p>Display of 429496729.5s:</p> 

Parameter	Name	Unit	Meaning	Example of Display
H0b.24	RMS value of phase current	0.01 A	Displays the RMS value of the phase current of the servo motor.	Display of 4.60 A: 
H0b.26	Bus voltage	0.1 V	Displays the DC bus voltage of the main circuit.	Display of 311.0 V rectified from 220 VAC:  Display of 537.0 V rectified from 380 VAC: 
H0b.27	Module temperature	°C	Displays the temperature of the power module inside the servo drive.	Display of 27°C: 
H0b.33	Fault log	-	Used to select the previous fault to be viewed. 0: Present fault 1: Last fault 2: 2nd to last fault ... 9: 9th to last fault	0: Display of present fault: 
H0b.34	Fault code of the selected fault	-	Displays the code of the fault selected in H0b.33. When no fault occurs, the displayed value of H0b.34 is E000.0.	If H0b.33 is 0, and H0b.34 is E941.0, the current fault code is 941. Corresponding display: 

Parameter	Name	Unit	Meaning	Example of Display
H0b.35	Time stamp upon occurrence of the selected fault	s	Displays the total operating time of the servo drive when the fault displayed in H0b.34 occurred. When no fault occurs, the value of H0b.35 is 0.	<p>If H0b.34 is E941.0 and H0b.35 is 107374182.4, the current fault code is 941 and the total operating time of the servo drive is 107374182.4s when the fault occurs.</p> 
H0b.37	Motor speed upon occurrence of the selected fault	rpm	Displays the servo motor speed when the fault displayed in H0b.34 occurred. When no fault occurs, the value of H0b.37 is 0.	<p>Display of 3000 rpm:</p>  <p>-3000 rpm:</p> 
H0b.38	Motor phase U current upon occurrence of the selected fault	0.01 A	Displays the RMS value of motor phase U winding current when the fault displayed in H0b.34 occurred. When no fault occurs, the value of H0b.38 is 0.	<p>Display of 4.60 A:</p> 
H0b.39	Motor phase V current upon occurrence of the selected fault	0.01 A	Displays the RMS value of motor phase V winding current when the fault displayed in H0b.34 occurred. When no fault occurs, the value of H0b.39 is 0.	<p>Display of 4.60 A:</p> 

Parameter	Name	Unit	Meaning	Example of Display
H0b.40	Bus voltage upon occurrence of the selected fault	V	Displays the DC bus voltage of the main circuit when the fault displayed in H0b.34 occurred. When no fault occurs, the value of H0b.40 is 0.	<p>Display of 311.0 V rectified from 220 VAC:</p>  <p>Display of 537.0 V rectified from 380 VAC:</p> 
H0b.41	DI status upon occurrence of the selected fault	-	<p>Displays the high/low level status of DI1 to DI9 when the fault displayed in H0b.34 occurs.</p> <p>The method for determining the DI level status is the same as that of H0b.03. When no fault occurs, all DIs are displayed as low level in H0b.41 (indicated by the decimal value 0).</p>	<p>Display of H0b.41 = 414:</p> 
H0b.42	DO status upon occurrence of the selected fault	-	<p>Displays the high/low level status of DO1 to DO5 when the fault displayed in H0b.34 occurred.</p> <p>The method for determining the DO level status is the same as that of H0b.05. When no fault occurs, all DOs are displayed as low level in H0b.42 (indicated by the decimal value 0).</p>	<p>Display of H0b.42 = 15:</p> 
H0b.53	Position deviation counter (32-bit decimal)	Reference unit	Position deviation = Sum of input position references (reference unit) - Sum of pulses fed back by the encoder (reference unit)	<p>Display of 10000 in reference unit:</p> 

Parameter	Name	Unit	Meaning	Example of Display
H0b.55	Motor speed actual value	0.1 rpm	Displays the actual value of the motor speed, which can be accurate to 0.1 RPM.	<p>Display of 3000.0rpm:</p>  <p>Display of -3000.0 RPM:</p> 
H0b.64	Real-time input position reference counter	Reference unit	Displays the value of the position reference counter before being divided or multiplied by the electronic gear ratio. This value is independent of the servo drive status and the control mode.	<p>Display of 1073741824 in reference unit:</p> 

6.2 DIDO Function Assignment

Code	Name	Function Name	Description	Remarks
Description of DI Signals				
FunIN.1	S-ON	Servo ON	Disabled: Servo motor disabled Enabled: Servo motor enabled	The corresponding terminal logic must be level-triggered. The change of the corresponding DI/VDI or terminal logic is activated at next power-on.

Code	Name	Function Name	Description	Remarks
FunIN.3	GAIN-SEL	Gain Switchover	<ul style="list-style-type: none"> <li>● H08.09 = 1:</li> <li>● Inactive: Speed control loop being PI control</li> <li>● Active: Speed control loop being P control</li> <li>● H08.09 = 2:</li> <li>● Inactive: Fixed to the 1st group of gains</li> <li>● Active: Fixed to the 2nd group of gains</li> </ul>	The corresponding terminal logic is recommended to be level-triggered.
FunIN.14	P-OT	Positive limit switch	Enabled: Forward drive inhibited Disabled: Forward drive permitted	Overtravel prevention applies when the machine moves beyond the limit. It is recommended that the corresponding terminal logic is level-triggered.
FunIN.15	N-OT	Negative limit switch	Overtravel prevention applies when the load moves beyond the limit. Active: Reverse drive inhibited Inactive: Reverse drive allowed	The corresponding terminal logic is recommended to be level-triggered.
FunIN.16	P-CL	Positive external torque limit	The torque limit source is switched based on H07.07 (Torque limit source). H07.07 = 1: Active: Positive external torque limit activated Inactive: Positive internal torque limit activated	The corresponding terminal logic is recommended to be level-triggered.
FunIN.17	N-CL	Negative external torque limit	The torque limit source is switched based on H07.07 (Torque limit source). H07.07 = 1: Active: Negative external torque limit activated Inactive: Negative internal torque limit activated	The corresponding terminal logic is recommended to be level-triggered.
FunIN.18	JOGCMD+	Forward jog	Active: Input based on command Inactive: Command input stopped	The corresponding terminal logic is recommended to be level-triggered.
FunIN.19	JOGCMD-	Reverse jog	Active: Input in reverse to the command Inactive: Command input stopped	The corresponding terminal logic is recommended to be level-triggered.

Code	Name	Function Name	Description	Remarks
FunIN.31	HomeSwitch	Home switch	Inactive: The switch is not triggered Enabled: The switch is triggered.	The corresponding terminal logic must be level-triggered. It is recommended to assign this function to a high-speed DI terminal. If the logic is set to 2 (rising edge active), the servo drive forcibly changes it to 1 (active high). If the logic is set to 3 (falling edge active), the servo drive forcibly changes it to 0 (active low). If the logic is set to 4 (both rising edge and falling edge active), the servo drive forcibly changes it to 0 (low level active).
FunIN.32	HomingStart	Homing enable	Inactive: Disabled Active: Enabled	-
FunIN.34	Emergence Stop	Emergency stop	Enabled: Position lock is applied after stop at zero speed. Disabled: Current operating state is unaffected.	The corresponding terminal logic is recommended to be level-triggered.
FunIN.36	V_LmtSel	Internal speed limit source	Inactive: H07.19 used as positive/negative internal speed limit Active: H07.20 used as positive/negative internal speed limit	The corresponding terminal logic is recommended to be level-triggered.
FunIN.38	TouchProbe1	Touch probe 1	Disabled - Touch probe is not triggered. Enabled - Touch probe is triggerable.	The touch probe logic is only related to the touch probe function (60B8h).
FunIN.39	TouchProbe2	Touch probe 2	Disabled - Touch probe is not triggered. Enabled - Touch probe is triggerable.	The touch probe logic is only related to the touch probe function (60B8h).
FunIN.41	HomeRecord	Present position as the home	Inactive: The switch is not triggered Active: Triggered	The corresponding terminal logic is recommended to be level-triggered.
FunIN.56	MExTriger	External switch of EPOS program block	Active: If H28.68 = 1, the program block function triggers the enabling operation. Inactive: No external DI program block trigger signal.	-
Description of DO signals				
FunOUT.1	S-RDY	Ready to switch on	The servo drive is ready to receive the S-ON signal. Enabled: The servo drive is ready. Disabled: The servo drive not ready.	-

Code	Name	Function Name	Description	Remarks
FunOUT.2	TGON	Motor rotation signal	Inactive. Absolute value of filtered motor speed is lower than the setpoint of H06.16. Active. Absolute value of filtered motor speed reaches the setpoint of H06.16.	-
FunOUT.3	ZERO	Zero speed signal	Inactive: Difference between motor speed feedback and reference value larger than H06.19 (Threshold of zero speed output signal) Active: The difference between the motor speed feedback and the reference value is within the threshold defined by H06.19.	-
FunOUT.4	V-CMP	Speed matching	Active when the absolute value of the difference between the motor speed and the speed reference lower than H06.17 (Threshold of V-Cmp signal) in the speed control mode	-
FunOUT.5	COIN	Positioning completed	Active when position deviation pulses reaching H05.21 (Threshold of positioning completion) in the position control mode	-
FunOUT.6	NEAR	Proximity	Active when position deviation pulses reaching H05.22 (Threshold of proximity) in the position control mode	-
FunOUT.7	C-LT	Torque limit	Confirming torque limit: Active: Servo drive torque reference reaching the torque limit value and restricted to this value Inactive: Servo drive torque reference not reaching the torque limit value	-
FunOUT.8	V-LT	Speed limit	Confirming speed limit in torque control: Active: Motor speed limited Inactive: Motor speed unlimited	-
FunOUT.9	BK	Brake output	Brake signal output: Active: Brake released Active: The power is off, the brake is released, and the motor can rotate.	-



Code	Name	Function Name	Description	Remarks
FunOUT.10	WARN	Warning	Enabled: The servo drive issued a warning. Disabled: The servo drive issued no warning or the warning has been reset.	-
FunOUT.11	ALM	Fault	The servo drive is faulty. Inactive: No fault occurred on the servo drive or the fault has been reset.	-
FunOUT.16	HomeAttain	Homing is completed.	Homing state: Active: Homing completed in the position control mode Inactive: Homing not completed	-
FunOUT.18	ToqReach	Torque Reach Output	Active: Absolute value of torque reference reached setpoint Inactive: Absolute value of torque reference smaller than setpoint	-
FunOUT.19	V-Arr	Speed reaches output	Active: Speed feedback reaches setpoint Inactive: Speed feedback smaller than setpoint	-
FunOUT.21	DB	Dynamic braking output	Active: Dynamic brake relay opened Inactive: Dynamic braking relay closed	-
FunOUT.25	CMP	Position compare DO	Enabled: The servo drive passed the target position comparison point. Inactive: The servo drive did not pass the target position comparison point.	-
FunOUT.30	WARN OR ALM	Warning or fault output	Active: A warning or fault is present. Inactive: No warning or fault.	-
FunOUT.32	EDM	EDM output	Enabled - STO is triggered Disabled - STO is not triggered	The EDM outputs active signals only when both the 24 V input voltages for STO1 and STO2 are disconnected.



19011668A01

---

Copyright © Shenzhen Inovance Technology Co., Ltd.

---

**Shenzhen Inovance Technology Co., Ltd.**

[www.inovance.com](http://www.inovance.com)

---

**Add.:** Inovance Headquarters Tower, High-tech Industrial Park,  
Guanlan Street, Longhua New District, Shenzhen

**Tel:** (0755) 2979 9595

**Fax:** (0755) 2961 9897

---

**Suzhou Inovance Technology Co., Ltd.**

[www.inovance.com](http://www.inovance.com)

---

**Add.:** No. 16 Youxiang Road, Yuexi Town,  
Wuzhong District, Suzhou 215104, P.R. China

**Tel:** (0512) 6637 6666

**Fax:** (0512) 6285 6720